

---

# **magicolor<sup>®</sup> 4690MF Printer / Copier / Scanner User's Guide**

---

**A0FD-9561-00A**

**1800859-001A**

---

## Thank You

Thank you for purchasing a magicolor 4690MF. You have made an excellent choice. Your magicolor 4690MF is specially designed for optimal performance in Windows and Macintosh environments.

## Trademarks

KONICA MINOLTA and the KONICA MINOLTA logo are trademarks or registered trademarks of KONICA MINOLTA HOLDINGS, INC.

magicolor and PageScope are trademarks or registered trademarks of KONICA MINOLTA BUSINESS TECHNOLOGIES, INC.

All other trademarks and registered trademarks are the property of their respective owners.

## Copyright Notice

Copyright © 2008 KONICA MINOLTA BUSINESS TECHNOLOGIES, INC., Marunouchi Center Building, 1-6-1 Marunouchi, Chiyoda-ku, Tokyo, 100-0005, Japan. All Rights Reserved. This document may not be copied, in whole or part, nor transferred to any other media or language, without written permission of KONICA MINOLTA BUSINESS TECHNOLOGIES, INC.

## Notice

KONICA MINOLTA BUSINESS TECHNOLOGIES, INC. reserves the right to make changes to this guide and to the equipment described herein without notice. Considerable effort has been made to ensure that this guide is free of inaccuracies and omissions. However, KONICA MINOLTA BUSINESS TECHNOLOGIES, INC. makes no warranty of any kind including, but not limited to, any implied warranties of merchantability and fitness for a particular purpose with regard to this guide. KONICA MINOLTA BUSINESS TECHNOLOGIES, INC. assumes no responsibility for, or liability for, errors contained in this guide or for incidental, special, or consequential damages arising out of the furnishing of this guide, or the use of this guide in operating the equipment, or in connection with the performance of the equipment when so operated.

---

# SOFTWARE LICENSE AGREEMENT

This package contains the following materials provided by Konica Minolta Business Technologies, Inc. (KMBT): software included as part of the printing system, the digitally-encoded machine-readable outline data encoded in the special format and in the encrypted form ("Font Programs"), other software which runs on a computer system for use in conjunction with the Printing Software ("Host Software"), and related explanatory written materials ("Documentation"). The term "Software" shall be used to describe Printing Software, Font Programs and/or Host Software and also include any upgrades, modified versions, additions, and copies of the Software.

The Software is being licensed to you under the terms of this Agreement.

KMBT grants to you a non-exclusive sublicense to use the Software and Documentation, provided that you agree to the following:

1. You may use the Printing Software and accompanying Font Programs for imaging to the licensed output device(s), solely for your own internal business purposes.
  2. In addition to the license for Font Programs set forth in Section 1 ("Printing Software") above, you may use Roman Font Programs to reproduce weights, styles, and versions of letters, numerals, characters and symbols ("Typefaces") on the display or monitor for your own internal business purposes.
  3. You may make one backup copy of the Host Software, provided your backup copy is not installed or used on any computer. Notwithstanding the above restrictions, you may install the Host Software on any number of computers solely for use with one or more printing systems running the Printing Software.
  4. You may assign its rights under this Agreement to an assignee of all of Licensee's right and interest to such Software and Documentation ("Assignee") provided you transfer to Assignee all copies of such Software and Documentation Assignee agrees to be bound by all of the terms and conditions of this Agreement.
  5. You agree not to modify, adapt or translate the Software and Documentation.
  6. You agree that you will not attempt to alter, disassemble, decrypt, reverse engineer or decompile the Software.
  7. Title to and ownership of the Software and Documentation and any reproductions thereof shall remain with KMBT and its Licensor.
  8. Trademarks shall be used in accordance with accepted trademark practice, including identification of the trademark owner's name. Trademarks can only be used to identify printed output produced by the Software. Such use of any trademark does not give you any rights of ownership in that trademark.
  9. You may not rent, lease, sublicense, lend or transfer versions or copies of the Software that the Licensee does not use, or Software contained on any unused media, except as part of the permanent transfer of all Software and Documentation as described above.
  10. In no event will KMBT or its licensor be liable to you for any consequential, incidental INDIRECT, PUNITIVE or special damages, including any lost profits or lost saving, even if KMBT has been advised of the possibility of such damages, or for any claim by any third party. KMBT or its licensor disclaims all warranties with regard to the software, express or implied, including, without limitation implied warranties of merchantability, fitness for a particular purpose, title and non-infringement of third party rights. Some states or jurisdictions do not allow the exclusion or limitation of incidental, consequential or special damages, so the above limitations may not apply to you.
-

11. Notice to Government End Users: The Software is a “commercial item,” as that term is defined at 48 C.F.R.2.101, consisting of “commercial computer software” and “commercial computer software documentation,” as such terms are used in 48 C.F.R. 12.212. Consistent with 48 C.F.R. 12.212 and 48 C.F.R. 227.7202-1 through 227.7202-4, all U.S. Government End Users acquire the Software with only those rights set forth herein.
  12. You agree that you will not export the Software in any form in violation of any applicable laws and regulations regarding export control of any countries.
-

# Legal Restrictions on Copying

Certain types of documents must never be copied with the purpose or intent to pass copies of such documents off as the originals.

The following is not a complete list, but is meant to be used as a guide to responsible copying.

## Financial Instruments

- Personal checks
- Traveler's checks
- Money orders
- Certificates of deposit
- Bonds or other certificates of indebtedness
- Stock certificates

## Legal Documents

- Food stamps
- Postage stamps (canceled or uncanceled)
- Checks or drafts drawn by government agencies
- Internal revenue stamps (canceled or uncanceled)
- Passports
- Immigration papers
- Motor vehicle licenses and titles
- House and property titles and deeds

## General

- Identification cards, badges, or insignias
- Copyrighted works without permission of the copyright owner

In addition, it is prohibited under any circumstances to copy domestic or foreign currencies, or works of art without permission of the copyright owner.

When in doubt about the nature of a document, consult with legal counsel.



*In order to prohibit the illegal reproduction of certain documents, such as paper currency, this machine is equipped with a counterfeit prevention feature.*


*Due to the counterfeit prevention feature that this machine is equipped with, images may be distorted.*

---

## For EU member states only

This symbol means: **Do not dispose of this product together with your household waste!**

Please contact the Local Authority for appropriate disposal instructions. In the case of a new device being purchased, the used one can also be given to our dealer for appropriate disposal. Recycling of this product will help to conserve natural resources and prevent potential negative consequences for the environment and human health caused by inappropriate waste handling.



This product complies with RoHS (2002/95/EC) directive.

---

---

# Contents

---

<b>1 Introduction .....</b>	<b>1</b>
<b>Getting Acquainted with Your Machine</b>	<b>2</b>
Space Requirements	2
Part Names	4
Front View	4
Rear View	5
Front View with Options	5
Drivers CD/DVD	6
Printer Drivers	6
Scanner Drivers	6
PC Fax Drivers	6
Applications CD/DVD	8
Applications	8
Documentation CD/DVD	9
Documentation	9
System Requirements	10
<b>2 Control Panel and Configuration Menu .....</b>	<b>11</b>
<b>About the Control Panel</b>	<b>12</b>
Control Panel Indicators and Keys	12

- Display Indications 15
  - Main Screen (Copy Mode) 15
  - Main Screen (Scan Mode) 17
  - Main Screen (Fax Mode) 20
  - Print Screen 23

**Checking the Machine Status and Settings 24**

- TONER REMAINING 24
- REPORT/STATUS Menu 24
  - TOTAL PRINT 25
  - SUPPLY STATUS 25
  - TX/RX RESULT 26
  - REPORT 26

**Configuration Menu Overview 27**

- UTILITY Menu 27
  - MACHINE SETTING Menu 29
  - PAPER SETUP Menu 34
  - ADMIN. MANAGEMENT Menu 37
  - COPY SETTING Menu 51
  - DIAL REGISTER Menu 53
  - FAX TX OPERATION Menu. 54
  - FAX RX OPERATION Menu. 56
  - REPORTING Menu. 59
  - SCAN SETTING Menu 61

**3 Media Handling .....65**

**Print Media 66**

- Specifications 66
- Types 67
  - Plain Paper (Recycled Paper) 67
  - Thick Stock 68
  - Envelope 69
  - Label 70
  - Letterhead 71
  - Postcard 71
  - Transparency 72
  - Glossy Media 73
  - Guaranteed Imageable (Printable) Area 75
  - Imageable Area—Envelopes 75
  - Page Margins 75

**Loading Media 76**

- How do I load media? 76
- Tray 1 (Manual Feed Tray) 76
  - Loading Plain Paper 76
  - Other Media 78
  - Loading Envelopes 79

	Loading Label Sheets/Letterheads/Postcards/Thick Stock/Glossy Media and Transparencies	81
	Tray 2	83
	Loading Plain Paper	83
	Tray 3 (Optional Lower Feeder Unit)	86
	Loading Plain Paper	86
	<b>About Duplex Printing</b>	<b>89</b>
	How do I autoduplex?	89
	<b>Output Tray</b>	<b>91</b>
	<b>Media Storage</b>	<b>92</b>
	<b>Original Media</b>	<b>93</b>
	Specifications	93
	Documents that can be placed on the original glass	93
	Documents that can be loaded into the ADF	93
	<b>Loading a Document to be Copied</b>	<b>95</b>
	Placing a document on the original glass	95
	Loading a document into the ADF	96
<b>4</b>	<b>Using the Printer Driver .....</b>	<b>97</b>
	<b>Selecting Printer Driver Options/Defaults (for Windows)</b>	<b>98</b>
	<b>Uninstalling the Printer Driver (for Windows)</b>	<b>100</b>
	Windows Vista/XP/Server 2003/2000	100
	<b>Displaying Printer Driver Settings</b>	<b>100</b>
	Windows Vista	100
	Windows XP/Server 2003	100
	Windows 2000	100
	<b>Printer Driver Settings</b>	<b>102</b>
	Common Buttons	102
	Basic Tab	103
	Layout Tab	104
	Overlay Tab	104
	Watermark Tab	104
	Quality Tab	104
	Device Options Setting Tab	105
	Version Tab	105
<b>5</b>	<b>Using the Copier .....</b>	<b>107</b>
	<b>Making Basic Copies</b>	<b>108</b>
	Basic Copy Operation	108
	Specifying the Copy Quality Setting	109
	Selecting the Copy Mode	109
	Specifying the Copy Density	110
	Specifying the Zoom Ratio	110
	Selecting a Preset Zoom Ratio	110
	Specifying a Custom Zoom Ratio	110
	Selecting the Media Tray	111

**Making Advanced Copies 112**

- Setting 2in1/4in1 Copying 112
  - 2in1/4in1 Copying From the ADF 112
  - 2in1/4in1 Copying From the Original Glass 112
- Setting a Copy Function 113
  - ID Card Copying 114
  - Repeat Copying 115
  - Poster Copying 116
- Setting Duplex (Double-Sided) Copying 117
  - Duplex (Double-Sided) Copying From the ADF 117
  - Duplex (Double-Sided) Copying From the Original Glass 118
  - Duplex (Double-Sided) Document Copying 119
- Setting Collated (Sort) Copying 119
  - Collated (Sort) Copying From the ADF 119
  - Collated (Sort) Copying From the Original Glass 119

**6 Using the Scanner .....121**

**Scanning From a Computer Application 122**

- Basic Scanning Operation 122
- Windows TWAIN Driver Settings 123
- Windows WIA Driver Settings 124
- Macintosh TWAIN Driver Settings 125

**Scanning With the Machine 128**

- Basic Scanning Operation 128
- Specifying the Data Location 130
  - Saving Data on a Computer Connected (Scan to PC) 130
  - Saving Data on a USB Memory Device (Scan to USB Memory) 130
- Specifying the Destination Address (Scan to E-mail/FTP/SMB) 132
  - Directly Entering the E-mail Address 132
  - Selecting From the Favorite List 133
  - Selecting a Speed Dial Destination 133
  - Selecting a Group Dial Destination 134
  - Selecting From the Address Book 135
  - Searching the Address Book 135
  - Searching an LDAP Server 136
  - Specifying Multiple Destination Addresses 137
  - Editing a Specified Destination Address 138
  - Deleting a Specified Destination Address 138
- Registering/Editing Addresses 139
  - Registering in the Favorite List 139
  - Deleting From the Favorite List 140
  - Registering Speed Dial Destinations (Direct Input) 140
  - Registering Speed Dial Destinations (LDAP Search) 142
  - Editing/Deleting Speed Dial Destinations 143
  - Registering Group Dial Destinations 144
  - Editing/Deleting Group Dial Destinations 145

Selecting the Data Format	146
Selecting the Scan Quality Setting	146
Selecting the Resolution	146
Selecting the Scan Mode	147
Selecting the Scan Density	147
Setting Duplex (Double-Sided) Scanning	147
Setting the Scan Size	148
Setting the Scan Color	148
Specifying the Subject	148
Deleting a Queued Transmission Job	148
<b>7 Replacing Consumables</b>	<b>151</b>
<b>Replacing Consumables</b>	<b>152</b>
About Toner Cartridges	152
Replacing a Toner Cartridge	155
Replacing an Imaging Unit	159
Replacing the Waste Toner Bottle	165
Replacing the Transfer Roller	169
Replacing the Transfer Roller	169
Replacing the Ozone Filter	173
Replacing the Transfer Belt Unit	174
Replacing the Fuser Unit	182
<b>8 Maintenance</b>	<b>187</b>
<b>Maintaining the Machine</b>	<b>188</b>
<b>Cleaning the Machine</b>	<b>190</b>
Exterior	190
Media Rollers	191
Cleaning the Media Feed Rollers (Manual Feed Tray)	191
Cleaning the Media Feed Rollers (Tray 2/3)	193
Cleaning the Media Transfer Rollers for Tray 3	194
Cleaning the Media Feed Rollers for the ADF	195
Cleaning the Media Feed Rollers for the Duplex	196
Laser Lens	197
<b>9 Troubleshooting</b>	<b>199</b>
<b>Introduction</b>	<b>200</b>
<b>Printing a Configuration Page</b>	<b>201</b>
<b>Preventing Media Misfeeds</b>	<b>202</b>
<b>Understanding the Media Path</b>	<b>203</b>
<b>Clearing Media Misfeeds</b>	<b>203</b>
Media Misfeed Messages and Clearing Procedures	204
Clearing a Media Misfeed from Tray 1 (Manual Feed Tray) and Transfer Roller	206
Clearing a Media Misfeed in Tray 2	209
Clearing a Media Misfeed in Tray 3	213

Clearing a Media Misfeed from the ADF	215
Clearing a Media Misfeed from the Duplex	217
Clearing a Media Misfeed from the Fuser Unit	218
Clearing a Media Misfeed from the Switchback	222
Clearing a Media Misfeed from the Horizontal Transport Area	224
<b>Solving Problems with Media Misfeeds</b>	<b>226</b>
<b>Solving Other Problems</b>	<b>229</b>
<b>Solving Problems with Printing Quality</b>	<b>235</b>
<b>Status, Error, and Service Messages</b>	<b>242</b>
Status Messages	242
Error Messages	243
Service Messages	250
<b>10 Installing Accessories</b>	<b>251</b>
<b>Introduction</b>	<b>252</b>
<b>Antistatic Protection</b>	<b>253</b>
<b>Tray 3 (Lower Feeder Unit)</b>	<b>254</b>
Kit Contents	254
Installing Tray 3	255
<b>A Appendix</b>	<b>259</b>
<b>Technical Specifications</b>	<b>260</b>
Consumable Life Expectancy Chart	263
User-Replaceable	263
Service-Replaceable	264
<b>Entering Text</b>	<b>265</b>
Key Operation	265
Entering Fax Numbers	265
Entering Names	266
Entering E-mail Addresses	266
Changing Input Mode	267
Inputting Example	267
Correcting Text and Input Precautions	268
<b>Our Concern for Environmental Protection</b>	<b>269</b>
What is an ENERGY STAR product?	269

---

*Introduction*


---

**1**


# Getting Acquainted with Your Machine

## Space Requirements


To ensure easy operation, consumable replacement and maintenance, adhere to the recommended space requirements detailed below.



Front View



Front View with Options



Side View with Options




*The option appears shaded in the above illustrations.*

# Part Names

The following drawings illustrate the parts of your machine referred to throughout this guide, so please take some time to become familiar with them.



## Front View



- 1—Control panel
- 2—Automatic Document Feeder (ADF)
  - 2-a: ADF feed cover
  - 2-b: Document guide
  - 2-c: Document feed tray
  - 2-d: Document output tray



*The ADF may appear as “document cover” in status and error messages.*


- 3—Tray 1 (Manual feed tray)
- 4—Tray 2
- 5—Original glass
- 6—Original cover pad
- 7—Scanner unit
- 8—Fuser unit
- 9—Right side cover
- 10—Transfer roller
- 11—Transfer belt unit
- 12—Imaging unit(s)
- 13—Laser lens cleaning tool
- 14—Front cover
- 15—Waste toner bottle
- 16—Toner cartridge(s)
- 17—Ozone filter






## Rear View

- 1—Output tray
- 2—Extend tray
- 3—Power switch
- 4—Power connection
- 5—TEL (telephone) jack
- 6—LINE (telephone line) jack
- 7—10Base-T/100Base-TX/  
1000Base-T Ethernet Inter-  
face port
- 8—USB port
- 9—Rear cover
- 10—USB HOST port



## Front View with Options

- 1—Lower feeder unit (Tray 3)



# Drivers CD/DVD

## Printer Drivers

Drivers	Use/Benefit
Windows Vista/XP/Server 2003/2000	These drivers give you access to all of the printer features, including finishing and advanced layout. For details, refer to “Displaying Printer Driver Settings” on page 100.
Windows Vista/XP/Server 2003 for 64bit	
Macintosh OS 10.2.8 or later	

## Scanner Drivers

Drivers	Use/Benefit
TWAIN Driver for Windows Vista/XP/Server 2003/2000	These drivers enables you to set scanning functions, such as the color setting and size adjustments.  For details, refer to “Windows TWAIN Driver Settings” on page 123.
TWAIN Driver for Macintosh OS X 10.2.8 or later	
WIA Driver for Windows Vista/XP	This driver enables you to set scanning functions, such as the color setting and size adjustments.  For details, refer to “Windows WIA Driver Settings” on page 124.

## PC Fax Drivers

Drivers	Use/Benefit
Windows Vista/XP/Server 2003/2000	These drivers enable you to specify fax settings, such as the paper settings for sending faxes and the settings for editing the address book. For details, refer to the Facsimile User's Guide on the Documentation CD/DVD.
Windows Vista/XP for 64 bit	



*For details on the installation of the drivers, refer to the Installation Guide on the Documentation CD/DVD.*



*For details of the Macintosh drivers, refer to the Reference Guide on the Documentation CD/DVD.*



*Windows TWAIN driver does not correspond to 64-bit application though it corresponds to 32-bit application on 64-bit OS.*

# Applications CD/DVD

## Applications

Applications	Use/Benefit
PaperPort SE	<p>This software is a document management software package that helps you scan, organize, access, share, and manage both your paper and digital documents on your personal computer.</p> <p>For details, refer to the PaperPort SE User's Guide from the Help menu.</p>
Local Setup Utility (LSU)	<p>This software enables one-touch dialing, speed dialing, and group dialing for faxes to be created and edited from the computer. In addition, the status of this machine can be checked.</p> <p>For details, refer to the Reference Guide on the Documentation CD/DVD.</p>
LinkMagic	<p>This software enables scanned document to be saved in a file, processed, mail attached, and printed out.</p> <p>For details, refer to the Reference Guide on the Documentation CD/DVD.</p>
PageScope Net Care	<p>Printer management functions such as status monitoring and network settings can be accessed.</p> <p>For details, refer to the PageScope Net Care Quick Guide on the Applications CD/DVD.</p>
PageScope Network Setup	<p>Using the TCP/IP, basic network printer settings can be specified.</p> <p>For details, refer to the PageScope Network Setup User Manual on the Applications CD/DVD.</p>

## Documentation CD/DVD

### Documentation

Documentation	Use/Benefit
Installation Guide	This manual provides details on the initial operations that must be performed in order to use this machine, such as setting up the machine and installing the drivers.
Printer/Copier/Scanner User's Guide (this manual)	This manual provides details on general daily operations, such as using the drivers and control panel and replacing consumables.
Facsimile User's Guide	This manual provides details on general fax operations, such as sending and receiving faxes and using the control panel.
Reference Guide	This manual provides details on installing the Macintosh drivers and on specifying settings for the network, Local Setup Utility (LSU), LinkMagic and the printer management utility.
Quick Guide	The Quick Guide provides simple procedures for copy, fax and scanning operations and for replacing consumables.
Service & Support Guide	This guide provides information on product support and servicing, including user registration, frequently asked questions and customer service inquiries.
Readme	This guide provides details on operating conditions and precautions. Be sure to read this information before using the machine.

# System Requirements

- Personal computer
  - For Windows
    - Pentium II: 400MHz or higher
  - For Macintosh
    - PowerPC G3 or later (G4 or later is recommended)
    - Intel processor
- Operating System
  - Microsoft Windows Vista Home Basic/Home Premium/Ultimate/Business/Enterprise, Windows Vista Home Basic/Home Premium/ Ultimate/Business/Enterprise x64 Edition, Windows XP Home Edition/ Professional (Service Pack 2 or later), Windows XP Professional x64 Edition, Windows Server 2003, Windows Server 2003 x64 Edition, Windows 2000 (Service Pack 4 or later)
  - Mac OS X (10.2.8 or later; We recommend installing the latest patch)
- Free hard disk space  
256 MB or more
- RAM  
128 MB or more
- CD/DVD/DVD drive
- I/O interface
  - 10Base-T/100Base-TX (IEEE 802.3) Ethernet interface port
  - USB Revision 2.0 and USB Revision 1.1 compliant port



*The Ethernet cable and USB cable are not included with the machine.*



*For details of the Macintosh drivers, refer to the Reference Guide on the Documentation CD/DVD.*


---

***Control Panel  
and Configuration  
Menu***

---

**2**

# About the Control Panel



## Control Panel Indicators and Keys


No.	Name	Function
1	<b>Addressbook</b> key	Displays the information registered in the favorite list, speed dial destinations and group dial destinations.  For details, refer to the Facsimile User's Guide on the Documentation CD/DVD.
2	<b>Auto RX</b> indicator	Lights up when the automatic reception function is selected.  For details, refer to the Facsimile User's Guide on the Documentation CD/DVD.
3	<b>Redial/Pause</b> key	Recalls the last number dialed. Inserts a pause when a number is dialed.  For details, refer to the Facsimile User's Guide on the Documentation CD/DVD.
4	<b>Onhook</b> key	Sends and receives transmissions with the receiver on the hook.  For details, refer to the Facsimile User's Guide on the Documentation CD/DVD.
5	<b>Message window</b>	Displays settings, menus, and messages.

No.	Name	Function
6	▲/▼ keys	Moves up and down through menus, options, or choices.
7	◀/▶ keys	Moves left and right through menus, options, or choices.
8	<b>Select</b> key	Press to select the setting that is currently displayed.
9	<b>Error</b> indicator	Indicates an error condition.
10	<b>Back</b> key	<p>Clears the specified number of copies and entered text.</p> <p>Press to return to the previous screen.</p> <p>Press to cancel the setting that is currently displayed.</p>
11	<b>Keypad</b>	Enters desired number of copies. Enters fax numbers, E-mail addresses, and names of recipients.
12	<b>Fax</b> key/LED	<p>Enters Fax mode.</p> <p>Lights up in green to indicate that the machine is in Fax mode.</p> <p>For details, refer to the Facsimile User's Guide on the Documentation CD/DVD.</p>
13	<b>Scan</b> key/LED	<p>Enters Scan mode. (Scan to E-mail, Scan to FTP, Scan to SMB, Scan to PC, or Scan to USB Memory)</p> <p>Lights up in green to indicate that the machine is in Scan mode.</p> <p>For details on the Scanner functions, refer to chapter 6, "Using the Scanner"</p>
14	<b>Copy</b> key/LED	<p>Enters Copy mode.</p> <p>Lights up in green to indicate that the machine is in Copy mode.</p> <p>For details on the Copy functions, refer to chapter 5, "Using the Copier".</p>
15	<b>Start</b> (Color) key/LED	Starts a fax or color copy.
16	<b>Start</b> indicator	<p>Lights up in green when copying and fax transmission are possible.</p> <p>Lights up in orange when copying and fax transmissions are not possible, for example, during warm-up or if an error has occurred.</p>

No.	Name	Function
17	<b>Start</b> (B&W) key/LED	Starts a fax or monochrome copy.
18	<b>Stop/Reset</b> key	Returns the settings to their defaults and stops functions.


## Display Indications

### Main Screen (Copy Mode)



No.	Indication	Description
1	Copy settings	Allows the current settings to be checked and the various settings to be changed. For details, refer to “Copy settings” on page 16.
2	Status	Depending on the situation, the machine status or an error message may appear.
3	Copy density	Indicates the copy density.  AUTO appears when DENSITY is set to AUTO and the TEXT copy mode is selected.
4	Number of copies	Indicates the number of copies.


■ Copy settings



No.	Indication	Description
1	Media tray	Indicates the media tray that is selected. For details on selecting the media tray, refer to “Selecting the Media Tray” on page 111.
2	Zoom ratio	Indicates the zoom ratio that is specified. For details on specifying the zoom ratio, refer to “Specifying the Zoom Ratio” on page 110.
3	Copy quality	Indicates the copy quality that is selected. For details on selecting the copy quality, refer to “Specifying the Copy Quality Setting” on page 109.
4	Collated (Sort) copying	Indicates whether or not collated (Sort) copying is selected. For details on selecting collated (Sort) copying, refer to “Setting Collated (Sort) Copying” on page 119.
5	2in1/4in1 copying	Indicates whether or not 2in1/4in1 copying is selected. For details on selecting 2in1/4in1 copying, refer to “Setting 2in1/4in1 Copying” on page 112.


No.	Indication	Description
6	Double-sided/ single-sided copying	Indicates whether double-sided copying or single-sided copying is selected. For details on selecting double-sided/single-sided copying, refer to “Setting Duplex (Double-Sided) Copying” on page 117.
7	Copy function	Indicates the copy function that is set. For details on setting a copy function, refer to “Setting a Copy Function” on page 113.
8	UTILITY	Select this menu item to change the various machine settings. For details, refer to “UTILITY Menu” on page 27.
9	REPORT/STA- TUS	Select this menu item to view the total number of pages printed by this machine and the results of fax transmissions/receptions as well as to print the reports. For details, refer to “REPORT/STATUS Menu” on page 24.

## Main Screen (Scan Mode)



No.	Indication	Description
1	Scan settings	Allows the current settings to be checked and the various settings to be changed. For details, refer to “Scan settings” on page 18.
2	Status	Depending on the situation, the machine status or an error message may appear.
3	Available mem- ory	Indicates the percentage of memory available for scanning and fax operations.

■ Scan settings




No.	Indication	Description
1	Data format	Indicates the data format that is selected. For details on selecting the data format, refer to “Selecting the Data Format” on page 146.
2	Scan quality	Indicates the scan quality that is selected. For details on selecting the scan quality, refer to “Selecting the Scan Quality Setting” on page 146.

No.	Indication	Description
3	Scan data destination	<p>Indicates the specified destination for the scan data. For details on specifying the destination of the data, refer to “Specifying the Data Location” on page 130 and “Specifying the Destination Address (Scan to E-mail/FTP/SMB)” on page 132.</p> <p> <i>If no destination has been specified, SCAN TO appears.</i></p>
4	Single-sided/ double-sided scanning	<p>Indicates whether double-sided scanning or single-sided scanning is selected. For details on selecting double-sided/single-sided scanning, refer to “Setting Duplex (Double-Sided) Scanning” on page 147.</p>
5	Scan size	<p>Indicates the scan size that is selected. For details on selecting the scan size, refer to “Setting the Scan Size” on page 148.</p>
6	Scan color	<p>Indicates the scan color that is selected. For details on selecting the scan color, refer to “Setting the Scan Color” on page 148.</p>
7	SUBJECT	<p>Select this menu item to specify the subject. For details on specifying the subject, refer to “Specifying the Subject” on page 148.</p> <p> <i>This menu item does not appear if an FTP address or SMB address was specified as the destination.</i></p>
8	CANCEL RESERV.	<p>Select this menu item to display the list of jobs queued for transmission and to delete a job. For details, refer to “Deleting a Queued Transmission Job” on page 148.</p> <p> <i>This menu item does not appear if an e-mail address, FTP address or SMB address was specified as the destination.</i></p>


No.	Indication	Description
9	UTILITY	Select this menu item to change the various machine settings. For details, refer to "UTILITY Menu" on page 27.   This menu item does not appear if an e-mail address, FTP address or SMB address was specified as the destination.
10	REPORT/STATUS	Select this menu item to view the total number of pages printed by this machine and the results of fax transmissions/receptions as well as to print the reports. For details, refer to "REPORT/STATUS Menu" on page 24.   This menu item does not appear if an e-mail address, FTP address or SMB address was specified as the destination.

## Main Screen (Fax Mode)



No.	Indication	Description
1	Time	Indicates the current time configured in ADMIN. MANAGEMENT/USER SETTING/DATE&TIME in the UTILITY menu.
2	Available memory	Indicates the percentage of memory available for scanning and fax operations.
3	Fax settings	Allows the current settings to be checked and the various settings to be changed. For details, refer to "Fax settings" on page 21.
4	Status	Depending on the situation, the machine status or an error message may appear.

■ Fax settings




No.	Indication	Description
1	Fax quality	Indicates the fax quality that is selected. For details on selecting the fax quality, refer to the Facsimile User's Guide on the Documentation CD/DVD.
2	Fax destination	Indicates the specified fax destination. For details on specifying the destination, refer to the Facsimile User's Guide on the Documentation CD/DVD.   If no destination has been specified, FAX TO appears.

No.	Indication	Description
3	TIMER TX	Select this menu item to specify the time when the fax is to be sent. For details, refer to the Facsimile User's Guide on the Documentation CD/DVD.
4	Transmission mode	Indicates the fax transmission mode that is selected. For details on selecting the transmission mode, refer to the Facsimile User's Guide on the Documentation CD/DVD.
5	Single-sided/ double-sided faxing	Indicates the fax document scanning method (single-sided/double-sided) that is selected. For details on selecting double-sided/single-sided scanning, refer to the Facsimile User's Guide on the Documentation CD/DVD.
6	CANCEL RESERV.	<p>Select this menu item to display the list of jobs queued for transmission and to delete a job. For details, refer to "Deleting a Queued Transmission Job" on page 148.</p> <p> <i>This menu item does not appear if a destination has been specified.</i></p>
7	UTILITY	<p>Select this menu item to change the various machine settings. For details, refer to "UTILITY Menu" on page 27.</p> <p> <i>This menu item does not appear if a destination has been specified.</i></p>
8	REPORT/STA- TUS	<p>Select this menu item to view the total number of pages printed by this machine and the results of fax transmissions/receptions as well as to print the reports. For details, refer to "REPORT/STATUS Menu" on page 24.</p> <p> <i>This menu item does not appear if a destination has been specified.</i></p>

## Print Screen

When a print job is received, **PRINTER: Printing** appears in the status section of the main screen. To display the print screen (as shown below), press the ◀ key while **PRINTER: Printing** is displayed.

To cancel printing, press the **Stop/Reset** key when the print screen appears. Press the **Select** key to select **YES**.



No.	Indication	Description
1	Status	Displays messages indicating operations such as printing.
2	Media tray/ media size	Indicates the media tray and media size that is selected.

# Checking the Machine Status and Settings

## TONER REMAINING

With the main screen displayed, press the ◀ key to display the **TONER REMAINING** screen. From this screen, a general estimate of the amount of toner remaining in the toner cartridges can be viewed.



To return to the main screen, press the **Back** key.




If the **Select** key is held down for at least 2 seconds while the screen described above is displayed, the configuration page will be printed.

## REPORT/STATUS Menu

To display the REPORT/STATUS screen, select REPORT/STATUS in the main screen, and then press the **Select** key. From this menu, the total number of pages printed by this machine and the results of fax transmissions/receptions can be viewed. In addition, the reports can be printed. The REPORT/STATUS menu is structured as shown below.



To return to the previous screen, press the **Back** key. To display the main screen, press the **Stop/Reset** key.



## TOTAL PRINT

The total number of pages for each of the following can be checked.

TOTAL PRINT	This counter shows the total number of pages printed.
MONO COPY	This counter shows the total number of pages copied in black-and-white.
COLOR COPY	This counter shows the total number of pages copied in color.
MONO PRINT	This counter shows the total number of pages printed in black-and-white.
COLOR PRINT	This counter shows the total number of pages printed in color.
FAX PRINT	This counter shows the total number of pages that were faxed.
TOTAL SCAN	This counter shows the total number of document pages that were scanned.

## SUPPLY STATUS

The remaining amount of toner in the toner cartridges and the remaining service life of the imaging units can be displayed as a percentage.

C TONER	Displays the remaining amount of toner in the cyan (C) toner cartridge as a percentage.
M TONER	Displays the remaining amount of toner in the magenta (M) toner cartridge as a percentage.
Y TONER	Displays the remaining amount of toner in the yellow (Y) toner cartridge as a percentage.
K TONER	Displays the remaining amount of toner in the black (K) toner cartridge as a percentage.
C I-UNIT	Displays the remaining service life of the cyan (C) imaging unit as a percentage.
M I-UNIT	Displays the remaining service life of the magenta (M) imaging unit as a percentage.
Y I-UNIT	Displays the remaining service life of the yellow (Y) imaging unit as a percentage.
K I-UNIT	Displays the remaining service life of the black (K) imaging unit as a percentage.

## TX/RX RESULT

The results of a maximum of 60 fax transmissions/receptions can be viewed. In addition, the transmission/reception results that are displayed can be printed by pressing the **Start-B&W** key. For details, refer to the Facsimile User's Guide on the Documentation CD/DVD.

## REPORT

The machine settings, lists and reports related to fax can be printed.

TX RESULT REPORT	Prints the results of fax transmissions. For details, refer to the Facsimile User's Guide on the Documentation CD/DVD.
RX RESULT REPORT	Prints the results of fax receptions. For details, refer to the Facsimile User's Guide on the Documentation CD/DVD.
ACTIVITY REPORT	Prints the results of fax transmissions and receptions. For details, refer to the Facsimile User's Guide on the Documentation CD/DVD.
MEMORY DATA LIST	Prints the information for queued fax transmissions. For details, refer to the Facsimile User's Guide on the Documentation CD/DVD.
MEMORY IMAGE PRINT	Prints the information and a reduced first page of queued fax transmissions. For details, refer to the Facsimile User's Guide on the Documentation CD/DVD.
FAVORITE LIST	Prints a list of the destinations registered in the favorite list. For details, refer to the Facsimile User's Guide on the Documentation CD/DVD.
SPEED DIAL LIST	Prints a list of the destinations programmed for speed dialing. For details, refer to the Facsimile User's Guide on the Documentation CD/DVD.
GROUP DIAL LIST	Prints a list of the one-touch dialing groups. For details, refer to the Facsimile User's Guide on the Documentation CD/DVD.
UTILITY MAP	Prints the configuration menu and its settings.
CONFIGURATION PAGE	Prints a rough estimate of the percentage of toner remaining and the settings, information and status of this machine.
DEMO PAGE	Prints a demo page.

# Configuration Menu Overview

To display the settings menu for this machine, select **UTILITY** in the main screen, and then press the **Select** key. From the **UTILITY** menu, settings for the various machine functions can be changed.

## UTILITY Menu


From this menu, various machine settings can be changed. The **UTILITY** menu is structured as shown below.




To return to the previous screen in the **UTILITY** menu, press the **Back** key. (If the **Back** key is pressed while settings are being specified, those settings are not saved.)





The **ADMIN. MANAGEMENT** menu is accessible only by the administrator. To display the settings for this menu, select **ADMIN. MANAGEMENT**; use the keypad to type in the 6-digit administrator access code, and then press the **Select** key.





# MACHINE SETTING Menu





*Manufacturer's default settings appear in bold.*


AUTO PANEL RESET	Setting	OFF / 30sec / <b>1min</b> / 2min / 3min / 4min / 5min
	<p>Select whether or not all settings in the control panel return to their default settings when no operation is performed for a set length of time.</p> <p>To set the machine to perform the auto panel reset operation, select from 30sec, 1min, 2min, 3min, 4min or 5min for the length of time until the auto panel reset operation is performed.</p> <p>If OFF is selected, the auto panel reset operation is not performed.</p>	
PREHEAT MODE	Setting	1 to 120 sec (Default: 15 sec)
	<p>Enters Preheat mode (first stage of the energy save mode) in order to conserve energy when no operation is performed. Specify the length of time in minutes until the machine enters Preheat mode.</p>	
ENERGY SAVE MODE	Setting	6 to 120 sec (Default: 30 sec)
	<p>Enters Energy Save mode in order to conserve energy when no operation is performed. Specify the length of time in minutes until the machine enters Energy Save mode.</p>	
LCD CONTRAST	Setting	(LIGHT)  (DARK)
	<p>Specify the brightness of the message window.</p>	

KEY SPEED	TIME TO START	Setting	0.1sec / 0.3sec / 0.5sec / <b>1.0sec</b> / 1.5sec / 2.0sec / 2.5sec / 3.0sec
		Specify the length of time until the cursor begins to move continuously when a key is held down.	
	INTERVAL	Setting	<b>0.1sec</b> / 0.3sec / 0.5sec / 1.0sec / 1.5sec / 2.0sec / 2.5sec / 3.0sec
		Specify the length of time until the cursor continuously moves between settings or characters.	
LANGUAGE		Setting	<b>ENGLISH</b> / FRENCH / GERMAN / ITALIAN / SPANISH / PORTUGUESE / RUSSIAN / CZECH / SLOVAK / HUNGARIAN / POLISH / JAPANESE
		Select the language of the menus and messages that appear in the message window.	
LAMP OFF TIME		Setting	<b>MODE1</b> / MODE2
		<p>Select the length of time until the scanner unit lamp goes off when no operation is performed.</p> <p>If MODE1 is selected, the lamp goes off when the machine enters Preheat mode.</p> <p>If MODE2 is selected, the lamp goes off when the machine enters Energy Save mode.</p>	

LAMP WARMUP TIME	Setting	AUTO / <b>FIX</b>
	<p>Specify the warm-up time for the lamp of the scanner unit.</p> <p>If AUTO is selected, the length of time to recover from Energy Save mode when the machine is turned on is adjusted according to the room temperature. Since the machine cannot be used until its condition is completely stabilized, select this setting, for example, if you wish to scan at a high image quality from the first page.</p> <p>If FIX is selected, the machine can be used after lamp warm-up is finished. With a low room temperature, the quality of the first page of a copy or scanned image may not be as good as if AUTO was selected.</p>	
BUZZER VOLUME	Setting	OFF / <b>LOW</b> / HIGH
	<p>Select the volume of the sound produced when a key is pressed and of the alarm that is sounded when an error occurs.</p>	
INITIAL MODE	Setting	<b>COPY</b> / FAX
	<p>Specify the default mode when the machine is turned on or when all settings in the control panel return to their default settings.</p>	
TONER EMPTY	Setting	<b>STOP</b> / BW CONTINUE
	<p>Select whether or not printing, copying and faxing stop when the toner has run out.</p> <p>If STOP is selected, printing, copying and faxing stop when the toner runs out.</p> <p>If BW CONTINUE is selected, printing, BW copying and faxing do not stop when the toner runs out.</p>	
TONER NEAR EMPTY	Setting	<b>ON</b> / OFF
	<p>When the toner is nearly run out, a warning message appears.</p>	
AUTO CONTINUE	Setting	ON / <b>OFF</b>
	<p>Select whether or not printing continues when a size error occurs during printing.</p>	

CALIBRATION	Setting	ON / <b>OFF</b>
	Select whether or not to perform image stabilization. If ON is selected, image stabilization is started.	

# PAPER SETUP Menu





Manufacturer's default settings appear in bold.


TRAY1 PAPER	Media type	<b>PLAIN PAPER</b> / THICK PAPER / THICK PAPER2 / TRANSPARENCY / LABELS / LETTERHEAD / GLOSSY / GLOSSY2 / ENVELOPE / POSTCARD
	Paper size	<p>When a setting other than ENVELOPE or POSTCARD is selected: <b>A4</b> / A5 / B5 / LEGAL / <b>LETTER</b> / G LETTER / STATEMENT / EXECUTIVE / FOLIO / G LEGAL / OFICIO (Mexico only) / CUSTOM</p> <p>When ENVELOPE is selected: <b>COM10</b> / C6 / DL / MONARCH / CHOU#3 / CUSTOM</p> <p>When POSTCARD is selected: <b>J-POSTCARD 100x148</b> / D-POSTCARD 148x200 / CUSTOM</p>
	<p>Select the type and size of the media loaded into Tray 1. If CUSTOM is selected as the paper size, specify settings for LENGTH and WIDTH separately.</p> <p>The Setting range for LENGTH is 5 . 83 to 14 . 00 inches (148 to 356 mm).</p> <p>The default setting is 11 . 00 inches (279 mm) for USA and Canada, and 11 . 69 inches (297 mm) for other countries.</p> <p>The Setting range for WIDTH is 3 . 63 to 8 . 50 inches (92 to 216 mm).</p> <p>The default setting is 8 . 50 inches (216 mm) for USA and Canada, and 8 . 26 inches (210 mm) for other countries.</p> <p>When a media type is selected, a screen appears, showing the available media sizes. The available media sizes differ depending on the selected media type.</p> <p>The default paper size for a setting other than ENVELOPE or POSTCARD is <b>LETTER</b> for 120 V models, and <b>A4</b> for 220 V models.</p>	


TRAY2 PAPER	Paper size	<b>A4</b> / A5 / B5 / <b>LETTER</b> / G LETTER / STATEMENT / EXECUTIVE / CUSTOM
	<p>Select the size of the media loaded into Tray 2. If CUSTOM is selected as the paper size, specify settings for LENGTH and WIDTH separately.</p> <p>The Setting range for LENGTH is 5 . 83 to 11 . 69 inches (148 to 297 mm).</p> <p>The default setting is 11 . 00 inches (279 mm) for USA and Canada, and 11 . 69 inches (297 mm) for other countries.</p> <p>The Setting range for WIDTH is 3 . 63 to 8 . 50 inches (92 to 216 mm).</p> <p>The default setting is 8 . 50 inches (216 mm) for USA and Canada, and 8 . 26 inches (210 mm) for other countries.</p> <p>Only plain paper can be loaded into Tray 2.</p> <p>The default paper size is LETTER for 120 V models, and A4 for 220 V models.</p>	


## ADMIN. MANAGEMENT Menu





The ADMIN. MANAGEMENT menu is accessible only by the administrator. To display the settings for this menu, select ADMIN. MANAGEMENT; use the keypad to type in the 6-digit administrator access code (default: 000000), and then press the **Select** key.













<sup>\*1</sup> *This menu item appears when ADMIN. MANAGEMENT/NET-WORK SETTING/TCP/IP is set to ENABLE.*

<sup>\*2</sup> *This menu item appears when ADMIN. MANAGEMENT/NET-WORK SETTING/POP BEFORE SMTP/DISABLE/ENABLE is set to ENABLE.*

<sup>\*3</sup> *This menu item appears when ADMIN. MANAGEMENT/NET-WORK SETTING/SMTP AUTH./DISABLE/ENABLE is set to ENABLE.*

<sup>\*4</sup> *This menu item appears when ADMIN. MANAGEMENT/NET-WORK SETTING/ LDAP SETTING /DISABLE/ENABLE is set to ENABLE.*



Manufacturer's default settings appear in bold.

ADMINISTRATOR NO.		Specify the new administrator access code.	
REMOTE MONITOR		Setting	<b>OFF</b> / ON
		<p>Select whether or not setting remote monitor.</p> <p>If ON is selected, technical support can access the menu mode.</p> <p>If OFF is selected, technical support cannot access the menu mode.</p> <p> <i>This setting is for technical support uses. Change the setting only when it is necessary.</i></p>	
NETWORK SETTING	TCP/IP	Setting	DISABLE / <b>ENABLE</b>
	<p>Select the setting for connecting to this machine through a network.</p>		
IP ADDR. SETTING	IP ADDR. SETTING	Setting	<b>AUTO</b> / SPECIFY
		<p>Set the IP address of this printer on the network.</p> <p>If AUTO is selected, the IP address will be assigned automatically.</p> <p>If SPECIFY is selected, manually specify settings for IP ADDRESS, SUB-NET MASK and GATEWAY.</p>	

DNS CONFIG.	Setting	<b>DISABLE</b> / ENABLE
	Set whether or not the DNS server setting is to be specified.  If <b>ENABLE</b> is selected, specify DNS server addresses (up to three addresses).	
DHCP	Setting	DISABLE / <b>ENABLE</b>
	If there is a DHCP server on the network, specify whether the IP address and other network information is automatically assigned by the DHCP server.	
BOOTP	Setting	<b>DISABLE</b> / ENABLE
	If there is a BOOTP server on the network, specify whether the IP address and other network information is automatically assigned by the BOOTP server.	
ARP/PING	Setting	<b>DISABLE</b> / ENABLE
	Select whether or not the ARP/PING command is used when the IP address is assigned.	
HTTP	Setting	DISABLE / <b>ENABLE</b>
	Select whether or not to enable HTTP.	
FTP	Setting	DISABLE / <b>ENABLE</b>
	Select whether or not to enable FTP.	
SMB	Setting	DISABLE / <b>ENABLE</b>
	Select whether or not to enable SMB.	
BONJOUR	Setting	DISABLE / <b>ENABLE</b>
	Select whether or not to enable Bonjour.	
IPP	Setting	DISABLE / <b>ENABLE</b>
	Select whether or not to enable IPP.   <i>If HTTP is set to DISABLE, NOT AVAILABLE appears.</i>	
SLP	Setting	DISABLE / <b>ENABLE</b>
	Select whether or not to enable SLP.	

	SNMP	Setting	DISABLE / <b>ENABLE</b>
		Select whether or not to enable SNMP.	
	SPEED/DUPLEX	Setting	<b>AUTO</b> / 10BASE-T FULL / 10BASE-T HALF / 100BASE-TX FULL / 100BASE-TX HALF
		Specifies the transmission speed for the network and the transmission method for bi-directional transmission.	
E-MAIL SETTING	SMTP	Setting	DISABLE / <b>ENABLE</b>
		Select whether to enable or disable e-mail transmission operations for this machine.	
	SENDER NAME	Specify the name of the E-mail sender (up to 20 characters) used for network scanning.  The default setting is "magicolor 4690MF".	
	E-MAIL ADDRESS	Specify the E-mail address (up to 64 characters) of the E-mail sender used for network scanning.	
	DEFAULT SUBJECT	Specify the subject (up to 20 characters) of the E-mail message used for network scanning.  The default setting is "from mc 4690MF".	
	SMTP SERVER ADDR.	Specify the IP address or host name (up to 64 characters) for the SMTP server. The default setting is "0.0.0.0".	
	SMTP PORT NO.	Setting	1 to 65535 (Default: 25)
		Specify the port number communicating with the SMTP server.	
SMTP TIMEOUT	Setting	30 to 300 sec (Default: 60 sec)	
	Select the amount of time (in seconds) until the connection with the SMTP server times out.		

TEXT INSERT		Setting	<b>OFF</b> / ON
		Select whether or not the previously specified text is inserted into the body of the E-mail message when using network scanning.	
POP BEFORE SMTP	DIS-ABLE/ ENABLE	Setting	<b>DISABLE</b> / ENABLE
	Select whether or not to enable POP Before SMTP.		
	POP3 SERVER ADDR .	Specify the host name or IP address for the POP3 server used for authentication with POP Before SMTP.  The default setting is "0.0.0.0".	
	POP3 PORT NO .	Setting	1 to 65535 (Default: 110)
	Specify the port number used for communicating with the POP3 server.		
	POP3 TIME-OUT	Setting	30 to 300 sec (Default: 30 sec)
	Select the amount of time (in seconds) until the connection with the POP3 server times out.		
POP3 ACCOUNT	Specify the user name (up to 63 characters) used for authentication with POP3 server.		
POP3 PASS-WORD	Specify the password (up to 15 characters) used for authentication with POP3 server.		
SMTP AUTH .	DIS-ABLE/ ENABLE	Setting	<b>DISABLE</b> / ENABLE
	Select whether or not to enable SMTP authentication.		
	SMTP USER-NAME	Specify the user name (up to 63 characters) used for SMTP authentication.	
SMTP PASS-WORD	Specify the password (up to 15 characters) used for SMTP authentication.		


LDAP SETTING	DISABLE/ENABLE	Setting	DISABLE / <b>ENABLE</b>
		Select whether or not to enable the LDAP function.	
	LDAP SERVER ADDR.	Specify the address (up to 64 characters) of the LDAP server.  The default setting is "0.0.0.0".	
	LDAP PORT NO.	Setting	1 to 65535 (Default: 389)
		Specify the port number of the LDAP server.	
	SSL SETTING	Setting	<b>DISABLE</b> / ENABLE
		Select whether or not to enable SSL.	
	SEARCH BASE	Specify the search starting point (up to 64 characters) in a hierarchical structure arranged on the LDAP server.	
	ATTRIBUTE	The conditions for searches can be specified as a name or e-mail address (up to 32 characters).  The default setting is "cn".	
	SEARCH METHOD	Setting	BEGIN / <b>CONTAIN</b> / END
		The specified characters can be searched for at the beginning, within or at the end.	
	LDAP TIMEOUT	Setting	5 to 300 sec (Default: 60 sec)
		Specify the maximum wait time during a search.	
	MAX. SEARCH RESULTS	Setting	5 to 100 (Default: 100)
	Specify the maximum number of destinations displayed after a search.		
AUTHENTICATION	Setting	<b>ANONYMOUS</b> / SIMPLE / DIGEST-MD5 / GSS-SPNEGO	
	Select the authentication method used for logging on to the LDAP server.		
LDAP ACCOUNT	Specify the account (up to 64 characters) used to connect to the LDAP server.		

	LDAP PASSWORD	Specify the password (up to 32 characters) used to connect to the LDAP server.	
	DOMAIN NAME	Specify the domain name (up to 64 characters) used to connect to the LDAP server.	
USB SETTING		Setting	<b>Windows</b> / Mac
		Select the operating system of the PC to which this machine is connected with a USB cable.	
COMM . SETTING	TONE/PULSE	Setting	<b>TONE</b> / PULSE
		<p>Select the dialing system. If this parameter is not correctly set to the type of dialing system used, faxes cannot be sent and received.</p> <p>Select the correct setting after checking which type of dialing system is used by your telephone line.</p> <p> <i>If PTT SETTING in the USER SETTING menu is set to U . S . A, CANADA or NEW ZEALAND, the settings cannot be changed.</i></p>	
	LINE MONITOR	Setting	OFF / <b>LOW</b> / HIGH
		Select the volume of the monitoring sound of the transmission signal.	
	PSTN/PBX	Setting	<b>PSTN</b> / PBX
		<p>Select whether the connected telephone wiring is a public switched telephone network (PSTN) or a private branch exchange (PBX).</p> <p>For a PBX system, the prefix number (outside line access number or extension number) can be specified.</p>	

USER SETTING	PTT SETTING	Setting	ARGENTINA / AUSTRALIA / AUSTRIA / BELGIUM / BRAZIL / CANADA / CHINA / CZECH / DENMARK / EUROPE / FINLAND / FRANCE / GERMANY / GREECE / HONG KONG / HUNGARY / IRELAND / ISRAEL / ITALY / JAPAN / KOREA / MALAYSIA / MEXICO / THE NETHERLANDS / NEW ZEALAND / NORWAY / PHILIPPINES / POLAND / PORTUGAL / RUSSIA / SAUDI ARABIA / SINGAPORE / SLOVAKIA / SOUTH AFRICA / SPAIN / SWEDEN / SWITZERLAND / TAIWAN / TURKEY / U.S.A / UNITED KINGDOM / VIETNAM
		Select the country where this machine is installed.	
	DATE&TIME	Setting	TIME: 00:00-23:59 DATE: 00/01/01-99/12/31 ZONE: GMT+12:00-GMT-12:00 (in 30-minute intervals)
		Use the keypad to specify the current date, time and time zone.	
DATE FORMAT	Setting	<b>MM/DD/YY</b> / DD/MM/YY / YY/MM/DD	
	Select the display format for reports and lists.		

	PRESET ZOOM	Setting	<b>INCH / METRIC</b>
		<p>Select the measurement units for the preset zoom ratios.</p> <p>The default setting is <b>INCH</b> for USA and Canada, and <b>METRIC</b> for other countries.</p>	
	USER FAX NUMBER	<p>Enter your fax number. A maximum of 20 characters (consisting of numbers, spaces, + and -) can be entered. The specified number is printed in the header of outgoing faxes.</p>	
	USER NAME	<p>Enter your name. A maximum of 32 characters can be entered. The specified name is printed in the header of outgoing faxes.</p>	
AUTO REDIAL	NUMBER OF REDIAL	Setting	1 to 10 (Default: depends on PTT SETTING)
		<p>Specify the number of times a redial is attempted if there is no answer, for example, when the line is busy.</p>	
	INTERVAL	Setting	1 to 99 min (Default: depends on PTT SETTING)
		<p>Specify the interval between redial attempts.</p>	
SUPPLIES REPLACE	TRANSFER BELT	<p>Replace the counter when the transfer belt unit is replaced with new one.</p>	
	FUSER UNIT	<p>Replace the counter when the fuser unit is replaced with new one.</p>	
	TRANSFER ROLLER	<p>Replace the counter when the transfer roller is replaced with new one.</p>	

## COPY SETTING Menu




Manufacturer's default settings appear in bold.

PAPER PRIORITY	Setting	TRAY1 / <b>TRAY2</b> / TRAY3
	Specify the paper tray that is normally used.	
	 If an optional lower feeder unit is not installed, TRAY3 does not appear.	
QUALITY PRIORITY	Setting	<b>MIX</b> / TEXT / PHOTO / FINE / MIX / FINE / TEXT / FINE / PHOTO
	Select the type of document being copied.  If TEXT or FINE / TEXT is selected, select either AUTO ON or AUTO OFF for the copy density.	


DENSITY PRIORITY		Setting	<b>AUTO</b> / MANUAL
		Select the density that is normally used.	
DENSITY LEVEL	AUTO	Setting	(LIGHT)  (DARK)
		Adjust the density of the background color.	
	MANUAL	Setting	(LIGHT)  (DARK)
		Specify the default copy density.	
OUTPUT PRIORITY		Setting	<b>NON-SORT</b> / SORT
		Select whether or not to sort copies by sets.	
4 IN1 COPY ORDER		Setting	<b>SIDEWISE</b> / DOWNWARD
		Select the arrangement of scanned documents with 4in1 copying.	
DUPLEX COPY		Setting	<b>OFF</b> / LONG EDGE / SHORT EDGE
		Select the default setting for duplex (double-sided) copying.	
		If <b>OFF</b> is selected, duplex (double-sided) copying is not performed as a default.	
		If <b>LONG EDGE</b> is selected, duplex (double-sided) copying is performed as a default, and the pages are fed out with the binding along the long side.	
		If <b>SHORT EDGE</b> is selected, duplex (double-sided) copying is performed as a default, and the pages are fed out with the binding along the short side.	

## DIAL REGISTER Menu



FAVORITE	Register speed dial destinations and group dial destinations in the favorite list. In addition, registered data can be deleted.
SPEED DIAL	Register e-mail addresses as speed dial destinations. In addition, registered e-mail addresses can be edited or deleted.
GROUP DIAL	Register speed dial destinations as group dial destinations. In addition, registered group dial destinations can be edited or deleted.

## FAX TX OPERATION Menu.




*Manufacturer's default settings appear in bold.*

DENSITY LEVEL	Setting	(LIGHT) <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> (DARK)
	Specify the density for scanning a document.	
QUALITY PRIORITY	Setting	<b>STD/TEXT</b> / FINE/TEXT / S-FINE/TEXT / STD/PHOTO / FINE/PHOTO / S-FINE/PHOTO
	<p>Select the default scanning resolution (fax document quality).</p> <p>STD/TEXT: Select this setting for documents containing handwriting or for computer printouts.</p> <p>FINE/TEXT: Select this setting for documents containing small print.</p> <p>S-FINE/TEXT: Select this setting for documents containing small print, such as newspapers, and documents containing detailed illustrations.</p> <p>STD/PHOTO: Select this setting for photo documents containing regular photos.</p> <p>FINE/PHOTO: Select this setting for photo documents containing fine images.</p> <p>S-FINE/PHOTO: Select this setting for photo documents containing finer images.</p>	

DEFAULT TX	Setting	<b>MEMORY TX / DIRECT TX</b>
HEADER	Setting	OFF / <b>ON</b>
	<p>Select the desired method for sending documents.</p> <p><b>MEMORY TX:</b> With this method, the fax transmission starts after the entire document is scanned and stored in the memory. The total number of pages is automatically printed with the page number in the header. However, the memory may become full if there are many pages in the document or if the data is large due to the fine image quality (resolution).</p> <p><b>DIRECT TX:</b> With this method, the transmission is performed in real time in the transmission sequence of the destinations. If there are many pages in the document, the fax can be sent with this method without the memory becoming full.</p>	
	<p>Select whether or not to print transmission source information (date/time of transmission, sender's name, sender's fax number, session number and page number) for the machine in the transmitted document.</p> <p> <i>If PTT SETTING in the USER SETTING menu is set to U. S . A, CANADA, or KOREA, this setting cannot be changed.</i></p>	

## FAX RX OPERATION Menu.




*Manufacturer's default settings appear in bold.*

MEMORY RX MODE	Setting	<b>OFF</b> / ON
	<p>Select whether to allow (ON) memory reception or not (OFF). In cases when confidential faxes are being received, the received documents can be stored in memory and printed at a specified time or when memory reception is turned off (this function is set to OFF).</p> <p>A password can be set to specify the starting time or ending time of memory reception, or to cancel the function. The set starting time and ending time are valid every day until memory reception is turned off.</p>	

No. of RINGS	Setting	1 to 16 (Default: depends on PTT SETTING)
	Enter the number of rings (between 1 and 16) until the machine automatically begins receiving the fax when an external telephone is connected.	
REDUCTION RX	Setting	OFF / ON / CUT
	<p>Select whether documents longer than the current paper size are printed reduced, split, or discarded.</p> <p>ON: The document is printed at a reduced size.</p> <p>OFF: The document is printed at full size and split onto multiple pages.</p> <p>CUT: The document is printed, but any part that does not fit within the page is erased.</p>	
RX PRINT	Setting	MEMORY RX / PRINT RX
	<p>Select whether the fax is printed only after all document pages have been received or printing begins as soon as the first page of the document is received.</p> <p>MEMORY RX: Printing begins after all pages have been received.</p> <p>PRINT RX: Printing begins after the first page has been received.</p>	
RX MODE	Setting	AUTO RX / MANUAL RX
	<p>Select whether the reception mode is set to automatic reception or manual reception.</p> <p>AUTO RX: Automatically begins receiving the fax after the set number of rings.</p> <p>MANUAL RX: Does not automatically receive the fax. Reception begins after making a connection by picking up the telephone receiver or pressing the <b>Onhook</b> key, then pressing the <b>Start</b> key.</p>	

FORWARD	Setting	<b>OFF / ON / ON (PRINT)</b>
	<p>Select whether or not to forward received fax documents.</p> <p>OFF: Select this setting to not forward the document.</p> <p>ON: Select this setting to forward the received fax document to the specified fax number or e-mail address.</p> <p>ON (PRINT) : Select this setting to forward the received fax document to the specified fax number or e-mail address at the same time that the machine prints it.</p>	
FOOTER	Setting	<b>OFF / ON</b>
	<p>Select whether or not the reception information (date received, number of pages, etc.) is printed at the bottom of each received document.</p>	
SELECT TRAY	Setting	<b>TRAY1 : DISABLE / ENABLE</b> <b>TRAY2 : DISABLE / ENABLE</b> <b>TRAY3 : DISABLE / ENABLE</b>
	<p>Select which paper tray can be used to supply paper when printing received documents or transmission reports. A paper tray that cannot be used for supplying paper can also be specified.</p> <p> <i>If an optional lower feeder unit is not installed, TRAY3 does not appear.</i></p>	

## REPORTING Menu.




Manufacturer's default settings appear in bold.

ACTIVITY REPORT	Setting	OFF / <b>ON</b>
	After every 60 transmissions/receptions, a report can be printed to show the results of the transmissions/receptions. Select whether the report is printed automatically when the 60th transmission/reception is reached.	
TX RESULT REPORT	Setting	ON / <b>ON (ERROR)</b> / OFF
	<p>Select whether the report showing the result of a transmission is printed automatically after the transmission is finished.</p> <p>ON: Prints the report after each transmission.</p> <p>ON (ERROR) : Prints the report after a transmission only if an error occurred.</p> <p>OFF: Does not print the report after each transmission, even if an error has occurred.</p> <p>The transmission result report is normally printed after a broadcast transmission.</p>	

RX RESULT REPORT	Setting	ON / <b>ON (ERROR)</b> / OFF
	<p>Select whether the report showing the result of a reception is printed automatically after the reception is finished.</p> <p>ON: Prints the report after each reception.</p> <p>ON (ERROR) : Prints the report after a reception only if an error occurred.</p> <p>OFF: Does not print the report after each reception, even if an error has occurred.</p>	

## SCAN SETTING Menu





Manufacturer's default settings appear in bold.

RESOLUTION	Setting	<b>150×150</b> / 300×300 / 600×600
	<p>Select the default scanning resolution for scan to E-mail operations.</p> <p> <i>When using the ADF to scan in color or grayscale, 300×300 is automatically selected, even if the resolution was set to 600×600.</i></p>	
IMAGE FORMAT	Setting	TIFF / <b>PDF</b> / JPEG
	<p>Select the default format for saving files with scan to E-mail operations.</p> <p> <i>PDF data can be opened in Adobe Acrobat Reader.</i></p> <p> <i>TIFF files of images that have been scanned with the Color or Gray setting cannot be opened with the Windows Picture and FAX Viewer, which is included with Windows XP as a standard component. These files can be opened with image-processing applications such as PhotoShop, Microsoft Office Document Imaging or ACDsee.</i></p>	
CODING METHOD	Setting	<b>MH</b> / MR / MMR
	<p>Select the default compression method for scan to E-mail operations.</p> <p>The compression ratio for these methods increases in the following order: MH &gt; MR &gt; MMR.</p> <p> <i>These settings are available only if B&amp;W was selected for the color setting during the e-mail transmission.</i></p>	
FILE SIZE	Setting	<b>NO SPLIT</b> / SPLIT
	<p>Select whether or not to limit the size for scan data sent as e-mail attachments.</p> <p>If SPLIT is selected, specify the maximum size between 1 and 10 Mb.</p>	
QUALITY PRIORITY	Setting	<b>MIX</b> / TEXT / PHOTO
	<p>Select the scan data quality that is used as a default.</p>	

DENSITY LEVEL	Setting	(LIGHT)  (DARK)
	Select the scan data density that is used as a default.	



---

***Media Handling***

---

**3**

# Print Media

## Specifications

Media	Media Size		Tray*	Duplex	Copy	Print	FAX
	Inch	Millimeter					
A4	8.2 x 11.7	210.0 x 297.0	1/2/3	Yes	Yes	Yes	Yes
B5 (JIS)	7.2 x 10.1	182.0 x 257.0	1/2/3	Yes	Yes	Yes	No
A5	5.9 x 8.3	148.0 x 210.0	1/2	No	Yes	Yes	No
Legal	8.5 x 14.0	215.9 x 355.6	1/3	Yes	Yes	Yes	Yes
Letter	8.5 x 11.0	215.9 x 279.4	1/2/3	Yes	Yes	Yes	Yes
Statement	5.5 x 8.5	139.7 x 215.9	1/2	No	Yes	Yes	No
Executive	7.25 x 10.5	184.2 x 266.7	1/2/3	Yes	Yes	Yes	No
Folio	8.25 x 13.0	210.0 x 330.0	1	Yes	Yes	Yes	No
Letter Plus	8.5 x 12.69	215.9 x 322.3	1	Yes	No	Yes	No
UK Quarto	8.0 x 10.0	203.2 x 254.0	1/2	No	No	Yes	No
Foolscap	8.0 x 13.0	203.2 x 330.2	1	Yes	No	Yes	No
Government Legal	8.5 x 13.0	215.9 x 330.2	1/3	Yes	Yes	Yes	No
Kai 16	7.3 x 10.2	185.0 x 260.0	1/2	Yes	No	Yes	No
Kai 32	5.1 x 7.3	130.0 x 185.0	1/2	No	No	Yes	No
Government letter	8.0 x 10.5	203.2 x 266.7	1/2	Yes	Yes	Yes	No
16 K	7.7 x 10.6	195.0 x 270.0	1/2	Yes	No	Yes	No
Oficio**	8.5 x 13.5	215.9 x 342.9	1	Yes	Yes	Yes	Yes
Photo size 4x6"	4.0 x 6.0	101.6 x 152.4	1/2	No	No	Yes	No
Photo size 10x15	3.9 x 5.9	100.0 x 150.0	1/2	No	No	Yes	No
J-Postcard	3.9 x 5.8	100.0 x 148.0	1	No	Yes	Yes	No
Double Postcard	5.8 x 7.9	148.0 x 200.0	1	No	Yes	Yes	No
B5 (ISO)	6.9 x 9.8	176.0 x 250.0	1	Yes	No	No	No
Envelope Com10	4.125 x 9.5	104.8 x 241.3	1	No	Yes	Yes	No
Envelope DL	8.7 x 4.3	220.0 x 110.0	1	No	Yes	Yes	No
Envelope Monarch	7.5 x 3.875	190.5 x 98.4	1	No	Yes	Yes	No
Envelope C6	6.4 x 4.5	162.0 x 114.0	1	No	Yes	Yes	No
Envelope Chou #3	4.7 x 9.2	120.0 x 235.0	1	No	Yes	Yes	No
Envelope You #6	7.5 x 3.875	190.5 x 98.4	1	Yes	No	No	No
Custom, Minimum	3.6 x 5.9	92.0 x 148.0	1/2	Yes	Yes	Yes	No
Custom, Maximum	8.5 x 14.0	216.0 x 356.0	1/2***	Yes	Yes	Yes	No
Thick Stock—Only supported for letter, A4, and smaller media.							
<b>Notes:</b> *Tray 1 = Multipurpose Tray 2/3 = Plain paper only **Oficio = Mexico only ***Tray 2 = 216.0 x 297.0							

## Types

Before purchasing a large quantity of special media, do a trial print with the same media and check the print quality.

Keep media on a flat, level surface in its original wrapper until it is time to load it. For a list of approved media, refer to <http://printer.konicaminolta.com>.

### Plain Paper (Recycled Paper)

<b>Capacity</b>	<b>Tray 1</b>	Up to 100 sheets, depending on the media weight
	<b>Tray 2</b>	Up to 250 sheets, depending on the media weight
	<b>Tray 3</b>	Up to 500 sheets, depending on the media weight
<b>Orientation</b>	<b>Tray 1</b>	Face down
	<b>Tray 2/3</b>	Face up
<b>Driver Media Type</b>	Plain Paper (Recycled)	
<b>Weight</b>	60 to 90 g/m <sup>2</sup> (16 to 24 lb bond)	
<b>Duplexing</b>	Supported	

#### Use plain paper that is

- Suitable for plain paper printers and copiers, such as standard or recycled office paper.

#### Note

---

---

**Do not use the media types listed below. These could cause poor print quality, media misfeeds, or damage to the machine.**

---

---

#### DO NOT use media that is

- Coated with a processed surface (such as carbon paper and colored paper that has been treated)
- Carbon backed
- Unapproved iron-on transfer media (such as heat-sensitive paper, heat-pressure paper, and heat-press transfer paper)
- Cold-water-transfer paper
- Pressure sensitive

- Designed specifically for inkjet printers (such as superfine paper, glossy film, and postcards)
- Already been printed on by another printer, copier, or fax machine
- Dusty
- Wet (or damp)



*Keep media between 15% and 85% relative humidity. Toner does not adhere well to moist or wet media.*

- Layered
- Adhesive
- Folded, creased, curled, embossed, warped, or wrinkled
- Perforated, three-hole punched, or torn
- Too slick, too coarse, or too textured
- Different in texture (roughness) on the front and back
- Too thin or too thick
- Stuck together with static electricity
- Composed of foil or gilt; too luminous
- Heat sensitive or cannot withstand the fusing temperature (180°C [356°F])
- Irregularly shaped (not rectangular or not cut at right angles)
- Attached with glue, tape, paper clips, staples, ribbons, hooks, or buttons
- Acidic
- Any other media that is not approved

## Thick Stock

Paper thicker than 90 g/m<sup>2</sup> (24 lb bond) is referred to as thick stock. Test all thick stock to ensure acceptable performance and to ensure that the image does not shift.

You can print continuously with thick stock. However, this could affect the media feed, depending on the media quality and printing environment. If problems occur, stop the continuous printing and print one sheet at a time.

<b>Capacity</b>	<b>Tray 1</b>	Up to 20 sheets, depending on their thickness
	<b>Tray 2/3</b>	Not supported
<b>Orientation</b>	Face down	

<b>Driver Media Type</b>	Thick Stock 1
	Thick Stock 2
<b>Weight</b>	91 to 210 g/m <sup>2</sup> (25 to 55.9 lb bond)
<b>Duplexing</b>	Not supported

**DO NOT use thick stock that is**

- Mixed with any other media in the trays (as this will cause media misfeeding)

**Envelope**

Print on the front (address) side only. Some parts of the envelope consist of three layers of paper—the front, back, and flap. Anything printed in these layered regions may be lost or faded.

You can print continuously with envelope. However, this could affect the media feed, depending on the media quality and printing environment. If problems occur, stop the continuous printing and print one sheet at a time.

<b>Capacity</b>	<b>Tray 1</b>	Up to 10 sheets, depending on their thickness
	<b>Tray 2/3</b>	Not supported
<b>Orientation</b>	Face down	
<b>Driver Media Type</b>	Envelope	
<b>Weight</b>	91 to 163 g/m <sup>2</sup> (25 to 43 lb bond)	
<b>Duplexing</b>	Not supported	

**Use envelopes that are**

- Common office envelopes approved for laser printing with diagonal joints, sharp folds and edges, and ordinary gummed flaps



*Because the envelopes pass through heated rollers, the gummed area on the flaps may seal. Using envelopes with emulsion-based glue avoids this problem.*

- Approved for laser printing
- Dry

## DO NOT use envelopes that have

- Sticky flaps
- Tape seals, metal clasps, paper clips, fasteners, or peel-off strips for sealing
- Transparent windows
- Too rough of a surface
- Material that will melt, vaporize, offset, discolor, or emit dangerous fumes
- Been presealed

## Label

A sheet of labels consists of a face sheet (the printing surface), adhesive, and a carrier sheet:

- The face sheet must follow the plain paper specification.
- The face sheet surface must cover the entire carrier sheet, and no adhesive should come through on the surface.

You can print continuously with label sheets. However, this could affect the media feed, depending on the media quality and printing environment. If problems occur, stop the continuous printing and print one sheet at a time.

Try printing your data on a sheet of plain paper first to check placement. Check your application documentation for more information on printing labels.

<b>Capacity</b>	<b>Tray 1</b>	Up to 20 sheets, depending on their thickness
	<b>Tray 2/3</b>	Not supported
<b>Orientation</b>	Face down	
<b>Driver Media Type</b>	Labels	
<b>Weight</b>	60 to 163 g/m <sup>2</sup> (16 to 43 lb bond)	
<b>Duplexing</b>	Not supported	

## Use label sheets that are

- Recommended for laser printing

## DO NOT use label sheets that




- Have labels that easily peel off or have parts of the label already removed
- Have backing sheets that have peeled away or have exposed adhesive



Labels may stick to the fuser, causing them to peel off and media misfeeds to occur.


- Are precut or perforated

Do not use



Shiny backed paper

OK to use



Full-page labels (uncut)

## Letterhead

You can print continuously with letterhead. However, this could affect the media feed, depending on the media quality and printing environment. If problems occur, stop the continuous printing and print one sheet at a time.

Try printing your data on a sheet of plain paper first to check placement.

<b>Capacity</b>	<b>Tray 1</b>	Up to 20 sheets, depending on their size and thickness
	<b>Tray 2/3</b>	Not supported
<b>Orientation</b>	Face down	
<b>Driver Media Type</b>	Letterhead	
<b>Weight</b>	60 to 90 g/m <sup>2</sup> (16 to 24 lb bond)	
<b>Duplexing</b>	Not supported	

## Postcard

You can print continuously with postcard. However, this could affect the media feed, depending on the media quality and printing environment. If problems occur, stop the continuous printing and print one sheet at a time.

Try printing your data on a sheet of plain paper first to check placement.

<b>Capacity</b>	<b>Tray 1</b>	Up to 20 sheets, depending on their thickness
	<b>Tray 2/3</b>	Not supported

<b>Orientation</b>	Face down
<b>Driver Media Type</b>	Postcard
<b>Weight</b>	60 to 163 g/m <sup>2</sup> (16 to 43 lb bond)
<b>Duplexing</b>	Not supported

### Use postcards that are

- Approved for laser printing

### DO NOT use postcards that are


- Coated
- Designed for inkjet printers
- Precut or perforated
- Preprinted or multicolored



*If the postcard is warped, press on the warped area before putting it in the tray.*



- Folded or wrinkled



### Transparency



*Do not fan transparencies before loading them. Resulting static electricity may cause printing errors.*



*If you touch the face of the transparencies with your bare hands, print quality may be affected.*



*Keep the media path clean. Transparencies are especially sensitive to a dirty media path. If there are shadows on either the top or the bottom of the sheets, see chapter 8, "Maintenance".*



*Remove transparencies as soon as possible from the output tray to avoid static buildup.*

You can print continuously with transparencies. However, this could affect the media feed, depending on the media quality, static buildup, and printing environment.

Try printing your data on a sheet of plain paper first to check placement.



*If you have problems feeding 20 sheets, try loading only 1–10 sheets at a time. Loading a large number of transparencies at one time may cause static buildup, causing feeding problems.*

<b>Capacity</b>	<b>Tray 1</b>	Up to 20 sheets, depending on their thickness
	<b>Tray 2/3</b>	Not supported
<b>Orientation</b>	Face down	
<b>Driver Media Type</b>	Transparency	
<b>Duplexing</b>	Not supported	



*Always first test a small quantity of a particular type of transparency.*

### **Use transparencies that are**

- Approved for laser printing

### **DO NOT use transparencies that**

- Have static electricity that will cause them to stick together
- Are specified for inkjet printers only

## **Glossy Media**

Test all glossy media to ensure acceptable performance and to ensure that the image does not shift.

You can print continuously with glossy media. However, this could affect the media feed, depending on the media quality and printing environment. If problems occur, stop the continuous printing and print one sheet at a time.

<b>Capacity</b>	<b>Tray 1</b>	Up to 20 sheets, depending on their thickness
	<b>Tray 2/3</b>	Not supported
<b>Orientation</b>	Face down	

<b>Driver</b>	Glossy 1
<b>Media Type</b>	Glossy 2
<b>Duplexing</b>	Not supported

**DO NOT use glossy media that is**

- Mixed with any other media in the trays (as this will cause media misfeeding)
- Specified for inkjet printers only


## Guaranteed Imageable (Printable) Area

The printable area on all media sizes is up to 4 mm (0.157") from the edges of the media.

Each media size has a specific imageable area, the maximum area on which the machine can print clearly and without distortion.

This area is subject to both hardware limits (the physical media size and the margins required by the machine) and software constraints (the amount of memory available for the full-page frame buffer).

The guaranteed imageable (printable) area for all media sizes is the page size minus 4.2 mm (0.165") from all edges of the media.



## Imageable Area—Envelopes


Envelopes have a nonguaranteed imageable area that varies with envelope type.



*The envelope print orientation is determined by your application.*



*With the Envelope DL size (long edge feeding), the nonimageable areas on the left and right sides are 6 mm.*




## Page Margins

Margins are set through your application. Some applications allow you to set custom page sizes and margins while others have only standard page sizes and margins from which to choose. If you choose a standard format, you may lose part of your image (due to imageable area constraints). If you can custom-size your page in your application, use those sizes given for the imageable area for optimum results.

# Loading Media

## How do I load media?

Take off the top and bottom sheets of a ream of paper. Holding a stack of approximately 100 sheets at a time, fan the stack to prevent static buildup before inserting it in a tray.



*Do not fan transparencies.*

### Note

---

**Although this machine was designed for printing on a wide range of media types, it is not intended to print exclusively on a single media type except plain paper. Continuous printing on media other than plain paper (such as envelopes, labels, thick stock, or transparencies) may adversely affect print quality or reduce engine life.**

---


When refilling media, first remove any media remaining in the tray. Stack it with the new media, even the edges, then reload it.

## Tray 1 (Manual Feed Tray)


For details on the types and sizes of media that can be printed from Tray 1, refer to “Specifications” on page 66.

### Loading Plain Paper

- 1 Open Tray 1.




- 2** Slide the media guides to provide more space between them.



- 3** Press down on the center of the paper-lifting plate until the left and right locking tabs (white) lock into place.




- 4** Load the paper face down in the tray.






*Do not load so much paper that the top of the stack is higher than the maximum limit guide. Up to 100 sheets (80 g/m<sup>2</sup> [22 lb]) of plain paper can be loaded into the tray at one time.*



- 5** Slide the media guides against the edges of the paper.



- 6** Select PAPER SETUP/TRAY1 PAPER in the UTILITY menu, and then select the settings for the size and type of paper that is loaded. See also “Specifications” on page 66.

## Other Media


When loading media other than plain paper, set the media mode (Envelope, Label, Letterhead, Thick 1, Thick 2, Glossy 1, Glossy 2, or Transparency) in the driver for optimum print quality.

## Loading Envelopes


- 1 Open Tray 1.



- 2 Slide the media guides to provide more space between them.




- 3 Press down on the center of the paper-lifting plate until the left and right locking tabs (white) lock into place.



- 4** Load the envelopes flap side up in the tray.




*Before loading envelopes, press them down to make sure that all air is removed, and make sure that the folds of the flaps are firmly pressed; otherwise the envelopes may become wrinkled or a media misfeed may occur.*




*Up to 10 envelopes can be loaded into the tray at one time.*



*For envelopes with the flap along the long edge (Envelope C6, Envelope Monarch, and Envelope DL), load the envelopes with the flap side up.*




- 5** Slide the media guides against the edges of the envelopes.




- 6 Select PAPER SETUP/TRAY1 PAPER in the UTILITY menu, and then select the settings for the size and type of media that is loaded. See also "Specifications" on page 66.

### Loading Label Sheets/Letterheads/Postcards/Thick Stock/Glossy Media and Transparencies


- 1 Open Tray 1.



- 2 Slide the media guides to provide more space between them.




- 3** Press down on the center of the paper-lifting plate until the left and right locking tabs (white) lock into place.




- 4** Load the media face down in the tray.



*Up to 20 sheets can be loaded into the tray at one time.*



- 5** Slide the media guides against the edges of the media.




- 6** Select PAPER SETUP/TRAY1 PAPER in the UTILITY menu, and then select the settings for the size and type of media that is loaded. See also "Specifications" on page 66.


## Tray 2

### Loading Plain Paper


- 1 Pull out Tray 2.




- 2 Press down the media pressure plate to lock it into place.




- 3 Slide the media guides to provide more space between them.




- 4 Load the paper face up in the tray.




*Do not load above the ▼ mark. Up to 250 sheets (80 g/m<sup>2</sup> [22 lb]) of plain paper can be loaded into the tray at one time.*



- 5 Slide the media guides against the edges of the paper.



- 6 Close Tray 2.




- 7 Select PAPER SETUP/TRAY2 PAPER in the UTILITY menu, and then select the settings for the size of paper that is loaded. See also "Specifications" on page 66.


# Tray 3 (Optional Lower Feeder Unit)

## Loading Plain Paper


1 Pull out Tray 3.




2 Press down the media pressure plate to lock it into place.




3 Slide the media guides to provide more space between them.




- 4** Load the paper face up in the tray.




*Do not load above the ▼ mark. Up to 500 sheets (80 g/m<sup>2</sup> [22 lb]) of plain paper can be loaded into the tray at one time.*



- 5** Slide the media guides against the edges of the paper.



**6** Close Tray 3.



# About Duplex Printing

Duplex (double-sided) printing can be done with magicolor 4690MF, which has the duplex unit built in as a standard. If the paper has low opacity (high translucency), then the printed data from one side of the page will show through to the other side. Check your application for margin information. For best results, print a small quantity to make sure the opacity is acceptable.

## Note

---

**Only plain paper, 60–90 g/m<sup>2</sup> (16–24 lb bond) can be autoduplexed. See “Specifications” on page 66.**



**Duplexing envelopes, labels, letterheads, postcards, thick stock, glossy media or transparencies is not supported.**

---

## How do I autoduplex?



Check your application to determine how to set your margins for duplex (double-sided) printing.

The following Binding Position settings are available.

 A diagram showing a sheet of paper with two punch holes at the top edge. The top edge is labeled '1', the right edge is labeled '3', and the bottom edge is labeled '2'. This indicates that the paper is laid out with the top edge as the binding edge.	If “Short Edge Binding” is selected, the pages will be laid out to flip at the top.
 A diagram showing a sheet of paper with two punch holes at the left edge. The left edge is labeled '1', the right edge is labeled '3', and the top edge is labeled '2'. This indicates that the paper is laid out with the left edge as the binding edge.	If “Long Edge Binding” is selected, the pages will be laid out to flip at the side.

In addition, if “Combination” has been set to “Booklet”, autoduplex printing is performed.

The following Order settings are available when “Booklet” is selected.

	If “Left Binding” is selected, the pages can be folded as a left-bound booklet.
	If “Right Binding” is selected, the pages can be folded as a right-bound booklet.

- 1 Load plain paper into the tray.
- 2 From the printer driver, specify duplex (double-sided) printing (Layout tab in Windows).
- 3 Click **OK**.



*With autoduplexing, the back side is printed first, and then the front side is printed.*

# Output Tray

All media is fed out facing down into the output tray on the left side of the machine. This tray has a capacity of approximately 250 sheets (A4/Letter) of 80 g/m<sup>2</sup> paper.




*If the media is stacked too high in the output tray, your machine may experience media misfeeds, excessive media curl, or static buildup.*



*Remove transparencies as soon as possible from the output tray to avoid static buildup*

The output tray can be pulled out to be extended. Adjust the output tray according to the size of paper to be printed on.



# Media Storage

- Keep media on a flat, level surface in its original wrapper until it is time to load it.

*Media that has been stored for a long time out of its packaging may dry up too much and cause misfeeding.*

- If media has been removed from its wrapper, place it in its original packaging and store in a cool, dark place on a level surface.
- Avoid moisture, excessive humidity, direct sunlight, excessive heat (above 35°C [95°F]), and dust
- Avoid leaning against other objects or placing it in an upright position.

Before using stored media, do a trial print and check print quality.

# Original Media

## Specifications

### Documents that can be placed on the original glass

The following types of documents can be placed on the original glass.

Document type	Sheets or books
Maximum document size	Legal
Maximum weight	3 kg (6.6 lb)

Observe the following precautions when placing a document on the original glass.

- Do not place objects weighing more than 3 kg (6.6 lb) on the original glass; otherwise the glass may be damaged.
- Do not press down extremely hard on a book spread on the original glass; otherwise the original glass may be damaged.

### Documents that can be loaded into the ADF

The following types of documents can be loaded into the ADF.

Document media type / Weight	Plain paper / 50 to 128 g/m <sup>2</sup> (13 to 34 lb)
Maximum document size	Legal
Media capacity	50 sheets (media weight: 80 g/m <sup>2</sup> )

Do not load the following types of documents into the ADF.


- Documents containing pages of different sizes
- Wrinkled, folded, curled, or torn documents
- Highly translucent or transparent documents, such as overhead transparencies or diazo photosensitive paper
- Coated documents such as carbon-backed paper
- Documents printed on paper thicker than 128 g/m<sup>2</sup> (34 lb)
- Documents with pages bound together with paper clips or staples
- Documents that are bound in a book or booklet
- Documents with pages bound together with glue

- Documents with pages that have had cutouts removed or are cutouts
- Label sheets
- Offset printing masters
- Documents with binder holes


# Loading a Document to be Copied

## Placing a document on the original glass


- 1 Lift to open the ADF cover.




- 2 Position the document on the original glass.



*Align the document with the arrow on the left side toward the rear of the machine.*



- 3 Gently close the ADF cover.




## Loading a document into the ADF


- 1 Put the document into the ADF document feed tray face up.



*Before loading a document into the ADF, check that no document pages remain on the original glass.*



- 2 Adjust the document guides to the document size.



---

***Using the Printer  
Driver***

---

**4**

# Selecting Printer Driver Options/Defaults (for Windows)

Before you start working with your machine, you are advised to verify and change the default printer driver settings if necessary. Also, in case you have options installed, you should “declare” the options in the printer driver.

- 1 Choose the driver’s properties as follows:
  - (Windows Vista)  
From the **Start** menu, select **Control Panel**, and then click **Hardware and Sound** to select **Printers**. Right-click the KONICA MINOLTA magicolor 4690MF printer icon, and then select **Printing Preferences**.
  - (Windows XP/Server 2003)  
From the **start** menu, select **Printers and Faxes** to display the **Printers and Faxes** directory. Right-click the KONICA MINOLTA magicolor 4690MF printer icon and select **Printing Preferences**.
  - (Windows 2000)  
From the **Start** menu, select **Settings** and then **Printers** to display the **Printers** directory. Right-click the KONICA MINOLTA magicolor 4690MF printer icon and select **Printing Preferences**.

2 If you have installed available options, proceed with the next step. Otherwise, proceed with step 8.

3 Select the **Device Options Setting** tab.

4 Check the options that have been correctly identified.



*Since **Auto Configure** is selected as a default with this driver, installed options are automatically identified. If the options are not correctly identified, follow the operations described in steps 5 through 7.*

5 Clear the **Auto Configure** check box.

6 Select an option (one at a time), and then select **Installed** from **Settings**. **Installed** appears to the right of the option in the **Device Options** list.



*To uninstall an option, select the option to be uninstalled in the **Device Options** list, and then select **Not Installed** from **Settings**.*

7 Click **Apply**.



*Depending on the version of the operating system, **Apply** may not appear. If this is the case, continue with the next step.*

8 Select the **Basic** tab. Select the default settings for your machine, such as the default media format you use.

- 9 Click **Apply**.
- 10 Click **OK** to exit from the Printing Preferences dialog box.

# Uninstalling the Printer Driver (for Windows)

This section describes how to uninstall the magicolor 4690MF printer driver if necessary.

## Windows Vista/XP/Server 2003/2000

- 1 Close all applications.
- 2 Choose Uninstall Program as follows:
  - (Windows Vista/XP/Server 2003)  
From the **Start** menu, choose **All programs, KONICA MINOLTA, magicolor 4690MF, Printer**, and then **Uninstall**.
  - (Windows 2000)  
From the **Start** menu, choose **Program, KONICA MINOLTA, magicolor 4690MF, Printer**, and then **Uninstall**.
- 3 When the Uninstall dialog box appears, click **OK** to uninstall.
- 4 The magicolor 4690MF printer driver will be uninstalled from your computer.

# Displaying Printer Driver Settings

## Windows Vista

- 1 From the **Start** menu, select **Control Panel**, and then click **Hardware and Sound** to select **Printers**.
- 2 Right-click the KONICA MINOLTA magicolor 4690MF printer icon then select **Printing Preferences**.

## Windows XP/Server 2003

- 1 From the **start** menu, select **Printers and Faxes** to display the **Printers and Faxes** directory.
- 2 Right-click the KONICA MINOLTA magicolor 4690MF printer icon and select **Printing Preferences**.

## Windows 2000

- 1 From the **Start** menu, select **Settings**, and then click **Printers** to display the **Printers** directory.

- 2 Right-click the KONICA MINOLTA magicolor 4690MF printer icon and select **Printing Preferences**.

# Printer Driver Settings

## Common Buttons

The buttons described below appear on each tab.

- OK

Click to exit the Properties dialog box, saving any changes made.

- Cancel

Click to exit the Properties dialog box without saving any changes made.

- Apply

Click to save all changes without exiting the Properties dialog box.



*Depending on the version of the operating system, **Apply** may not appear.*

- Help

Click to view the help.

- Easy Set

Click **Save** to save the current settings. Specify a **Name** and **Comment** to access the settings for use again later.

**Name:** Type in the name of the settings to be saved.

**Comment:** Add a simple comment to the settings to be saved.

Afterward, the saved settings can be selected from the drop-down list. To change the registered settings, click **Edit**.

Select **Default** from the drop-down list to reset the functions in all tabs to their default values.

- Paper View

Click the button to display a sample of the page layout in the figure area.



*This button does not appear on the **Watermark, Quality and Version** tabs.*

- Printer View

Click the button to display an image of the printer in the figure area.



*This button does not appear on the **Version** tab.*

- Watermark View

Click the button to display a preview of the watermark.



*This button appears only when the **Watermark** tab is selected.*

- Quality View

Click the button to display a sample of the settings selected in the **Quality** tab.



*This button appears only when the **Quality** tab is selected.*

- Default

Click the button to reset the settings to their defaults.



*This button does not appear on the **Version** tab.*



*When this button is clicked, the settings in the displayed dialog box are reset to their defaults. The settings on other tabs are not changed.*

## Basic Tab

The Basic Tab allows you to

- Specify the orientation of the media
- Specify the size of the original document
- Select the output media size
- Register/edit custom paper sizes
- Zoom (expand/reduce) documents
- Specify the paper source
- Specify the type of media
- Select the paper used for the front page
- Specify the number of copies
- Turn on/off job collation

## Layout Tab

The Layout Tab allows you to

- Print several pages of a document on the same page (N-up printing)
- Print a single copy for enlargement and print several pages
- Rotate the print image 180 degrees
- Specify Double-Sided printing
- Specify booklet printing
- Specify image shift settings

## Overlay Tab



*Be sure to use overlays with print jobs with a media size and orientation that matches the overlay form.*

*In addition, if settings have been specified for “N-up” or “Booklet” in the printer driver, the overlay form cannot be adjusted to match the specified settings.*

The Overlay Tab allows you to

- Select the form Overlay to use
- Add, edit or delete overlay files
- Print the form on all pages or only the first page

## Watermark Tab

The Watermark Tab allows you to

- Select the watermark to be used
- Add, edit or delete watermarks
- Print the watermark on the background
- Print the watermark on only the first page
- Print multiple copies of the selected watermark on a single page

## Quality Tab

The Quality Tab allows you to

- Specify whether to print in color or black and white
- Adjust the contrast (Contrast)
- Control the darkness of an image (Brightness)
- Adjust the saturation of printed image (Saturation)

- Adjust the sharpness of the printed image
- Specify the color matching for printing documents
- Specify the resolution for the printout
- Select whether or not economy print is used

## **Device Options Setting Tab**

The Device Options Setting tab allows you to

- Automatically identify installed options
- Activate Tray 3
- Enter the user name that is sent with the print job(s)

## **Version Tab**

- The Version Tab allows you to view information about the printer driver.



---

*Using the Copier*

---

**5**

# Making Basic Copies

This section contains descriptions of the basic copy operation procedure and the functions that are frequently used when making copies, such as specifying the zoom ratio and the copy density.



*If the **Fax** key or **Scan** key lights up in green while copying, press the **Copy** key.*



*The default paper size setting can be changed with **PAPER SETUP** in the **UTILITY** menu. For details, refer to “**PAPER SETUP Menu**” on page 34.*



If, while specifying settings, no key is pressed for the length of time specified for **AUTO PANEL RESET**, the entered settings are canceled and the main screen is displayed.

## Basic Copy Operation

- 1 Position the document to be copied.



*For details on positioning the document, refer to “**Placing a document on the original glass**” on page 95 and “**Loading a document into the ADF**” on page 96.*



## 2 Specify the desired copy settings.



For details on specifying the copy mode and the copy density, refer to “Specifying the Copy Quality Setting” on page 109.

For details on specifying the zoom ratio, refer to “Specifying the Zoom Ratio” on page 110.

For details on selecting the media tray, refer to “Selecting the Media Tray” on page 111.

For details on setting 2in1 and 4in1 copying, refer to “Setting 2in1/4in1 Copying” on page 112.

For details on ID card copying, repeat copying or poster copying, refer to “Setting a Copy Function” on page 113.

For details on duplex (double-sided) copying, refer to “Setting Duplex (Double-Sided) Copying” on page 117.

For details on setting collated copying, refer to “Setting Collated (Sort) Copying” on page 119.

## 3 Using the keypad, specify the desired number of copies.



If the number of copies was incorrectly entered, press the **Back** key, and then specify the correct number of copies.

## 4 To print color copies, press the **Start-Color** key. To print monochrome copies, press the **Start-B&W** key.

Copying begins.



If the **Stop/Reset** key is pressed while copying, **JOB CANCEL** appears. To stop copying, select **YES**. To continue copying, select **NO**.

## Specifying the Copy Quality Setting

Select the copy mode and density appropriate for the contents and density of the document to be copied.

### Selecting the Copy Mode

1 In the main screen, press the **▲** or **▼** key to select the current copy quality setting, and then press the **Select** key.

2 Press the **▲** or **▼** key to select **MODE**, and then press the **Select** key.

3 Press the **▲** or **▼** key to select **MIX**, **TEXT**, **PHOTO**, **FINE/MIX**, **FINE/TEXT** or **FINE/PHOTO**, and then press the **Select** key.

The main screen appears again.

## Specifying the Copy Density

- 1 In the main screen, press the ▲ or ▼ key to select the current copy quality setting, and then press the **Select** key.
- 2 Press the ▲ or ▼ key to select DENSITY, and then press the **Select** key.
- 3 Press the ◀ or ▶ key to select the desired copy density.  
As the indicator is moved to right, the density becomes darker.



*If TEXT or FINE/TEXT is selected as the copy mode, select either AUTO or MANUAL in step 3. If MANUAL is selected, specify the copy density.*

## Specifying the Zoom Ratio

The zoom ratio can be specified either by selecting a preset zoom ratio or by specifying a custom zoom ratio.

### Selecting a Preset Zoom Ratio

- 1 In the main screen, press the ▲ or ▼ key to select the current zoom ratio setting, and then press the **Select** key.
- 2 Press the ▲ or ▼ key to select FIXED, and then press the **Select** key.
- 3 Press the ▲ or ▼ key to select the desired zoom ratio, and then press the **Select** key.



*The following zoom ratios can be selected.*

*In metric dimensions:*

*25%, 50%, 70% (A4→A5), 81% (A4→B5), 100%, 115% (B5→A4), 141% (A5→A4), 200%, 400%*

*In inch dimensions:*

*25%, 50%, 64% (LT→ST), 78% (LG→LT), 100%, 129% (ST→LT), 154% (ST→LG), 200%, 400%*

*The zoom ratio cannot be changed using the keypad.*

### Specifying a Custom Zoom Ratio

- 1 In the main screen, press the ▲ or ▼ key to select the current zoom ratio setting, and then press the **Select** key.
- 2 Press the ▲ or ▼ key to select MANUAL, and then press the **Select** key.
- 3 Use the keypad to type in the desired zoom ratio, or press the ▲ or ▼ key to specify the zoom ratio.



*Each press of the ▲ or ▼ key changes the zoom ratio by 1%.  
A setting between 25% and 400% can be specified.*

## Selecting the Media Tray



*If the optional lower feeder unit is not installed, the TRAY3 does not appear.*

- 1 In the main screen, press the ▲ or ▼ key to select the current media tray setting, and then press the **Select** key.
- 2 Press the ▲ or ▼ key to select the desired media tray, and then press the **Select** key.



*If no paper is loaded, EMPTY appears to the right of the media type.*

# Making Advanced Copies

This section contains descriptions on setting 2in1/4in1 copying, ID card copying, repeat copying, poster copying, duplex (double-sided) copying and collated (Sort) copying.

## Setting 2in1/4in1 Copying

If 2in1 copying is set, two document pages can be copied together onto a single page. If 4in1 copying is set, four document pages can be copied together onto a single page.

### 2in1/4in1 Copying From the ADF

- 1 In the main screen, press the ▲ or ▼ key to select the current page layout setting, and then press the **Select** key.
- 2 Press the ▲ or ▼ key to select 2in1 or 4in1, and then press the **Select** key.  
The zoom ratio is automatically set according to the specified paper type. Change the zoom ratio if necessary.



*In order to perform duplex (double-sided) copying or collated (Sort) copying with 2in1/4in1 copying, specify the necessary settings before starting the copy operation. For details, refer to “Setting Duplex (Double-Sided) Copying” on page 117 and “Setting Collated (Sort) Copying” on page 119.*

### 2in1/4in1 Copying From the Original Glass

- 1 In the main screen, press the ▲ or ▼ key to select the current page layout setting, and then press the **Select** key.
- 2 Press the ▲ or ▼ key to select 2in1 or 4in1, and then press the **Select** key.  
The zoom ratio is automatically set according to the specified paper type. Change the zoom ratio if necessary.
- 3 Position the first page of the document on the original glass.



*For details on positioning the document on the original glass, refer to “Placing a document on the original glass” on page 95.*

- 4 To print color copies, press the **Start-Color** key. To print monochrome copies, press the **Start-B&W** key.  
Scanning of the document begins.



*In order to perform duplex (double-sided) copying or collated (Sort) copying with 2in1/4in1 copying, specify the necessary settings before performing step 4. For details, refer to “Setting Duplex (Double-Sided) Copying” on page 117 and “Setting Collated (Sort) Copying” on page 119.*

- 5 When **NEXT PAGE?** appears in the message window, place the second document page on the original glass, and then press the **Select** key.
- 6 Repeat step 5 until all document pages have been scanned.  
If **2in1** is set, printing automatically begins after two document pages (four document pages if duplex (double-sided) copying was set) have been scanned. If **4in1** is set, printing automatically begins after four document pages (eight document pages if duplex (double-sided) copying was set) have been scanned.
- 7 After all document pages have been scanned, press the **Start-Color** key or the **Start-B&W** key to begin printing the remaining pages.

## Setting a Copy Function

ID card copying, repeat copying and poster copying can be set.




*If a copy function other than **NORMAL COPY** has been set, 2in1/4in1 copying, collated (Sort) copying and duplex (double-sided) copying cannot be set. In addition, the zoom ratio is automatically set (and cannot be changed).*



*ID card copying, repeat copying and poster copying can only be performed with the original glass. Position the document pages to be scanned so that they are aligned in the upper-left corner of the original glass. Since the image is printed 4 mm from the top and left side, adjust the position of the document as necessary. For details on positioning the document on the original glass, refer to “Placing a document on the original glass” on page 95.*

## ID Card Copying

With ID card copying, the back and front of a document, such as a certificate, are copied at full size on a single sheet of paper.



The paper sizes that are available for ID card copying are A4, Letter and Legal.

- 1 Position the document on the original glass.



For details on positioning the document on the original glass, refer to “Placing a document on the original glass” on page 95.


- 2 In the main screen, press the ▲ or ▼ key to select the current copy function setting, and then press the **Select** key.
- 3 Press the ▲ or ▼ key to select ID CARD COPY, and then press the **Select** key.
- 4 To print color copies, press the **Start-Color** key. To print monochrome copies, press the **Start-B&W** key.  
*Scanning of the document begins.*
- 5 When NEXT PAGE? appears, position the back side of the document at the same location as the front side, and then press the **Select** key.  
*After the back side has been scanned, printing automatically begins.  
The main screen appears again.*



To print only the front sides that were scanned first, press the **Start-Color** key or the **Start-B&W** key in step 5.

## Repeat Copying

With repeat copying, small documents, such as memos, are tiled and printed on a single page.



- 1 Position the document on the original glass.
  -  For details on positioning the document on the original glass, refer to “Placing a document on the original glass” on page 95.
- 2 In the main screen, press the ▲ or ▼ key to select the current copy function setting, and then press the **Select** key.
- 3 Press the ▲ or ▼ key to select REPEAT COPY, and then press the **Select** key.
- 4 When the How to Repeat Copy screen appears, check the settings, and then press the **Select** key.
- 5 To print color copies, press the **Start-Color** key. To print monochrome copies, press the **Start-B&W** key.
- 6 Use the keypad to type in the document length, and then press the **Select** key.
  -  To change the document size, press the **Back** key to delete the current size, and then use the keypad to specify the desired size.
- 7 Use the keypad to type in the document width, and then press the **Select** key.
 

After the document has been scanned, printing automatically begins. The main screen appears again.



  -  To change the document size, press the **Back** key to delete the current size, and then use the keypad to specify the desired size.

## Poster Copying

With poster copying, the length and width of the scanned document are each enlarged 200%, and printed on four pages.



*If the scanned image does not fit on the size of paper that is used, there may be margins on the sides of the image or the image may not fit in the paper.*



- 1 Position the document on the original glass.



*For details on positioning the document on the original glass, refer to "Placing a document on the original glass" on page 95.*

- 2 In the main screen, press the ▲ or ▼ key to select the current copy function setting, and then press the **Select** key.
- 3 Press the ▲ or ▼ key to select **POSTER COPY**, and then press the **Select** key.
- 4 To print color copies, press the **Start-Color** key. To print monochrome copies, press the **Start-B&W** key.  
After the document has been scanned, printing automatically begins.  
The main screen appears again.

## Setting Duplex (Double-Sided) Copying

### Duplex (Double-Sided) Copying From the ADF

With duplex (double-sided) copying, two single-sided document pages can be scanned with the ADF and printed onto a single sheet of paper.

- 1 In the main screen, press the ▲ or ▼ key to select the current simplex/duplex (single-sided/double-sided) setting, and then press the **Select** key.
- 2 Press the ▲ or ▼ key to select 1 - SIDE→2 - SIDE, and then press the **Select** key.
- 3 Press the ▲ or ▼ key to select LONG EDGE or SHORT EDGE, and then press the **Select** key.  
The main screen appears again.



*When LONG EDGE or SHORT EDGE is selected, duplex (Double-Sided) copying is performed as described below.*

	If <i>LONG EDGE</i> is selected, the pages will be laid out to flip at the sides.
	If <i>SHORT EDGE</i> is selected, the pages will be laid out to flip at the top.


## Duplex (Double-Sided) Copying From the Original Glass

Duplex (double-sided) copying can also be performed by placing the document on the original glass.

- 1 Position the document on the original glass.



*For details on positioning the document on the original glass, refer to "Placing a document on the original glass" on page 95.*



- 2 In the main screen, press the ▲ or ▼ key to select the current simplex/duplex (single-sided/double-sided) setting, and then press the **Select** key.
- 3 Press the ▲ or ▼ key to select 1 - SIDE→2 - SIDE, and then press the **Select** key.
- 4 Press the ▲ or ▼ key to select LONG EDGE or SHORT EDGE, and then press the **Select** key.



*For details on LONG EDGE and SHORT EDGE, refer to "Duplex (Double-Sided) Copying From the ADF" on page 117.*

- 5 To print color copies, press the **Start-Color** key. To print monochrome copies, press the **Start-B&W** key.  
*Scanning of the document begins.*
- 6 When NEXT PAGE? appears in the message window, place the second document page on the original glass, and then press the **Start-Color** key or the **Start-B&W** key.

*After the second page (back side) is scanned, printing begins automatically.*

*The main screen appears again.*

## Duplex (Double-Sided) Document Copying

A duplex (double-sided) document can be scanned and printed as either a duplex (double-sided) copy or a simplex (single-sided) copy.



*Duplex (double-sided) document copying can only be performed from the ADF.*

- 1 In the main screen, press the ▲ or ▼ key to select the current simplex/duplex (single-sided/double-sided) setting, and then press the **Select** key.
- 2 Press the ▲ or ▼ key to select 2 -SIDE→2 -SIDE for a duplex (double-sided) copy or 2 -SIDE→1 -SIDE for a simplex (single-sided) copy, and then press the **Select** key.
- 3 Press the ▲ or ▼ key to select LONG EDGE or SHORT EDGE as the binding position in the document to be scanned, and then press the **Select** key.
- 4 If 2 -SIDE→2 -SIDE was selected in step 3, select LONG EDGE or SHORT EDGE as the binding position of the duplex (double-sided) copy, and then press the **Select** key.

## Setting Collated (Sort) Copying

With collated (Sort) copying, multiple copies of multi-page documents can be printed in order and sorted by copy set.

### Collated (Sort) Copying From the ADF

- 1 In the main screen, press the ▲ or ▼ key to select the current Sort setting, and then press the **Select** key.
- 2 Press the ▲ or ▼ key to select SORT, and then press the **Select** key.

### Collated (Sort) Copying From the Original Glass

- 1 Position the document on the original glass.



*For details on positioning the document on the original glass, refer to "Placing a document on the original glass" on page 95.*

- 2 In the main screen, press the ▲ or ▼ key to select the current Sort setting, and then press the **Select** key.
- 3 Press the ▲ or ▼ key to select SORT, and then press the **Select** key.
- 4 To print color copies, press the **Start-Color** key. To print monochrome copies, press the **Start-B&W** key.

- 5 When **NEXT PAGE?** appears in the message window, place the second document page on the original glass, and then press the **Select** key.
- 6 Repeat step 5 until all document pages have been scanned.
- 7 After all document pages have been scanned, specify the desired number of copies using the keypad, and then press the **Start-Color** key or the **Start-B&W** key to begin printing.

---

*Using the Scanner*

---

6

# Scanning From a Computer Application

Documents can be scanned from a computer connected to this machine with a USB cable or via a network. Scanning settings can be specified and the scanning operation can be performed from TWAIN- or WIA-compatible applications. From the scanner driver, a preview can be displayed and various adjustments, such as the size of the scan area, can be specified.





*For details on the installation of the scanner driver or network TWAIN settings, refer to the Installation Guide on the Documentation CD/DVD.*

## Basic Scanning Operation

- 1 Position the document to be scanned.



*For details on positioning the document, refer to “Placing a document on the original glass” on page 95 and “Loading a document into the ADF” on page 96.*



- 2 Start the application to be used for scanning.
- 3 Start the scanner driver according to the application settings.
- 4 Specify the necessary scanner driver settings.
- 5 Click the **Scan** button in the scanner driver.

## Windows TWAIN Driver Settings

- Load

Specify a saved settings file (dat file) for scanning.

- Save

Save the current settings as a settings file (dat file).

- Default

Return all settings to their defaults.

- Help icon

Click to display the Help.

- About icon

Click to display the software version information.

- ADF

With scanning documents from the ADF, select whether to scan only the front side or both sides of the document.

- Original Size

Specify the original size.

- Scan Type

Specify the scan type.

- Resolution

Specify the resolution.

- Scale

Specify the enlargement or reduction ratio for the selected area.



*If the resolution is set at 1200 × 1200dpi or higher, a setting larger than 100% cannot be specified.*

- Scanning mode

Select **Auto** or **Manual**. When **Manual** is selected, a tab appears so that detailed settings can be specified, for example, for **Brightness/Contrast** and **Filter**.

- Image size

Shows the data size of the scan image.

- Rotation

Select the orientation of the image to be scanned.



*If the **Rotate back side** check box is selected, the back side of the image is rotated 180° and scanned. (Applies only if **ADF (Duplex)** is selected)*

- Close

Click to close the TWAIN driver window.

- Prescan

Click to begin scanning a preview image.

- Scan

Click to begin scanning.

- AutoCrop icon

Click to automatically detect the scanning position based on the preview image.

- Zoom icon

Click to rescan the area selected in the preview window and enlarge it to fit the window.

- Mirror icon

Click to display a mirror image of the preview image.

- Tone Reversal icon

Click to reverse the colors of the preview image.

- Clear icon

Click to erase the preview image.

- Preview window

Displays a preview image. Drag the rectangle over the image to select an area.

- Before/After (RGB)

Move the pointer in the preview window to display the color tones at the pointer's position before and after adjustments.

- Width/Height

Displays the width and height for the selected area in the selected measurement units.

## Windows WIA Driver Settings

- Paper source

Select the paper source.

- Color picture

Select this setting when scanning in color.

- Grayscale picture

Select this setting when scanning in grayscale.

- Black and white picture or text

Select this setting when scanning in black and white.

- Custom Settings

Select this setting when scanning with **Adjust the quality of the scanned picture** settings applied.



*If settings have been specified with **Adjust the quality of the scanned picture**, **Custom Settings** is automatically selected.*

- Adjust the quality of the scanned picture

Click this message to display the Advanced Properties dialog box. In the Advanced Properties dialog box, settings can be specified for **Brightness**, **Contrast**, **Resolution**, and **Picture type** (select from color, grayscale or black and white).



*These settings are applied when **Custom Settings** is selected.*

- Page size

Specify the paper size when **Page source** is set to **Document Feeder**.

- Preview window

Displays a preview image. Drag the rectangle over the image to select an area.

- Preview

Click to begin scanning a preview image.

- Scan

Click to begin scanning.

- Cancel

Click to close the WIA driver window.

## Macintosh TWAIN Driver Settings

- Load

Specify a saved settings file (dat file) for scanning.

- Save

Save the current settings as a settings file (dat file).

- Default

Return all settings to their defaults.

- Help icon

Click to display the Help.

- About icon

Click to display the software version information.

- ADF

With scanning documents from the ADF, select whether to scan only the front side or both sides of the document.

- Original Size

Specify the original size.

- Scan Type

Specify the scan type.

- Resolution

Specify the resolution.

- Scale

Specify the enlargement or reduction ratio for the selected area.



*If the resolution is set at 1200 × 1200dpi or higher, a setting larger than 100% cannot be specified.*

- Scanning mode

Select **Auto** or **Manual**. When **Manual** is selected, a tab appears so that detailed settings can be specified, for example, for **Brightness/Contrast** and **Filter**.

- Image size

Shows the data size of the scan image.

- Rotation

Select the orientation of the image to be scanned.



*If the **Rotate back side** check box is selected, the back side of the image is rotated 180° and scanned. (Applies only if **ADF (Duplex)** is selected)*

- Close

Click to close the TWAIN driver window.

- Prescan

Click to begin scanning a preview image.

- Scan

Click to begin scanning.

- AutoCrop icon

Click to automatically detect the scanning position based on the preview image.

- Zoom icon

Click to rescan the area selected in the preview window and enlarge it to fit the window.

- Mirror icon

Click to display a mirror image of the preview image.

- Tone Reversal icon

Click to reverse the colors of the preview image.

- Clear icon

Click to erase the preview image.

- Preview window

Displays a preview image. Drag the rectangle over the image to select an area.

- Before/After (RGB)

Move the pointer in the preview window to display the color tones at the pointer's position before and after adjustments.

- Width/Height

Displays the width and height for the selected area in the selected measurement units.

# Scanning With the Machine

The machine keys can be used to make scans. This operation differs from scanning from a computer application since the destination of the scan data can also be specified.





*If, while specifying settings, no key is pressed for the length of time specified for **AUTO PANEL RESET**, the entered settings are canceled and the main screen is displayed.*

## Basic Scanning Operation

- 1 Position the document to be scanned.



*For details on positioning the document, refer to “Placing a document on the original glass” on page 95 and “Loading a document into the ADF” on page 96.*



- 2 Press the **Scan** key to enter Scan mode.

### 3 Specify the desired scan settings.



*For details on specifying the destination of the data, refer to “Specifying the Data Location” on page 130 and “Specifying the Destination Address (Scan to E-mail/FTP/SMB)” on page 132.*

*For details on selecting the data format, refer to “Selecting the Data Format” on page 146.*

*For details on selecting the scan quality setting, refer to “Selecting the Scan Quality Setting” on page 146.*

*For details on setting duplex (double-sided) scanning, refer to “Setting Duplex (Double-Sided) Scanning” on page 147.*

*For details on setting the scan size, refer to “Setting the Scan Size” on page 148.*

*For details on setting the color of the scan data, refer to “Setting the Scan Color” on page 148.*

*For details on specifying the subject when sending data, refer to “Specifying the Subject” on page 148.*

### 4 To scan color scans, press the **Start-Color** key. To scan monochrome scans, press the **Start-B&W** key.

If the document was loaded in the ADF, scanning begins, and then the data is sent to the specified location. If the document was placed on the original glass, continue with step 5.



*When scanning with the Scan to PC operation, select in the dialog box appearing on the computer screen the connection method that is used (USB or network).*

### 5 When **NEXT PAGE?** appears in the message window, place the second document page on the original glass, and then press the **Select** key.



*When scanning with the Scan to PC operation, a multi-page document cannot be scanned with the original glass. To scan a multi-page document, load the document into the ADF.*

### 6 Press the **▲** or **▼** key to select the size of the document positioned in step 5, and then press the **Select** key.

### 7 After all document pages have been scanned, press the **Start** key. The scanned document is sent to the specified location.



*If the **Stop/Reset** key is pressed while scanning, **JOB CANCEL** appears. To continue scanning, select **YES**. To stop scanning, select **NO**.*



*To cancel a job where scanning was finished and the data is queued to be sent, refer to “Deleting a Queued Transmission Job” on page 148.*

## Specifying the Data Location

Select whether the computer or USB memory device is the location where scan data is to be saved. When transmitting via a network, refer to "Specifying the Destination Address (Scan to E-mail/FTP/SMB)" on page 132.



*If an address has been specified as the destination for the data, **SCAN TO PC** and **SCAN TO USB MEMORY** cannot be selected.*

## Saving Data on a Computer Connected (Scan to PC)

Follow the procedure described below to send scan data to a computer connected to this machine.



*In order to perform this operation, make sure the TWAIN (or WIA) scanner driver, the printer driver, and LinkMagic (Windows only) have been installed on your computer.*



*Before performing the Scan to PC operation, be sure that either LinkMagic is activated or the LinkMagic icon appears in the notification area.*



*The scan settings specified with LinkMagic are given priority. Specify the various settings with LinkMagic. For details, refer to the Reference Guide on the Documentation CD/DVD.*

- 1 In the main screen, press the **▲** or **▼** key to select the current data destination setting, and then press the **Select** key.
- 2 Press the **▲** or **▼** key to select **SCAN TO PC**, and then press the **Select** key.



*The scan data is saved in the folder specified with LinkMagic. For details, refer to the Reference Guide on the Documentation CD/DVD.*

## Saving Data on a USB Memory Device (Scan to USB Memory)

Follow the procedure described below to save scan data to a USB memory device plugged into the USB HOST port of this machine.



*This machine is compatible with a USB memory device of 4 GB or less.*

- 1 Plug the USB memory device into the USB HOST port of this machine.
- 2 In the main screen, press the **▲** or **▼** key to select the current data destination setting, and then press the **Select** key.

- 3 Press the ▲ or ▼ key to select **SCAN TO USB MEMORY**, and then press the **Select** key.

# Specifying the Destination Address (Scan to E-mail/FTP/SMB)

Scan data can be sent via the network to a specified address (e-mail, FTP or SMB address). The address can be typed in directly, or an address registered on the machine can be selected.



*To send scan data via the network, settings for NETWORK SETTING and E-MAIL SETTING (when sending to an e-mail address) must be specified. For details, refer to the Reference Guide on the Documentation CD/DVD.*



*If the size of the scan data sent by e-mail exceeds the size specified with FILE SIZE, the data is automatically divided into multiple e-mail messages. For details, refer to "SCAN SETTING Menu" on page 61.*

## Directly Entering the E-mail Address

The destination address (e-mail address) where the scan data is to be sent can be directly typed in.



*A maximum of 16 addresses (total of e-mail addresses from direct input and an LDAP search) can be specified.*

- 1 In the main screen, use the keypad to type in the destination address.



*For details on entering/editing text, refer to "Entering Text" on page 265.*

- 2 After the text is entered, press the **Select** key.

- 3 If an e-mail address was selected, press the ▲ or ▼ key to select FINISH, and then press the **Select** key.



*To add an additional e-mail address, select ADD in step 3, and then specify the destination.  
To edit the specified e-mail address, select CHECK/EDIT in step 3, and then continue with step 2 of "Editing a Specified Destination Address". To delete an address, select CHECK/EDIT in step 3, and then continue with step 2 of "Deleting a Specified Destination Address".*

## Selecting From the Favorite List

From the speed dial destinations and group dial destinations registered on this machine, register a maximum of 20 destinations in the favorite list for convenient access to frequently specified destinations. Follow the procedure described below to specify an address (e-mail, FTP or SMB address) from the favorite list as the recipient of the scan data.



*For details on registering addresses in the favorite list, refer to "Registering in the Favorite List" on page 139.*

- 1 With the main screen or **Can Use AddressBook** displayed, press the **AddressBook** key so that **FAVORITE** appears.
- 2 Press the **▲** or **▼** key to select the desired data, and then press the **Select** key.  
If an FTP address or an SMB address was selected, the destination address is specified.
- 3 If an e-mail address was selected, press the **▲** or **▼** key to select **FINISH**, and then press the **Select** key.



*To add an additional e-mail address, select **ADD** in step 3, and then specify the destination. When sending the data to an FTP address or SMB address, multiple addresses cannot be specified. To edit the specified e-mail address, select **CHECK/EDIT** in step 3, and then continue with step 2 of "Editing a Specified Destination Address". To delete an address, select **CHECK/EDIT** in step 3, and then continue with step 2 of "Deleting a Specified Destination Address".*

## Selecting a Speed Dial Destination

A maximum of 250 speed dial destinations can be registered on this machine. Follow the procedure described below to specify an address (e-mail, FTP or SMB address) from the registered speed dial destinations as the recipient of the scan data.



*For details on registering addresses as speed dial destinations, refer to "Registering Speed Dial Destinations (Direct Input)" on page 140 or "Registering Speed Dial Destinations (LDAP Search)" on page 142.*

- 1 With the main screen or **Can Use AddressBook** displayed, press the **AddressBook** key twice so that **SPEED DIAL** appears.
- 2 Use the keypad to type in the number (between 1 and 250) for the speed dial destination, and then press the **Select** key.  
The information registered for the speed dial destination appears for two seconds.

- 3 Press the **Select** key again.  
If an FTP address or an SMB address was selected, the destination address is specified.
- 4 If an e-mail address was selected, press the ▲ or ▼ key to select FINISH, and then press the **Select** key.



*To add an additional e-mail address, select ADD in step 4, and then specify the destination. When sending the data to an FTP address or SMB address, multiple addresses cannot be specified. To edit the specified e-mail address, select CHECK/EDIT in step 4, and then continue with step 2 of "Editing a Specified Destination Address". To delete an address, select CHECK/EDIT in step 4, and then continue with step 2 of "Deleting a Specified Destination Address".*

## Selecting a Group Dial Destination

A maximum of 20 group dial destinations can be registered on this machine. (A maximum of 50 e-mail addresses can be registered with one group.) Follow the procedure described below to specify e-mail addresses from the registered group dial destinations as the recipient of the scan data.



*For details on registering e-mail addresses as group dial destinations, refer to "Registering Group Dial Destinations" on page 144.*



*A group dial destination containing a telephone number cannot be used in Scan mode.*

- 1 With the main screen or Can Use AddressBook displayed, press the **AddressBook** key three times so that Group DIAL appears.
- 2 Use the keypad to type in the number (between 1 and 20) for the group dial destination, and then press the **Select** key.  
The information registered for the group dial destination appears for two seconds.
- 3 Press the **Select** key again.
- 4 Press the ▲ or ▼ key to select FINISH, and then press the **Select** key.



*To add an additional e-mail address, select ADD in step 4, and then specify the destination. To edit the specified e-mail address, select CHECK/EDIT in step 4, and then continue with step 2 of "Editing a Specified Destination Address". To delete an address, select CHECK/EDIT in step 4, and then continue with step 2 of "Deleting a Specified Destination Address".*

## Selecting From the Address Book

The speed dial destinations and group dial destinations registered on this machine are saved in the address book. Follow the procedure described below to specify an address (e-mail, FTP or SMB address) from the address book as the recipient of the scan data.



*This feature is available only if data has been registered in the address book.*

- 1 With the main screen or **Can Use AddressBook** displayed, press the **AddressBook** key four times so that **PHONE BOOK** appears.
- 2 Press the **▲** or **▼** key to select **LIST**, and then press the **Select** key. A list of the address book contents appears.
- 3 Press the **▲** or **▼** key to select the desired data, and then press the **Select** key.
- 4 Press the **Select** key again. If an FTP address or an SMB address was selected, the destination address is specified.
- 5 If an e-mail address was selected, press the **▲** or **▼** key to select **FINISH**, and then press the **Select** key.



*To add an additional e-mail address, select **ADD** in step 5, and then specify the destination. When sending the data to an FTP address or SMB address, multiple addresses cannot be specified. To edit the specified e-mail address, select **CHECK/EDIT** in step 5, and then continue with step 2 of "Editing a Specified Destination Address". To delete an address, select **CHECK/EDIT** in step 5, and then continue with step 2 of "Deleting a Specified Destination Address".*

## Searching the Address Book

The destination address (e-mail, FTP or SMB address) where the scan data is to be sent can be specified by searching the address book.



*This feature is available only if data has been registered in the address book.*

- 1 With the main screen or **Can Use AddressBook** displayed, press the **AddressBook** key four times so that **PHONE BOOK** appears.
- 2 Press the **▲** or **▼** key to select **SEARCH**, and then press the **Select** key. A list of the address book contents appears.
- 3 Use the keypad to type in the search keyword (maximum of 10 characters), and then press the **Select** key.

The search begins, and the search results appear after a while. If no data matches the search keyword, **NOT FOUND** appears for about two seconds.



*For details on entering/editing text, refer to "Entering Text" on page 265.*



*Text starting with the first character of the maximum 10 characters is searched for. Text will not be found if the search keyword is in the middle of a word.*

- 4 Press the **▲** or **▼** key to select the desired data, and then press the **Select** key.
- 5 Press the **Select** key again.  
If an FTP address or an SMB address was selected, the destination address is specified.
- 6 If an e-mail address was selected, press the **▲** or **▼** key to select **FINISH**, and then press the **Select** key.



*To add an additional e-mail address, select **ADD** in step 6, and then specify the destination. When sending the data to an FTP address or SMB address, multiple addresses cannot be specified. To edit the specified e-mail address, select **CHECK/EDIT** in step 6, and then continue with step 2 of "Editing a Specified Destination Address". To delete an address, select **CHECK/EDIT** in step 6, and then continue with step 2 of "Deleting a Specified Destination Address".*

## Searching an LDAP Server

The destination e-mail address where the scan data is to be sent can be specified by using information on the LDAP server.



*To connect to an LDAP server, settings for **LDAP SETTING** must be specified. For details, refer to the Reference Guide on the Documentation CD/DVD.*



*A maximum of 16 addresses (total of addresses from direct input and an LDAP search) can be specified.*

- 1 With the main screen or **Can Use AddressBook** displayed, press the **AddressBook** key four times so that **PHONE BOOK** appears.
- 2 Press the **▲** or **▼** key to select **LDAP SEARCH**, and then press the **Select** key.
- 3 Press the **▲** or **▼** key to select **NAME** or **E-MAIL**, and then press the **Select** key.



To search registered names, select **NAME**. To search e-mail addresses, select **E-MAIL**.

- 4 Use the keypad to type in the search keyword (maximum of 10 characters), and then press the **Select** key.

The search begins, and the search results appear after a while. If no data matches the search keyword, **NOT FOUND** appears for about two seconds.



For details on entering/editing text, refer to "Entering Text" on page 265.



Text starting with the first character of the maximum 10 characters is searched for. Text will not be found if the search keyword is in the middle of a word.

- 5 Press the **▲** or **▼** key to select the desired data, and then press the **Select** key.



To check the found information, press the **▶** key.



An e-mail address exceeding 64 characters cannot be specified. If such an e-mail address is specified, **ADDRESS IS TOO LONG** appears for about two seconds, and then the screen for specifying the destination address appears.

- 6 Press the **Select** key again.

- 7 Press the **▲** or **▼** key to select **FINISH**, and then press the **Select** key.



To add an additional e-mail address, select **ADD** in step 7, and then specify the destination.

To delete a specified e-mail address, select **CHECK/EDIT** in step 7, and then continue with step 2 of "Deleting a Specified Destination Address". The address cannot be edited.

## Specifying Multiple Destination Addresses

A destination address can be added if a destination e-mail address is specified.



If an **FTP** address or an **SMB** address was selected, multiple destination addresses cannot be specified.

- 1 In the main screen, press the **▲** or **▼** key to select the current data destination setting, and then press the **Select** key.
- 2 Press the **▲** or **▼** key to select **ADD**, and then press the **Select** key.
- 3 Specify the destination address.



*For details on typing in an e-mail address, refer to “Directly Entering the E-mail Address” on page 132.*

*For details on selecting from the favorite list, refer to “Selecting From the Favorite List” on page 133.*

*For details on selecting a speed dial destination, refer to “Selecting a Speed Dial Destination” on page 133.*

*For details on selecting a group dial destination, refer to “Selecting a Group Dial Destination” on page 134.*

*For details on selecting from the address book, refer to “Selecting From the Address Book” on page 135.*

*For details on searching the address book, refer to “Searching the Address Book” on page 135.*

*For details on searching an LDAP server, refer to “Searching an LDAP Server” on page 136.*

## Editing a Specified Destination Address

A specified destination e-mail address can be edited.



*FTP addresses, SMB addresses and e-mail addresses specified by searching an LDAP server cannot be edited.*



*Changes made with this procedure will not be applied to the original data (speed dial destination, group dial destination, etc.).*

- 1 In the main screen, press the ▲ or ▼ key to select the current data destination setting, and then press the **Select** key.
- 2 Press the ▲ or ▼ key to select CHECK/EDIT, and then press the **Select** key.
- 3 Press the ▲ or ▼ key to select the e-mail address to be edited, and then press the **Select** key.
- 4 Use the keypad to edit the e-mail address, and then press the **Select** key.



*For details on entering/editing text, refer to “Entering Text” on page 265.*

- 5 Press the ▲ or ▼ key to select FINISH, and then press the **Select** key.

## Deleting a Specified Destination Address

A specified destination address (e-mail, FTP or SMB address) can be deleted.



*Changes made with this procedure will not be applied to the original data (speed dial destination, group dial destination, etc.).*

- 1 In the main screen, press the ▲ or ▼ key to select the current data destination setting, and then press the **Select** key.
- 2 To delete an e-mail address, press the ▲ or ▼ key to select CHECK/EDIT, and then press the **Select** key. Then, press the ▲ or ▼ key to select the address to be deleted. To delete an FTP address or SMB address, continue with step 3.
- 3 Press the **Stop/Reset** key.
- 4 Press the ▲ or ▼ key to select YES, and then press the **Select** key. The selected address is deleted.
- 5 To delete another address, repeat the procedure from step 2.
- 6 To finish deleting addresses, press the **Back** key.
- 7 Press the ▲ or ▼ key to select FINISH, and then press the **Select** key.

## Registering/Editing Addresses

Addresses can be registered/edited in the favorite list, as speed dial destinations or as group dial destinations.



*Addresses can also be registered/edited with PageScope Web Connection or with LSU (Local Setup Utility) on the enclosed Applications CD/DVD. For details, refer to the Reference Guide on the Documentation CD/DVD.*



*The same settings menu used to register/edit fax numbers is used to register/edit addresses. For details on registering/editing fax numbers, refer to the Facsimile User's Guide on the Documentation CD/DVD.*

## Registering in the Favorite List

From the speed dial destinations and group dial destinations registered on this machine, register a maximum of 20 destinations in the favorite list for convenient access to frequently specified destinations. Follow the procedure described below to register an address (e-mail, FTP or SMB address) on the favorite list.

- 1 In the main screen, press the ▲ or ▼ key to select UTILITY, and then press the **Select** key.
- 2 Press the ▲ or ▼ key to select DIAL REGISTER, and then press the **Select** key.
- 3 Press the ▲ or ▼ key to select FAVORITE, and then press the **Select** key.



*If data is already registered on the favorite list, continue with step 6 after completing step 3.*

- 4 Press the **AddressBook** key to switch between **SPEED DIAL** and **GROUP DIAL**.
- 5 Use the keypad to type in the number (between 1 and 250) for the speed dial destination or the number (between 1 and 20) for the group dial destination to be registered on the favorite list, and then press the **Select** key. The information registered for the selected speed dial destination or group dial destination appears.
- 6 To register another address, press the **▲** or **▼** key to select **ADD**, press the **Select** key, and then repeat the procedure from step 4.
- 7 To finish registering addresses, press the **▲** or **▼** key to select **FINISH**, and then press the **Select** key.

## Deleting From the Favorite List

Registered information can be deleted from the favorite list.



*Changes made with this procedure will not be applied to the original data (speed dial destination, group dial destination, etc.).*

- 1 In the main screen, press the **▲** or **▼** key to select **UTILITY**, and then press the **Select** key.
- 2 Press the **▲** or **▼** key to select **DIAL REGISTER**, and then press the **Select** key.
- 3 Press the **▲** or **▼** key to select **FAVORITE**, and then press the **Select** key.
- 4 Press the **▲** or **▼** key to select **CHECK/EDIT**, and then press the **Select** key.
- 5 Press the **▲** or **▼** key to select the address to be deleted from the favorite list, and then press the **Stop/Reset** key.
- 6 Press the **▲** or **▼** key to select **YES**. The selected address is deleted.
- 7 To delete another address, repeat the procedure from step 5.
- 8 To finish deleting addresses, press the **Back** key.
- 9 Press the **▲** or **▼** key to select **FINISH**, and then press the **Select** key.

## Registering Speed Dial Destinations (Direct Input)

E-mail addresses can be registered as speed dial destinations. A maximum of 250 speed dial destinations can be registered.



Machine key operations cannot be used to register an FTP address or SMB address as a speed dial destination. These addresses can be registered with PageScope Web Connection. For details, refer to the Reference Guide on the Documentation CD/DVD.



Speed dial destination numbers 221 to 250 are reserved for registering FTP addresses and SMB address from PageScope Web Connection.

- 1 In the main screen, press the ▲ or ▼ key to select **UTILITY**, and then press the **Select** key.
- 2 Press the ▲ or ▼ key to select **DIAL REGISTER**, and then press the **Select** key.
- 3 Press the ▲ or ▼ key to select **SPEED DIAL**, and then press the **Select** key.
- 4 Use the keypad to type in the number (between 1 and 220) for the speed dial destination, and then press the **Select** key.
- 5 Press the ▲ or ▼ key to select **MANUAL SETTING**, and then press the **Select** key.



If an LDAP server is not specified, step 5 is skipped.

- 6 Use the keypad to type in the registration name, and then press the **Select** key.



For details on entering/editing text, refer to “Entering Text” on page 265.



A maximum of 20 characters can be entered.

- 7 Use the keypad to type in the e-mail address, and then press the **Select** key.  
The settings are registered, and the **DIAL REGISTER** menu appears again.



A maximum of 64 characters can be entered.

## Registering Speed Dial Destinations (LDAP Search)

E-mail addresses can be registered as speed dial destinations by using information on the LDAP server. A maximum of 250 speed dial destinations can be registered.



*To connect to an LDAP server, settings for `LDAP SETTING` must be specified. For details, refer to the Reference Guide on the Documentation CD/DVD.*



*Machine key operations cannot be used to register an FTP address or SMB address as a speed dial destination. These addresses can be registered with PageScope Web Connection. For details, refer to the Reference Guide on the Documentation CD/DVD.*



*Speed dial destination numbers 221 to 250 are reserved for registering FTP addresses and SMB address from PageScope Web Connection.*

- 1 In the main screen, press the **▲** or **▼** key to select `UTILITY`, and then press the **Select** key.
- 2 Press the **▲** or **▼** key to select `DIAL REGISTER`, and then press the **Select** key.
- 3 Press the **▲** or **▼** key to select `SPEED DIAL`, and then press the **Select** key.
- 4 Use the keypad to type in the number (between 1 and 220) for the speed dial destination, and then press the **Select** key.
- 5 Press the **▲** or **▼** key to select `LDAP SEARCH`, and then press the **Select** key.



*If an LDAP server is not specified, `LDAP SEARCH` does not appear.*

- 6 Press the **▲** or **▼** key to select `NAME` or `E-MAIL`, and then press the **Select** key.



*To search registered names, select `NAME`. To search e-mail addresses, select `E-MAIL`.*

- 7 Use the keypad to type in the search keyword (maximum of 10 characters), and then press the **Select** key.  
The search begins, and the search results appear after a while. If no data matches the search keyword, `NOT FOUND` appears for about two seconds.



*For details on entering/editing text, refer to "Entering Text" on page 265.*



*Text starting with the first character of the maximum 10 characters is searched for. Text will not be found if the search keyword is in the middle of a word.*

- 8 Press the ▲ or ▼ key to select the desired data, and then press the **Select** key.



*To check the found information, press the ► key.*



*An e-mail address exceeding 64 characters cannot be specified. If such an e-mail address is specified, ADDRESS IS TOO LONG appears for about two seconds, and then the screen for specifying the destination address appears.*

- 9 If desired, edit the registration name, and then press the **Select** key.
- 10 If desired, edit the e-mail address, and then press the **Select** key.  
The settings are registered, and the DIAL REGISTER menu appears again.

## Editing/Deleting Speed Dial Destinations

Information registered as a speed dial destination can be edited or deleted.



*Machine key operations cannot be used to edit/delete an FTP address or SMB address registered as a speed dial destination. These addresses can be edited/deleted with PageScope Web Connection. For details, refer to the Reference Guide on the Documentation CD/DVD.*

- 1 In the main screen, press the ▲ or ▼ key to select UTILITY, and then press the **Select** key.
- 2 Press the ▲ or ▼ key to select DIAL REGISTER, and then press the **Select** key.
- 3 Press the ▲ or ▼ key to select SPEED DIAL, and then press the **Select** key.
- 4 Use the keypad to type in the number (between 1 and 220) for the speed dial destination to be edited/deleted, and then press the **Select** key.  
The information currently registered for the speed dial destination appears for two seconds.
- 5 Press the ▲ or ▼ key to select EDIT to edit information or DELETE to delete the destination, and then press the **Select** key.  
If DELETE was selected, the settings are deleted, and the DIAL REGISTER menu appears again.
- 6 Use the keypad to edit the registration name, and then press the **Select** key.



For details on entering/editing text, refer to “Entering Text” on page 265.

- 7 Use the keypad to edit the e-mail address, and then press the **Select** key. The edited settings are saved, and the DIAL REGISTER menu appears again.



If the edited speed dial destination is registered in the favorite list or with a group dial destination, a confirmation message asking whether or not to keep the destination registered as it is appears after the operation in step 7 is performed. To keep the destination registered as it is, select **Yes**. To cancel the registration, select **No**.

## Registering Group Dial Destinations

An e-mail address can be registered with a group dial destination. A maximum of 20 group dial destinations can be registered. (A maximum of 50 e-mail addresses can be registered with one group.)

- 1 In the main screen, press the ▲ or ▼ key to select UTILITY, and then press the **Select** key.
- 2 Press the ▲ or ▼ key to select DIAL REGISTER, and then press the **Select** key.
- 3 Press the ▲ or ▼ key to select GROUP DIAL, and then press the **Select** key.
- 4 Use the keypad to type in the number (between 1 and 20) for the group dial destination, and then press the **Select** key.
- 5 Use the keypad to type in the group name, and then press the **Select** key.



For details on entering/editing text, refer to “Entering Text” on page 265.

- 6 Use the keypad to type in the number (between 1 and 220) for the speed dial destination to be added to the group, and then press the **Select** key. The information registered for the selected speed dial destination appears.
- 7 Press the **Select** key again.
- 8 To register another speed dial destination, press the ▲ or ▼ key to select ADD, press the **Select** key, and then repeat the procedure from step 4.
- 9 To finish registering speed dial destinations, press the ▲ or ▼ key to select FINISH, and then press the **Select** key.

## Editing/Deleting Group Dial Destinations

Information registered with a group dial destination can be edited or deleted.

- 1 In the main screen, press the ▲ or ▼ key to select **UTILITY**, and then press the **Select** key.
- 2 Press the ▲ or ▼ key to select **DIAL REGISTER**, and then press the **Select** key.
- 3 Press the ▲ or ▼ key to select **GROUP DIAL**, and then press the **Select** key.
- 4 Use the keypad to type in the number (between 1 and 20) for the group dial destination to be edited/deleted, and then press the **Select** key.  
The information currently registered for the group dial destination appears for about two seconds.
- 5 Press the ▲ or ▼ key to select **EDIT** to edit information or **DELETE** to delete the destination, and then press the **Select** key.  
If **DELETE** was selected, the settings are deleted, and the **DIAL REGISTER** menu appears again.
- 6 If desired, edit the group name, and then press the **Select** key.  
 *For details on entering/editing text, refer to “Entering Text” on page 265.*
- 7 Press the ▲ or ▼ key to select **ADD** to add a speed dial destination, **CHECK/EDIT** to delete the destination or **FINISH** to finish editing, and then press the **Select** key.  
If **FINISH** was selected, the edited settings are saved, and the **DIAL REGISTER** menu appears again. If **ADD** was selected, continue with step 6 of “Registering Group Dial Destinations” on page 144. If **CHECK/EDIT** was selected, continue with step 8.
- 8 Press the ▲ or ▼ key to select the speed dial destination to be deleted, and then press the **Stop/Reset** key.  
 *To check the settings for the selected speed dial destination, press the **Select** key.*
- 9 Press the ▲ or ▼ key to select **Yes**, and then press the **Select** key.
- 10 After the speed dial destination is deleted, press the **Back** key.
- 11 To delete another speed dial destination, repeat the procedure from step 7.
- 12 To finish deleting speed dial destinations, press the ▲ or ▼ key to select **FINISH**, and then press the **Select** key.



If the edited group dial destination is registered in the favorite list, a confirmation message asking whether or not to keep the destination registered as it is appears after the operation in step 12 is performed. To keep the destination registered as it is, select *Yes*. To cancel the registration, select *No*.

## Selecting the Data Format

The data format for the scanned image can be selected.

- 1 In the main screen, press the ▲ or ▼ key to select the current data format setting, and then press the **Select** key.
- 2 Press the ▲ or ▼ key to select TIFF, PDF or JPEG, and then press the **Select** key.  
The main screen appears again.



If *SIMPLEX/DUPLEX* is set to *2-SIDE*, only *PDF* appears. In addition, if *BW ONLY* was selected for the color setting, *JPEG* does not appear.



*PDF* data can be opened in *Adobe Acrobat Reader*.



*TIFF* files of images that have been scanned with the *Color* or *Gray* setting cannot be opened with the *Windows Picture and FAX Viewer*, which is included with *Windows XP* as a standard component. These files can be opened with image-processing applications such as *PhotoShop*, *Microsoft Office Document Imaging* or *ACDsee*.

## Selecting the Scan Quality Setting

The resolution, scan mode and density appropriate for the scanned image can be selected.

### Selecting the Resolution

- 1 In the main screen, press the ▲ or ▼ key to select the current scan quality setting, and then press the **Select** key.
- 2 Press the ▲ or ▼ key to select **RESOLUTION**, and then press the **Select** key.
- 3 Press the ▲ or ▼ key to select **150x150dpi**, **300x300dpi** or **600x600dpi**, and then press the **Select** key.  
The main screen appears again.

## Selecting the Scan Mode



*These settings are available only if BW Only was selected for the color setting.*

- 1 In the main screen, press the ▲ or ▼ key to select the current scan quality setting, and then press the **Select** key.
- 2 Press the ▲ or ▼ key to select MODE, and then press the **Select** key.
- 3 Press the ▲ or ▼ key to select MIX, TEXT or PHOTO, and then press the **Select** key.  
The main screen appears again.

## Selecting the Scan Density

- 1 In the main screen, press the ▲ or ▼ key to select the current scan quality setting, and then press the **Select** key.
- 2 Press the ▲ or ▼ key to select DENSITY, and then press the **Select** key.
- 3 Press the ◀ or ▶ key to select the desired scan density.  
As the indicator is moved to right, the density becomes darker.

## Setting Duplex (Double-Sided) Scanning

Double-sided document pages can be scanned with the ADF.



*These settings are available only if the document is loaded in the ADF. If the document is scanned without being loaded in the ADF, 1 - SIDE is automatically selected, and the document is scanned from the original glass.*



*This setting is available only if PDF is selected as the data format for the scan image.*

- 1 In the main screen, press the ▲ or ▼ key to select the current simplex/ duplex (single-sided/double-sided) setting, and then press the **Select** key.
- 2 Press the ▲ or ▼ key to select 2 - SIDE, and then press the **Select** key.
- 3 Press the ▲ or ▼ key to select LONG EDGE or SHORT EDGE, and then press the **Select** key.  
The main screen appears again.



*For details on LONG EDGE and SHORT EDGE, refer to “Duplex (Double-Sided) Copying From the ADF” on page 117.*

## Setting the Scan Size

The size of the scan data can be specified.



*The default setting is LETTER for USA and Canada, and A4 for other countries.*

- 1 In the main screen, press the ▲ or ▼ key to select the current scan size setting, and then press the **Select** key.
- 2 Press the ▲ or ▼ key to select the desired size, and then press the **Select** key.  
The main screen appears again.

## Setting the Scan Color

The color of the scan data can be specified.

- 1 In the main screen, press the ▲ or ▼ key to select the current scan color setting, and then press the **Select** key.
- 2 Press the ▲ or ▼ key to select BW Only or COLOR or GRAY, and then press the **Select** key.  
The main screen appears again.



*If JPEG is selected as the data format, the scan color is set to BW Only, and the data format is automatically set to PDF.*



*The SCAN SETUP/CODING METHOD setting is automatically changed according to the specified scan color setting.*

## Specifying the Subject

Specify the subject used when sending scan data via the network.

- 1 In the main screen, press the ▲ or ▼ key to select SUBJECT, and then press the **Select** key.
- 2 Use the keypad to type in the subject name, and then press the **Select** key.  
The main screen appears again.



*To erase the specified subject name, press the **Back** key.*

## Deleting a Queued Transmission Job

The list of jobs queued for transmission can be displayed, and a job can be deleted.

- 1 In the main screen, press the ▲ or ▼ key to select CANCEL RESERV., and then press the **Select** key.

- 2 Press the ▲ or ▼ key to select the job to be deleted, and then press the **Select** key.
  -  *To check the information for the selected job, press the ► key.*
  -  *If no jobs are queued for transmission, **NONE** appears.*
- 3 Press the ▲ or ▼ key to select **YES**, and then press the **Select** key.  
The main screen appears again.



---

***Replacing  
Consumables***

---

**7**

# Replacing Consumables

---

---

## Note

Failure to follow instructions as outlined in this manual could result in voiding your warranty.

---

---

---

---

## Note

If an error message (Toner Empty, Trans. Belt Life, etc.) appears, print out the configuration page, and then check the status of the other consumables. For details on the error messages, refer to “Error Messages” on page 243. For details on printing the configuration page, refer to “Printing a Configuration Page” on page 201.

---

---

## About Toner Cartridges

Your machine uses four toner cartridges: black, yellow, magenta, and cyan. Handle the toner cartridges carefully to avoid spilling toner inside the machine or on yourself.



*Install only new toner cartridges in your machine. If a used toner cartridge is installed, the indicator message will not clear and the supplies status in the Status Monitor will not be updated.*



*The toner is nontoxic. If you get toner on your skin, wash it off with cool water and a mild soap. If you get toner on your clothes, lightly dust them off as best as you can. If some toner remains on your clothes, use cool, not hot water, to rinse the toner off.*



## CAUTION

**If you get toner in your eyes, wash it out immediately with cool water and consult a doctor.**

---

---



*Refer to the following URL for recycling information.  
US: [printer.konicaminolta.net/products/recycle/index.asp](http://printer.konicaminolta.net/products/recycle/index.asp)  
Europe: [cleanplanet-printer.konicaminoltaeurope.com/cleanplanet/choose.php](http://cleanplanet-printer.konicaminoltaeurope.com/cleanplanet/choose.php)  
Other regions: [printer.konicaminolta.com](http://printer.konicaminolta.com)*

## Note

**Do not use refilled toner cartridges or unapproved toner cartridges. Any damage to the machine or quality problems caused by a refilled toner cartridge or an unapproved toner cartridge will void your warranty. No technical support is provided to recover from these problems.**

When replacing a toner cartridge, refer to the following table. For optimum print quality and performance, use only approved KONICA MINOLTA toner cartridges for your specific machine type, as listed in the table below. You can find your machine type and the toner cartridge part numbers on the consumables reorder label inside the front cover your machine.

Machine Type	Machine Parts Number	Toner Cartridge Type	Toner Cartridge Parts Number
AM	A0FD 011	Standard-Capacity Toner Cartridge -Black (K)	A0DK 131
		Standard-Capacity Toner Cartridge -Yellow (Y)	A0DK 231
		Standard-Capacity Toner Cartridge -Magenta (M)	A0DK 331
		Standard-Capacity Toner Cartridge -Cyan (C)	A0DK 431
		High-Capacity Toner Cartridge -Black (K)	A0DK 132
		High-Capacity Toner Cartridge -Yellow (Y)	A0DK 232
		High-Capacity Toner Cartridge -Magenta (M)	A0DK 332
		High-Capacity Toner Cartridge -Cyan (C)	A0DK 432
EU	A0FD 021	Standard-Capacity Toner Cartridge -Yellow (Y)	A0DK 251
		Standard-Capacity Toner Cartridge -Magenta (M)	A0DK 351
		Standard-Capacity Toner Cartridge -Cyan (C)	A0DK 451
		High-Capacity Toner Cartridge -Black (K)	A0DK 152
		High-Capacity Toner Cartridge -Yellow (Y)	A0DK 252
		High-Capacity Toner Cartridge -Magenta (M)	A0DK 352
AP	A0FD 041	High-Capacity Toner Cartridge -Cyan (C)	A0DK 452
		Standard-Capacity Toner Cartridge -Yellow (Y)	A0DK 291
		Standard-Capacity Toner Cartridge -Magenta (M)	A0DK 391
		Standard-Capacity Toner Cartridge -Cyan (C)	A0DK 491
		High-Capacity Toner Cartridge -Black (K)	A0DK 192
		High-Capacity Toner Cartridge -Yellow (Y)	A0DK 292
		High-Capacity Toner Cartridge -Magenta (M)	A0DK 392
AU	A0FD 051	High-Capacity Toner Cartridge -Cyan (C)	A0DK 492
		Standard-Capacity Toner Cartridge -Yellow (Y)	A0DK 291
		Standard-Capacity Toner Cartridge -Magenta (M)	A0DK 391
		Standard-Capacity Toner Cartridge -Cyan (C)	A0DK 491
		High-Capacity Toner Cartridge -Black (K)	A0DK 192
		High-Capacity Toner Cartridge -Yellow (Y)	A0DK 292
		High-Capacity Toner Cartridge -Magenta (M)	A0DK 392
		High-Capacity Toner Cartridge -Cyan (C)	A0DK 492

Machine Type	Machine Parts Number	Toner Cartridge Type	Toner Cartridge Parts Number
GC	A0FD 081	Standard-Capacity Toner Cartridge -Yellow (Y)	A0DK 281
		Standard-Capacity Toner Cartridge -Magenta (M)	A0DK 381
		Standard-Capacity Toner Cartridge -Cyan (C)	A0DK 481
		High-Capacity Toner Cartridge -Black (K)	A0DK 182
		High-Capacity Toner Cartridge -Yellow (Y)	A0DK 282
		High-Capacity Toner Cartridge -Magenta (M)	A0DK 382
		High-Capacity Toner Cartridge -Cyan (C)	A0DK 482




*For optimum print quality and performance, use only the corresponding TYPE genuine KONICA MINOLTA toner cartridges.*

Keep toner cartridges:

- In their packaging until you're ready to install them.
- In a cool, dry location away from sunlight (due to heat).
- The maximum storage temperature is 35°C (95°F) and the maximum storage humidity is 85% (noncondensing). If the toner cartridge is moved from a cold place to a warm, humid place, condensation may occur, degrading print quality. Allow the toner to adapt to the environment for about one hour before use.
- Level during handling and storage.

*Do not hold, stand or store cartridges on their ends or turn them upside down; the toner inside the cartridges may become caked or unequally distributed.*



- Away from salty air and corrosive gases such as aerosols.

## Replacing a Toner Cartridge

### Note


---

**Be careful not to spill toner while replacing a toner cartridge. If toner spills, immediately wipe it off with a soft, dry cloth.**

---

If MACHINE SETTING/TONER EMPTY in the UTILITY menu is set to STOP, the message TONER EMPTY/CHANGE X TONER (where "X" indicates the color of the toner) appears when the toner cartridge is nearly empty. Follow the steps below to replace the toner cartridge.


- 1 Open the machine's front cover.




- 2 Pull the front lever of the color toner cartridge indicated to the right.

The replacement procedure for the toner cartridge is the same for all colors (yellow: Y, magenta: M, cyan: C, and black: K).

The following instructions show the procedure to replace the toner cartridge (Y).




- 3 Lower the lever to release the lock.



- 4 Grab the handle of the toner cartridge to be replaced, and then pull out the cartridge.

The following instructions show the procedure to replace the toner cartridge(Y).



---

### Note


---

**Dispose of the used toner cartridge according to your local regulations. Do not burn the toner cartridge. For details, refer to “About Toner Cartridges” on page 152.**


---

- 5 Check the color of the new toner cartridge to be installed.
- 6 Remove the toner cartridge from the bag.


- 7 Shake the cartridge to distribute the toner.




- 8 Make sure that the toner cartridge is the same color as the machine compartment, and then insert the toner cartridge into the machine.



- 9 Make sure that the toner cartridge is securely installed, and then peel off the protective film.




- 10 Raise the front lever to its original position.




- 11 Pull the lever to the left to lock it in place.



*The front lever should be securely returned to its original position; otherwise, the front cover of the machine cannot be closed.*



- 12 Close the front cover.



## Replacing an Imaging Unit


When replacing an imaging unit, refer to the following table. For optimum print quality and performance, use only approved KONICA MINOLTA imaging units for your specific machine type, as listed in the table below. You can find your machine type and the imaging unit part numbers on the consumables reorder label inside the front cover your machine.

Machine Type	Machine Parts Number	Imaging Unit Type	Imaging Unit Parts Number
AM	A0FD 011	Imaging Unit -Black (K)	A031 00F
		Imaging Unit -Yellow (Y)	A031 05F
		Imaging Unit -Magenta (M)	A031 0AF
		Imaging Unit -Cyan (C)	A031 0GF
EU	A0FD 021	Imaging Unit -Black (K)	A031 00H
		Imaging Unit -Yellow (Y)	A031 05H
		Imaging Unit -Magenta (M)	A031 0AH
		Imaging Unit -Cyan (C)	A031 0GH
AP	A0FD 041	Imaging Unit -Black (K)	A031 00H
		Imaging Unit -Yellow (Y)	A031 05H
		Imaging Unit -Magenta (M)	A031 0AH
		Imaging Unit -Cyan (C)	A031 0GH
AU	A0FD 051	Imaging Unit -Black (K)	A031 00H
		Imaging Unit -Yellow (Y)	A031 05H
		Imaging Unit -Magenta (M)	A031 0AH
		Imaging Unit -Cyan (C)	A031 0GH
GC	A0FD 081	Imaging Unit -Black (K)	A031 00N
		Imaging Unit -Yellow (Y)	A031 05N
		Imaging Unit -Magenta (M)	A031 0AN
		Imaging Unit -Cyan (C)	A031 0GN

## Note


---

Do not touch the OPC drum surface. This could lower image quality.



You are advised to replace the indicated imaging unit when the message *I-UNIT END/REPLACE X* appears.


- 1 Check the message window to see which color imaging unit needs replacing.
- 2 Open the machine's front cover.




- 3** Pull the front lever of the color toner cartridge indicated to the right.

The replacement procedure for the imaging unit is the same for all colors (yellow: Y, magenta: M, cyan: C, and black: K).

The following instructions show the procedure to replace the toner cartridge (K).




- 4** Lower the lever to release the lock.



- 5** Press down the area marked "Push" on the imaging unit to be replaced, and then slide the unit all the way out of the machine.

The following instructions show the procedure to replace the imaging unit (K).



## Note


**Dispose of the used imaging unit according to your local regulations. Do not burn the imaging unit.**

- 6 Check the color of the new imaging unit to be installed.



*In order to prevent toner from spilling, leave the imaging unit in the bag until step 5 is being performed.*



- 7 Remove the imaging unit from the bag.




- 8 Hold the imaging unit with both hands, and then shake it twice as shown in the illustration.




*Do not grab the bottom of the bag; otherwise, the imaging unit may be damaged, resulting in decreased print quality.*




- 9 Remove all packing tape from the imaging unit.




- 10 Remove the protective cover from the imaging unit. The protective cover slides after having turned.



- 11 Make sure that the new imaging unit to be installed is the same color as the machine compartment, and then install the imaging unit in the machine.




- 12 Raise the front lever to its original position.




- 13 Pull the lever to the left to lock it in place.



*The front lever should be securely returned to its original position; otherwise, the front cover of the machine cannot be closed.*




- 14 Close the front cover.




## Replacing the Waste Toner Bottle

When the waste toner bottle becomes full, the message **WASTE TONER FULL/REPLACE BOTTLE** appears in the message window. The machine stops and will not start again until the waste toner bottle is replaced.


- 1 Open the machine's front cover.



- 2 Turn the dial on the waste toner bottle counterclockwise until it is in the unlock position.




- 3 Open the left and right handles of the waste toner bottle.



- 4 Grab the left and right handles of the waste toner bottle, and then slowly pull out the bottle.



*Be careful since some waste toner may spill if the lock is closed when the waste toner bottle is removed.*



- 5 Remove the new waste toner bottle from its packaging. Insert the used waste toner bottle into the plastic bag included in the box, and then box it up.

---

### Note

---


**Dispose of the used waste toner bottle according to your local regulations. Do not burn the waste toner bottle.**

---




*Before installing the waste toner bottle, be sure that the dial on the waste toner bottle is unlocked.*


- 6 Slide the waste toner bottle all the way into the machine.



- 7 Turn the dial clockwise until the waste toner bottle is in the locked position.



8 Close the front cover.



*If the waste toner bottle is not fully inserted or if the dial is not locked, the front cover cannot be closed.*

## Replacing the Transfer Roller

When the time to replace the transfer roller is reached, the message **Trans. Roll. Life** appears. Printing can continue even after this message appears; however, since the print quality is reduced, the transfer roller should be replaced immediately.


When replacing the transfer roller, also replace the ozone filter. A new ozone filter is included with the new transfer roller.

### Replacing the Transfer Roller


- 1 Pull the lever, and then open the right side cover.






*Before opening the right side cover, fold up Tray 1.*



- 2 Move the lever toward you.




**3** Remove the transfer roller.




**4** Prepare a new transfer roller.


- 5 Insert the shaft of the transfer roller into the bearings.



- 6 Move the levers away from you until it snaps into place.




- 7 Close the right side cover.




- 8 Reset the counter with ADMIN . MANAGEMENT/SUPPLIES REPLACE/TRANSFER ROLLER in the UTILITY menu.
- 9 Replace the ozone filter, using the following procedure.

## Replacing the Ozone Filter

- 1 Remove the ozone filter from the machine.




- 2 Slide the new ozone filter into the machine until it snaps into place.



## Replacing the Transfer Belt Unit

When the time to replace the transfer belt unit is reached, the message *Trans. Belt Life* appears. Printing can continue even after this message appears; however, since the print quality is reduced, the transfer belt unit should be replaced immediately.


- 1 Turn off the machine and disconnect the power cord and interface cover.




- 2 Pull the lever, and then open the right side cover.




*Before opening the right side cover, fold up Tray 1.*



- 3 Use a coin to loosen the screws securing the transfer belt unit.




- 4 Open the machine's front cover.



- 5 Remove the waste toner bottle.




*For details on removing the waste toner bottle, refer to "Replacing the Waste Toner Bottle" on page 165.*




## 6 Remove the all imaging units.

 For details on removing the imaging unit, refer to “Replacing an Imaging Unit” on page 159.


 Cover the removed imaging unit to protect it from direct sunlight.



## 7 Remove the output tray.




- 8 Open the left side cover.




- 9 On the left side, pull to the right the blue shutter lever for the transfer belt unit.



*Do not remove the blue lever.*




- 10 Hold the arm, and then carefully pull out the transfer belt unit.




**11** Prepare a new transfer belt unit.

 *Be careful not to touch the surface of the belt.*


 *Do not remove the blue lever.*




**12** Remove all packing tape from the new transfer belt unit.




**13** Remove the protective cover from the new transfer belt unit.




**14** Insert the new transfer belt unit along the rails.




**15** Close the left-side cover.




**16** Install the output tray.



**17** From the right side cover side, tighten the screws to secure the transfer belt unit.





18 Close the right side cover.



19 Install the all imaging units.




*For details on installing the imaging unit, refer to “Replacing an Imaging Unit” on page 159.*




**20** Install the waste toner bottle.


 For details on installing the waste toner bottle, refer to “Replacing the Waste Toner Bottle” on page 165.



**21** Close the front cover.



**22** Reconnect the power cord, and turn on the machine.




**23** Reset the counter with ADMIN. MANAGEMENT/SUPPLIES REPLACE/TRANSFER BELT in the UTILITY menu.

## Replacing the Fuser Unit

When the time to replace the fuser unit is reached, the message **Fuser Unit Life** appears. Printing can continue even after this message appears; however, since the print quality is reduced, the fuser unit should be replaced immediately.

- 1 Turn off the machine and disconnect the power cord and interface cover.




---

### Note


There are extremely hot parts within the machine. Before replacing the fuser unit, wait about 20 minutes after turning off the machine, and then check that the fusing section has reached room temperature, otherwise, you may get burnt.

---

- 2 Open the machine's front cover.




- 3 Slowly raise the scanner unit.




- 4 Pull the lever, and then open the right side cover.




*Before opening the right side cover, fold up Tray 1.*



- 5 Use a coin to loosen the two screws securing the fuser unit.




6 Remove the fuser unit.




7 Prepare a new fuser unit.




*Be careful not to touch the surface of the fuser roller.*




8 Insert the fuser unit.




- 9** Tighten the two screws to secure the fuser unit.



- 10** Close the right side cover; slowly lower the scanner unit, and then close the front cover.



- 11** Reconnect the power cord, and turn on the machine.



- 12** Reset the counter with ADMIN . MANAGEMENT / SUPPLIES REPLACE / FUSER UNIT in the UTILITY menu.



---

***Maintenance***

---

**8**

# Maintaining the Machine



## CAUTION

**Read all caution and warning labels carefully, making sure to follow any instructions contained in them. These labels are located on the inside of the machine's covers and the interior of the machine body.**

Handle the machine with care to preserve its life. Abuse handling may cause damage and void your warranty. If dust and paper scraps remain on the inside or outside of the machine, machine performance and print quality will suffer, so the machine should be cleaned periodically. Keep the following guidelines in mind.



## WARNING!

**Turn off the machine, unplug the power cord, and disconnect all interface cables before cleaning. Do not spill water or detergent into the machine; otherwise the machine will be damaged and an electric shock may occur.**




## CAUTION

**The fuser unit is hot. When the right side cover is opened, the fuser unit temperature drops gradually (one hour wait time).**



- Be careful when cleaning the inside of the machine or removing media misfeeds, as the fuser unit and other internal parts may be very hot.
- Do not place anything on top of the machine.
- Use a soft cloth to clean the machine.
- Never spray cleaning solutions directly on the machine's surface; the spray could penetrate through the air vents of the machine and damage the internal circuits.
- Avoid using abrasive or corrosive solutions or solutions that contain solvents (such as alcohol and benzene) to clean the machine.
- Always test any cleaning solution (such as mild detergent) on a small inconspicuous area of your machine to check the solution's performance.
- Never use sharp or rough implements, such as wire or plastic cleaning pads.
- Always close the machine's covers gently. Never subject the machine to vibration.

- Do not cover the machine immediately after using it. Turn it off and wait until it cools down.
- Do not leave the machine's covers open for any length of time, especially in well-lit places; light may damage the toner cartridges.
- Do not open the machine during printing.
- Do not tap media stacks on the machine.
- Do not lubricate or disassemble the machine.
- Do not tilt the machine.
- Do not touch the electrical contacts, gears, or laser devices. Doing so may damage the machine and cause the print quality to deteriorate.
- Keep media in the output tray at a minimum level. If the media is stocked too high, your machine may experience media misfeeds and excessive media curl.
- Make sure two people are available to lift the machine when moving it.  
Keep the machine level to avoid toner spillage.
- When lifting the machine, fold up Tray 1 and remove the output tray, and then lift the machine as shown in the illustration at the right.
- If the output tray and lower feeder unit are installed, remove them from the machine and move each part separately.
- If you get toner on your skin, wash it off with cool water and a mild soap.



## CAUTION

**If you get toner in your eyes, wash it out immediately with cool water and consult a doctor.**

- Make sure any parts removed during cleaning are replaced before you plug in the machine.

# Cleaning the Machine




## CAUTION


Be sure to turn off the machine and unplug the power cord before cleaning.

### Exterior


#### ■ Control Panel




#### ■ Ventilation Grill




#### ■ Machine Exterior



#### ■ Original Glass



#### ■ Original Cover Pad




## Media Rollers

The accumulation of paper dust and other debris on the media rollers can cause media-feeding problems.

### Cleaning the Media Feed Rollers (Manual Feed Tray)


**1** Open Tray 1.



**2** Press down on the center of the paper-lifting plate until the left and right locking tabs (white) lock into place.



- 3** Clean the media feed rollers by wiping them with a soft, dry cloth.




- 4** Close the tray.




## Cleaning the Media Feed Rollers (Tray 2/3)


- 1 Pull out the tray.



- 2 Clean the media feed rollers by wiping them with a soft, dry cloth.



- 3 Close the tray.




## Cleaning the Media Transfer Rollers for Tray 3


- 1 Open the right side cover of Tray 3.




*Before opening the right side cover of Tray 3, fold up Tray 1.*



- 2 Clean the media transfer rollers by wiping them with a soft, dry cloth.




- 3 Close the right side cover of Tray 3.




## Cleaning the Media Feed Rollers for the ADF


- 1 Open the ADF feed cover.



- 2 Clean the media feed rollers by wiping them with a soft, dry cloth.



- 3 Close the ADF feed cover.




## Cleaning the Media Feed Rollers for the Duplex



- 1 Pull the lever, and then open the right-side cover.




*Before opening the right-side cover, fold up Tray 1.*



- 2 Clean the feed rollers by wiping them with a soft, dry cloth.





- 3 Close the right-side cover



## Laser Lens

This machine is constructed with four laser lenses. Clean all lenses as described below. The laser lens cleaning tool should be attached to the inside of the front cover.


- 1 Open the machine's front cover and remove the cleaning tool from the machine's front cover.




- 2 Insert the laser lens cleaning tool into the laser lens cleaning opening, pull it out, and then repeat this back and forth movement 2 or 3 times.
- 3 Clean between each of the laser lenses in the same way.



*The laser lens cleaning tool is included with the machine.  
Safely store the laser lens cleaning tool so that it will not be lost.*



- 4 Return the laser lens cleaning tool to its holder on the inside of the front cover.
- 5 Close the front cover.



---

***Troubleshooting***

---

**9**

# Introduction

This chapter provides information to aid you in resolving machine problems you may encounter, or at least guide you to the proper sources for help.

Printing a Configuration Page	page 201
Preventing Media Misfeeds	page 202
Understanding the Media Path	page 203
Clearing Media Misfeeds	page 203
Solving Problems with Media Misfeeds	page 226
Solving Other Problems	page 229
Solving Problems with Printing Quality	page 235
Status, Error, and Service Messages	page 242

## Printing a Configuration Page

- 1 In the main screen, press the ▲ or ▼ key to select REPORT/STATUS, and then press the **Select** key.
- 2 Press the ▲ or ▼ key to select REPORT, and then press the **Select** key.
- 3 Press the ▲ or ▼ key to select CONFIGURATION PAGE, and then press the **Select** key.
- 4 Press the **Start-B&W** key or the **Start-Color** key.

# Preventing Media Misfeeds



<b>Make sure that...</b>
Media matches the machine specifications.
Media is flat, especially on the leading edge.
The machine is on a hard, flat, level surface.
You store media in a dry location away from moisture and humidity.
You remove transparencies from the output tray immediately after printing to avoid static buildup.
You always adjust the media guides in Tray 2/3 after inserting the media ( <i>a guide that is not properly adjusted can cause poor print quality, media misfeeds, and machine damage</i> ).
You load the media printing-side up in the tray ( <i>many manufacturers place an arrow on the end of the wrapper to indicate the printing side</i> ).

<b>Avoid...</b>
Media that is folded, wrinkled, or excessively curled.
Double feeding ( <i>remove the media and fan the sheets—they may be sticking together</i> ).
Fanning transparencies since this causes static.
Loading more than one type/size/weight of media in a tray at the same time.
Overfilling the trays.
Allowing the output tray to overfill ( <i>the output tray has a 250 sheet capacity—misfeeding may occur if you allow more than 250 sheets of media to accumulate at one time</i> ).
Allowing the output tray to fill with more than a few transparencies.

# Understanding the Media Path

Understanding the media path will help you locate media misfeeds.

1. ADF media feed rollers
2. Document feed tray
3. Document output tray
4. Toner cartridge
5. Fuser unit
6. Duplex
7. Tray 1 (manual feed tray)
8. Tray 3 (optional lower feed unit)
9. Tray 2
10. Laser
11. Imaging unit
12. Transfer belt unit
13. Output tray



## Clearing Media Misfeeds

To avoid damage, always remove misfed media gently, without tearing it. Any piece of media left in the machine, whether large or small, can obstruct the media path and cause further misfeeds. Do not reload media that has misfed.

### **Note**

**The image is not fixed on the media before the fusing process. If you touch the printed surface, the toner may stick to your hands, so be careful not to touch the printed face when removing the misfed media. Make sure not to spill any toner inside the machine.**



## CAUTION

Unfused toner can mess your hands, clothes, or anything else it gets on.

If you accidentally get toner on your clothes, lightly dust them off as best as you can. If some toner remains on your clothes, use cool, not hot water, to rinse the toner off. If toner gets on your skin, wash it off with cool water and a mild soap.



## CAUTION

If you get toner in your eyes, wash it out immediately with cool water and consult a doctor.

If, after clearing the media misfeed, the misfeed message in the message window persists, open and close the engine cover. This should clear the misfeed message.

## Media Misfeed Messages and Clearing Procedures

Media Misfeed Message	Page Reference
PAPER MISFEED OPEN RIGHT DOOR	page 209
PAPER MISFEED OPEN TRANSPORT DOOR	page 213
FUSER JAM OPEN RIGHT DOOR	page 218
TRANSFER ROLLER JAM OPEN TRANSPORT DOOR	page 213
VERTICAL TRANS JAM OPEN RIGHT DOOR	page 209
DUPLEX LOWER JAM OPEN RIGHT DOOR	page 217
DUPLEX UPPER JAM OPEN RIGHT DOOR	page 217


<b>Media Misfeed Message</b>	<b>Page Reference</b>
MP TRAY JAM OPEN RIGHT DOOR	page 206
HORIZONTAL TRANS JAM OPEN FRONT COVER UP SCANNER UNIT	page 224
OUTPUT JAM OPEN FRONT COVER UP SCANNER UNIT	page 224
SWITCH BACK JAM OPEN FRONT COVER UP SCANNER UNIT	page 222
ORIGINAL DOC. JAM OPEN DOC.FEED COVER	page 215

## Clearing a Media Misfeed from Tray 1 (Manual Feed Tray) and Transfer Roller


- 1 Pull the lever, and then open the right side cover.



*Before opening the right side cover, fold up Tray 1.*




- 2 Carefully pull out the misfed media.





## CAUTION

The area around the fuser unit is extremely hot. Touching anything other than the indicated levers may result in burns. If you get burned, immediately cool the skin under cold water, and then seek professional medical attention.





---


## Note

Decreased print quality may result if the surface of the image transfer belt or the transfer roller is touched.

Be careful not to touch the surface of the image transfer belt or transfer roller.



**3** Close the right side cover.




## Clearing a Media Misfeed in Tray 2


- 1 Pull the lever, and then open the right side cover.



*Before opening the right side cover, fold up Tray 1.*




- 2 Carefully pull out the misfed media.





## CAUTION



The area around the fuser unit is extremely hot. Touching anything other than the indicated levers may result in burns. If you get burned, immediately cool the skin under cold water, and then seek professional medical attention.




## Note

Decreased print quality may result if the surface of the image transfer belt or the transfer roller is touched.


Be careful not to touch the surface of the image transfer belt or transfer roller.




- 3** Close the right side cover.



- 4** Pull out Tray 2, and then remove all media from the tray.



- 5** Fan the media you removed and then align it well.




6 Load the media face up in Tray 2.

 *Make sure that the media is flat.*

 *Do not load paper above the ▼ mark.*

7 Close Tray 2.




## Clearing a Media Misfeed in Tray 3


- 1 Open the right side cover of Tray 3.




*Before opening the right side cover of Tray 3, fold up Tray 1.*




- 2 Carefully pull out the misfed media.




- 3 Close the right side cover of Tray 3.



- 4 Pull out Tray 3, and then remove all paper from the tray.



- 5 Fan the paper you removed and then align it well.



- 6 Load the paper face up in Tray 3.



*Make sure that the paper is flat.*




*Do not load paper above the ▼ mark.*




*Slide the media guides against the edges of the paper.*

- 7 Close Tray 3.




## Clearing a Media Misfeed from the ADF


- 1 Open the ADF feed cover.




- 2 Remove the document from the ADF document feed tray.




- 3 Lift to open the ADF cover.




**4** Remove any misfed media.



**5** Close the ADF cover.



**6** Close the ADF feed cover.




## Clearing a Media Misfeed from the Duplex


- 1 Pull the lever, and then open the right side cover.




*Before opening the right side cover, fold up Tray 1.*



- 2 Carefully pull out the misfed media.




- 3 Close the right side cover.




## Clearing a Media Misfeed from the Fuser Unit

- 1 Open the machine's front cover.




- 2 Slowly raise the scanner unit, and open the cover.




- 3 Pull the lever, and then open the right side cover.




*Before opening the right side cover, fold up Tray 1.*




- 4** Push up the levers of the fuser unit cover, and then open the cover.



- 5** Carefully pull out the misfed media.




*If the misfed media cannot be removed by pulling it down, pull it from the top of the fuser unit.*






If the paper becomes crinkled and jammed in the fuser unit, open the fuser unit cover, and then remove the paper.



## CAUTION



The area around the fuser unit is extremely hot. Touching anything other than the indicated levers may result in burns. If you get burned, immediately cool the skin under cold water, and then seek professional medical attention.




## Note

Decreased print quality may result if the surface of the image transfer belt or the transfer roller is touched.


Be careful not to touch the surface of the image transfer belt or transfer roller.



6 Push down the levers.




- 7 Close the right side cover; slowly lower the scanner unit, and then close the front cover.




## Clearing a Media Misfeed from the Switchback


- 1 Open the machine's front cover.




- 2 Slowly raise the scanner unit, and open the cover.




- 3 Carefully pull out the misfed media.



- 4 Close the cover, and slowly lower the scanner unit.




- 5 Close the front cover.




# Clearing a Media Misfeed from the Horizontal Transport Area


1 Open the machine's front cover.




2 Slowly raise the scanner unit, and open the cover.




3 Carefully pull out the misfed media.



- 4 Close the cover, and slowly lower the scanner unit.



- 5 Close the front cover.



## Solving Problems with Media Misfeeds



Frequent misfeeds in any area indicate that area should be checked, repaired, or cleaned. Repeated misfeeds may also happen if you're using unsupported print media or original media.

Symptom	Cause	Solution
Several sheets go through the machine together.	The front edges of the media are not even.	Remove the media and even up the front edges, then reload it.
	The media is moist from humidity.	Remove the moist media and replace it with new, dry media.
	Too much static electricity is present.	Do not fan transparencies.
Media misfeed message stays on.	Engine cover needs to be opened and closed again to reset the machine.	Open and close the engine cover again.
	Some media remains misfed in the machine.	Check the media path again to make sure that you have removed all of the misfed media.
Duplex misfeeds.	Unsupported media (wrong size, thickness, type, etc.) is being used.	Use KONICA MINOLTA-approved media. See "Specifications" on page 66.  Also, refer to <a href="http://printer.konicaminolta.com">http://printer.konicaminolta.com</a> for a complete list of currently approved media.
		Plain paper, recycled paper can be aut duplexed if the media type is set properly in the driver. See "Specifications" on page 66.
		Make sure that you have not mixed media types in the tray.
		Do not duplex, envelopes, labels, letter head, postcards, thick stock, glossy media, or transparencies.
	Media is still being misfed.	Check the media path inside the duplex again to make sure that you have removed all of the misfed media.

<b>Symptom</b>	<b>Cause</b>	<b>Solution</b>
Media is misfed in the ADF.	The loaded document does not meet the specifications.	Load the correct document. For details on the documents that can be loaded, refer to “Documents that can be loaded into the ADF” on page 93.
	The loaded document exceeds the maximum capacity.	Load the document so that it does not exceed the maximum capacity. For details on the documents that can be loaded, refer to “Documents that can be loaded into the ADF” on page 93.
	The document guides were not slid against the edges of the document.	Slide the document guides against the edges of the document. For details on loading the document, refer to “Loading a document into the ADF” on page 96.
Media is misfeeding.	The media is not correctly positioned in the tray.	Remove the misfed media and reposition the media properly in the tray.
	The number of sheets in the tray exceeds the maximum allowed.	Remove the excess media and reload the correct number of sheets in the tray.
	The media guides are not correctly adjusted to the media size.	Adjust the media guides in the Tray 1 to match the size of the media.
	Warped or wrinkled media is loaded in the tray.	Remove the media, smooth it out, and reload it. If it still misfeeds, do not use that media.
	The media is moist from humidity.	Remove the moist media and replace it with new, dry media.
	Envelopes, labels, postcards, thick stock, letterhead, glossy media, or transparencies are loaded in Tray 2.	Special media must be loaded in Tray 1 only.
	The recommended transparency or label sheet is facing the wrong way in Tray 1.	Load the transparencies or label sheets according to the manufacturer’s instructions.

<b>Symptom</b>	<b>Cause</b>	<b>Solution</b>
Media is mis-feeding.	Envelopes are facing the wrong way in Tray 1.	Load the envelopes in Tray 1 with the flaps facing down.  If the flaps are on the long edge, load the envelopes with the flap edge toward the machine and the flap side facing down.
	Transparencies have collected static electricity in the tray.	Remove the transparencies and load them in Tray 1 one sheet at a time. Do not fan transparencies before loading them.
	Unsupported media (wrong size, thickness, type, etc.) is being used.	Use KONICA MINOLTA-approved media.  See "Specifications" on page 66.  Also, refer to <a href="http://printer.konicaminolta.com">http://printer.konicaminolta.com</a> for a complete list of currently approved media.
	The media feed roller is dirty.	Remove the transfer roller and clean it.  For details on removing the transfer roller, refer to page 169.

# Solving Other Problems

To order KONICA MINOLTA consumables, go to [www.q-shop.com](http://www.q-shop.com).

Symptom	Cause	Solution
Machine power is not on.	The power cord is not correctly plugged into the outlet.	Turn off the machine, confirm that the power cord is correctly plugged into the outlet, and then turn on the machine.
	Something is wrong with the outlet connected to the machine.	Plug another electrical appliance into the outlet and see whether it operates properly.
	The power switch is not correctly turned on (I position).	Turn the power switch off (O position), then turn it back to the on (I position).
	The machine is connected to an outlet with a voltage or frequency that does not match the machine specifications.	Use a power source with the specifications listed in appendix A, "Technical Specifications."
The control panel displays Toner Low much sooner than expected.	One of the toner cartridges may be defective.	Remove the toner cartridges and check for damage. If it is damaged, replace it.
	Printed with heavy toner coverage.	See specifications in Appendix A.
Cannot print the machine status list.	The tray is empty.	Check that at least Tray 1 is loaded with media, in place, and secure.
	There is a media misfeed.	Clear the media misfeed.
When the paper type or paper size for Tray 1 is changed, Check Fax Mode appears.	If a fax is received, it could not be printed on paper of the currently specified type or size. However, copy and print operations can be performed.	To print a received fax, change the paper type to PLAIN PAPER and the paper size to A4, LEGAL, LETTER or OFICIO (Mexico only).

<b>Symptom</b>	<b>Cause</b>	<b>Solution</b>
Printing takes too much time.	The machine is set to a slow printing mode (for example, thick stock or transparency).	It takes more time to print with special media. When using regular paper, make sure that the media type is set properly in the driver.
	The machine is set to power saving mode.	It takes time for printing to start in power saving mode.
	The job is very complex.	Wait. No action needed.
	A toner cartridge for a different region or an unapproved toner cartridge is installed (Wrong Toner X is displayed in the message window).	Install a correct KONICA MINOLTA toner cartridge approved for your specific machine.
	If an error has been detected during printing job transmission in the Copy mode, it takes a while to process the error and resume the printing operation.	Wait. No action needed.
Blank pages are printed.	One or more of the toner cartridges are defective or empty.	Check the toner cartridges. The image will not print correctly or not at all, if the cartridges are empty.
	The wrong media is being used.	Check that the media type.
Not all pages print.	A different user accidentally canceled the job.	Try printing the remaining pages.
	The tray is empty.	Check that the tray is loaded with media, in place, and secure.
	A document is printed with an overlay file which has been created by an unsuitable printer driver.	Print the overlay file using a suitable printer driver.

<b>Symptom</b>	<b>Cause</b>	<b>Solution</b>
Some parts of the image are lost with 2in1 (4in1) copying.	When printing envelopes, the zoom ratio was specified, and then 2in1 (4in1) copying was set.	With 2in1 (4in1) copying, the zoom ratio is automatically adjusted. For 2in1 (4in1) copying on media with a narrow printing area, such as envelopes, set 2in1 (4in1) copying, and then adjust the zoom ratio, if necessary.
Machine resets or turns off frequently.	The power cord is not correctly plugged into the outlet.	Turn off the machine, confirm that the power cord is correctly plugged into the outlet, and then turn on the machine.
	A system error occurred.	Contact Technical Support with the error information.
You are experiencing duplex problems.	Media or settings are not correct.	Make sure that you are using correct media. <ul style="list-style-type: none"> <li>■ See “Specifications” on page 66.</li> </ul> Also, refer to <a href="http://printer.konicaminolta.com">http://printer.konicaminolta.com</a> for a complete list of currently approved media. <ul style="list-style-type: none"> <li>■ Do not duplex custom-sized media, envelopes, labels, postcards, thick stock, letterhead, glossy media, or transparencies.</li> <li>■ Make sure that you have not mixed media types in the tray.</li> </ul>
		In the printer driver (Layout/Double-Sided), choose “Short Edge Binding” (flipped as on a clipboard) or “Long Edge Binding” (flipped as in a loose-leaf notebook).
		Set duplex (Double-Sided) copying. For details on setting duplex (Double-Sided) copying, refer to “Setting Duplex (Double-Sided) Copying” on page 117.
		For N-up on duplexed pages, choose Collate only in the printer driver’s Basic Tab. Do not set collation in the application.

<b>Symptom</b>	<b>Cause</b>	<b>Solution</b>
With N-up on multiple copies, the output is incorrect.	Both the printer driver and the application have been set for collation.	For N-up on multiple copies, choose Collate only in the printer driver's Basic Tab. Do not set collation in the application.
Booklet Left and Right Binding output is incorrect.	Both the printer driver and the application have been set for collation.	For Booklet Left Binding and Booklet Right Binding, choose Collate only in the printer driver's Basic Tab. Do not set collation in the application.
You hear unusual noises.	The machine is not level.	Place the machine on a flat, hard, level surface.
	The tray is not installed correctly.	Remove the tray that you are printing from and reinsert it completely into the machine.
	There is a foreign object stuck inside the machine.	Turn off the machine and remove the object. If you cannot remove it, contact Technical Support.
When copying or scanning with the ADF, a band appears at the end of the image or paper (5 to 6 mm).	A malfunction may have occurred while paper was being transferred with the ADF.	If a band appears in the copy after copying, select a copy density setting that is one level darker.  If a band appears in the image after scanning, scan using the original glass.
Cannot copy with the ADF.	Envelope DL, Envelope Monarch, or Envelope C6 is set to the ADF.	Place the document on the original glass. With the Envelope DL size, some areas may not be copied.
While scanning with the ADF at 600 dpi, the image has become lighter and the background has become darker.	Immediately after the machine is turned on, the lamp intensity increases. Therefore, the image may become lighter and the background may become darker.	If the image becomes lighter or darker, scan using the original glass. In addition, perform the scan operation after turning the machine on and lighting the lamp for an hour and a half or more.

<b>Symptom</b>	<b>Cause</b>	<b>Solution</b>
Scanned images are noisy.	Resolution is set to 150 x 150 while the scan mode is set to MIX or TEXT.	Set the scan mode to PHOTO.
Some areas of the scanned image are missing.	Acrobat 8 (Macintosh version) is used for scanning the image.	With the Acrobat Scan setting, turn off the OCR and Filtering functions.
The web-based utility cannot be accessed.	The PageScope Web Connection Administrator's password is incorrect.	The PageScope Web Connection Administrator password has a 4-character minimum and an 8-character maximum. For details of the PageScope Web Connection administrator password, refer to the Reference Guide on the Documentation CD/DVD.

Symptom	Cause	Solution
Media is wrinkled. 	The media is moist from humidity or having water spilled on it.	Remove the moist media and replace it with new, dry media.
	The media feed roller or fuser unit is defective.	Check them for damage. If necessary, contact Technical Support with the error information.
	Unsupported media (wrong size, thickness, type, etc.) is being used.	Use KONICA MINOLTA-approved media. See "Specifications" on page 66.  Also, refer to <a href="http://printer.konicaminolta.com">http://printer.konicaminolta.com</a> for a complete list of currently approved media.
	Envelopes are being printed with the fuser separator levers in the plain paper position.	Before printing envelopes, place the fuser separator levers in the envelope position.
When a mail server that requires user authentication is used, Scan to E-mail operation is not available.	Changed the time period of POP Before SMTP Time in PageScope Web Connection.	Change the time period of POP Before SMTP Time to default (1 second) setting.  For details, refer to the Reference Guide on the Documentation CD/DVD.

# Solving Problems with Printing Quality


Symptom	Cause	Solution
Nothing is printed, or there are blank spots on the printed page. 	One or more of the toner cartridges may be defective.	Remove the toner cartridges and check if any is damaged.
	One or more of the imaging units may be defective.	Remove the imaging units and check for damage. If it is damaged, replace it.
	The media is moist from humidity.	Adjust the humidity for media storage. Remove the moist media and replace it with new, dry media.
	The media set in the printer driver mismatches the media loaded in the machine.	Load the correct media in the machine.
	The power source does not match the machine specifications.	Use a power source with the proper specifications.
	Several sheets are being fed at the same time.	Remove the media from the tray and check for static electricity. Fan plain paper or other media (but not transparencies), and replace it in the tray.
	Media is not set properly in the tray(s).	Remove the media, tap it to straighten it out, return it to the tray, and realign the media guides.
Entire sheet is printed in black or color. 	One or more of the toner cartridges may be defective.	Remove the toner cartridges and check for damage. If it is damaged, replace it.
	One or more of the imaging units may be defective.	Remove the imaging units and check for damage. If it is damaged, replace it.

<b>Symptom</b>	<b>Cause</b>	<b>Solution</b>
Image is too light; there is low image density. 	Laser lens is dirty.	Clean the laser lens.
	The copy density is set too light.	Select a darker copy density.
	The media is moist from humidity.	Remove the moist media and replace with new, dry media.
	There is not much toner left in the cartridge.	Replace the toner cartridge.
	One or more of the toner cartridges may be defective.	Remove the toner cartridges and check for damage. If it is damaged, replace it.
	Media type is set incorrectly.	When printing envelopes, labels, postcards, thick stock, glossy media, or transparencies, specify the appropriate media type in the printer driver.
Image is too dark. 	The copy density is set too dark.	Select a lighter copy density.
	The document was not pressed close enough against the original glass.	Position the document so that it is pressed close enough against the original glass. For details on positioning the document on the original glass, refer to "Placing a document on the original glass" on page 95.
	One or more of the toner cartridges may be defective.	Remove the toner cartridges and check for damage. If it is damaged, replace it.
	One or more of the imaging units may be defective.	Remove the imaging units and check for damage. If it is damaged, replace it.

<b>Symptom</b>	<b>Cause</b>	<b>Solution</b>
Image is blurred; background is lightly stained; there is insufficient gloss of the printed image.  	One or more of the toner cartridges may be defective.	Remove the toner cartridges and check for damage. If it is damaged, replace it.
	One or more of the imaging units may be defective.	Remove the imaging units and check for damage. If it is damaged, replace it.
	The original glass is dirty.	Clean the original glass. For details, refer to “Cleaning the Machine” on page 190.
	The original cover pad is dirty.	Clean the original cover pad. For details, refer to “Cleaning the Machine” on page 190.
The print or color density is uneven.  	One or more of the toner cartridges may be defective or low.	Remove the toner cartridges and check for damage. If it is damaged, replace it.
	One or more of the imaging units is defective.	Remove the imaging units and check for damage. If it is damaged, replace it.
	The machine is not level.	Place the machine on a flat, hard, level surface.

Symptom	Cause	Solution
Irregular print or mottled image appears. 	The media is moist from humidity.	Adjust the humidity in the media storage area.  Remove the moist media and replace it with new, dry media.
	Unsupported media (wrong size, thickness, type, etc.) is being used.	Use KONICA MINOLTA-approved media. See "Specifications" on page 66.  Also, refer to <a href="http://printer.konicaminolta.com">http://printer.konicaminolta.com</a> for a complete list of currently approved media.
	One or more of the toner cartridges may be defective.	Remove the toner cartridges and check for damage. If it is damaged, replace it.
	One or more of the imaging units is defective.	Remove the imaging units and check for damage. If it is damaged, replace it.
	The fuser separator levers are adjusted for envelope printing.	Return the fuser separator levers to the plain paper setting.
There is insufficient fusing or the image comes off when rubbed. 	The media is moist from humidity.	Remove the moist media and replace it with new, dry media.
	Unsupported media (wrong size, thickness, type, etc.) is being used.	Use KONICA MINOLTA-approved media. See "Specifications" on page 66.  Also, refer to <a href="http://printer.konicaminolta.com">http://printer.konicaminolta.com</a> for a complete list of currently approved media.
	Media type is set incorrectly.	When printing envelopes, labels, postcards, thick stock, or transparencies, specify the appropriate media type in the printer driver.
	The fuser separator levers are adjusted for envelope printing.	Return the fuser separator levers to the plain paper setting.

Symptom	Cause	Solution
There are toner smudges or residual images. 	One or more of the toner cartridges are defective or installed incorrectly.	Remove the toner cartridges and check for damage. If it is damaged, replace it.
	The fuser separator levers are adjusted for envelope printing.	Return the fuser separator levers to the plain paper setting.
There are toner smudges on the back side of the page (whether or not it has been duplexed). 	The media transfer roller is dirty.	Clean the media transfer roller. If you think the transfer roller should be replaced, contact Technical Support with the error information.
	The media path is dirty with toner.	Print several blank sheets and the excess toner should disappear.
	One or more of the toner cartridges are defective.	Remove the toner cartridges and check for damage. If it is damaged, replace it.
	One or more of the imaging units is defective.	Remove the imaging units and check for damage. If it is damaged, replace it.
Abnormal areas (white, black, or color) appear in a regular pattern. 	The laser lens is dirty.	Clean the laser lens.
	A toner cartridge may be defective.	Remove the toner cartridges with the color causing the abnormal image. Replace it with a new toner cartridge.
	One or more of the imaging units is defective.	Remove the imaging units and check for damage. If it is damaged, replace it.

Symptom	Cause	Solution
Image defects. 	The laser lens is dirty.	Clean the laser lens.
	A toner cartridge may be leaking.	Remove the toner cartridges and check for damage. If it is damaged, replace it.
	A toner cartridge may be defective.	Remove the toner cartridge with the color causing the abnormal image. Replace it with a new toner cartridge.
	One or more of the imaging units may be defective.	Remove the imaging units and check for damage. If it is damaged, replace it.
Lateral lines or bands appear on image. 	The machine is not level.	Place the machine on a flat, hard, level surface.
	The media path is dirty with toner.	Print several sheets and the excess toner should disappear.
	One or more of the toner cartridges may be defective.	Remove the toner cartridges and check for damage. If it is damaged, replace it.
	One or more of the imaging units is defective.	Remove the imaging units and check for damage. If it is damaged, replace it.
Colors look drastically wrong.	One or more of the toner cartridges may be defective.	Remove the toner cartridges and verify that the toner is distributed evenly on each cartridge roller, and reinstall the toner cartridges.
Colors are not registering properly; colors are mixed or have page-to-page variation.	The engine cover is not properly closed.	Make sure that the engine cover is closed.
	One or more of the imaging units is not correctly seated.	Remove the imaging units and check for damage. If it is damaged, replace it.
	One or more of the toner cartridges may be defective.	Remove the toner cartridges and check for damage. If it is damaged, replace it.
	The media is moist from humidity.	Remove the moist media and replace it with new, dry media.

Symptom	Cause	Solution
Line art does not print in color.	The line art setting for 2400 x 600 dpi requires Color Matching to be turned off.	<p>In the printer driver, go to Quality tab and choose Off in the Color Matching.</p> <p>Lower the resolution to 1200 x 600 or 600 x 600 dpi.</p>
<p>The color has a poor reproduction or has poor color density.</p> 	One or more of the imaging units may be defective.	Remove the imaging units and check for damage. If it is damaged, replace it.

If the problem is not resolved, even after all of the above have been performed, contact Technical Support with the error information.

For contact information, refer to the Need Assistance sheet.

# Status, Error, and Service Messages

Status, error, and service messages are displayed in the message window. They provide information about your machine and help you locate many problems. When the condition associated with a displayed message has changed, the message is cleared from the window.

## Status Messages

This message...	means...	Do this...
ACCEPTED	The settings were applied.	No action needed.
DATA RECEIVING	This machine is receiving data.	
ENERGY SAVE	The machine is in Energy Save mode to reduce power consumption during periods of inactivity.	
NONE	The object does not exist.	
PC SCAN CANCEL	The scan job was canceled from the driver.	
PLEASE WAIT!	After replacing a toner cartridge, or after rebooting your machine after environmental changes, your machine automatically pauses to perform an Auto-Image Density Control (AIDC) cycle. This process provides reliable machine operation with the most optimum output quality possible.	
PRINT WAITING	The machine is waiting to print.	
PRINTING	The machine is printing.	
SEARCHING	The machine is searching data.	
SCANNING	The machine is scanning the document.	
Warming Up	The machine is warming up,	

## Error Messages



For details on fax error messages, refer to the *Facsimile User's Guide on the Documentation CD/DVD*.

<b>This message...</b>	<b>means...</b>	<b>Do this...</b>
ADDRESS IS TOO LONG	The e-mail address retrieved from the LDAP server exceeds 64 characters.	This machine can handle addresses containing no more than 64 bytes. Use a shorter address.
CANNOT CONNECT xxx Server	While the scanned document was being sent in Scan mode, a connection with the specified server could not be established.	Check the settings specified in the NETWORK SETTING and E-MAIL SETTING menus, and then try sending the data again.
CANNOT GET IP xxx Server	The IP address of the SMTP server could not be obtained from the DNS server.	Check the settings specified in the NETWORK SETTING and E-MAIL SETTING menus, and then try sending the data again.
COMMUNICATION ERROR PC CONNECTION FAILED	While data was being sent in Scan mode, the connection to the computer was interrupted.	Check the connection with the computer and the scanner driver status, and then try sending the data again.
COMMUNICATION ERROR USB Memory	While data was being sent in Scan mode, the connection to the USB memory device was interrupted.	Check the connection to the USB memory device, and then try sending the fax again.
COMMUNICATION ERROR xxx Server	While data was being sent in Scan mode, the connection to the server was interrupted.	Check the settings specified in the NETWORK SETTING and E-MAIL SETTING menus, and then try sending the data again.

<b>This message...</b>	<b>means...</b>	<b>Do this...</b>
DISCONNECT USB Memory	The connection to the USB memory device was interrupted.	Check the connection to the USB memory device, and then try sending the fax again.
DISCONNECT xxx Server	The connection to the server was interrupted.	Check the settings specified in the NETWORK SETTING and E-MAIL SETTING menus, and then try sending the data again.
Fuser Unit Life	The time to replace the fuser unit has been reached.	Replace the fuser unit.
I-UNIT END REPLACE x	The time to replace the indicated imaging unit has been reached.	Replace the indicated imaging unit.
I-Unit End x	The time to replace the indicated imaging unit has been reached.	Replace the indicated imaging unit.
I-Unit Life (x)	The time to replace the indicated imaging unit has been reached.	Replace the indicated imaging unit.
I-Unit Low x	The indicated imaging unit is low and should be replaced within 200 pages at 5% coverage of Letter/A4 paper.	Prepare the indicated imaging unit.
INCORRECT TONER CHANGE x TONER	The indicated toner cartridge is not correct.	Replace the indicated toner cartridge with a correct one.
INCORRECT PAPER SIZE CHANGE xxx→xxx	The paper size set in the tray is not correct.	Follow the message and replace the paper.

<b>This message...</b>	<b>means...</b>	<b>Do this...</b>
JOB CANCELED	While a document was being scanned from the original glass in Scan mode, more than one minute had passed after the first page of the document was scanned or the data could not be sent. Therefore, the scan job was automatically canceled.	Turn the machine off, and then, after waiting a few seconds, turn it on again. When sending multiple pages, for example, from a book, scan the first page, and then scan the next page within one minute.
MEDIA TYPE ERROR LOAD xxx	Paper of the selected type is not loaded in a paper tray.	Load paper of the selected type into a paper tray.
MEMORY FILE FULL	The maximum number of 1,024 image data files has been reached.	Turn the machine off, and then, after a few seconds, turn it on again. Decrease the amount of data to be printed (for example, by decreasing the resolution), and then try printing again.
MEMORY FULL	The machine has received more data than can be processed with its internal memory.	Turn the machine off, and then, after a few seconds, turn it on again. Decrease the amount of data to be printed (for example, by decreasing the resolution), and then try printing again.
NO DUPLEX PAPER CLOSE DUPLEX FUNC. OR CHANGE PAPER SIZE	Duplex (double-sided) printing is specified, but paper with a size incompatible with duplex (double-sided) printing is selected.	Switch to simplex (single-sided) printing, or select paper with a size compatible with duplex (double-sided) printing.

<b>This message...</b>	<b>means...</b>	<b>Do this...</b>
NO NETWORK SETTING	The network settings had not been completely specified when the machine was switched to Scan mode.	Before scanning in Scan mode, specify the network settings in the NETWORK SETTING menu.
NO SUITABLE PAPER LOAD PAPER (xxx)	Paper suitable for printing is not loaded in a paper tray.	Load paper suitable for printing into a paper tray.
NOT E-MAIL ADDRESS	No speed dial destination or group dial destination is registered.  Otherwise, an FTP address or SMB address is being added after the destination address for the scan data has been specified.	Directly type in the destination address for the scan data, or register a speed dial destination or group dial destination and try specifying the destination address again.  When sending scan data to an FTP address or SMB address, only one address can be specified. Delete all specified destinations, or send the scan data, then scan again.
NOT INSTALLED I-UNIT CHECK x	The indicated imaging unit is not installed.	Install the indicated imaging unit.
NOT INSTALLED TONER CHECK x	The indicated toner cartridge is not installed.	Install the indicated toner cartridge.
NOT REGISTERED	No speed dial destination or group dial destination is registered.	Directly type in the destination address for the scan data, or register a speed dial destination or group dial destination and try specifying the destination address again.

<b>This message...</b>	<b>means...</b>	<b>Do this...</b>
OUTPUT TRAY FULL REMOVE PAPER	The output tray is full of paper.	Remove all paper from the output tray.
OVER SEARCH TIME	Communication with the LDAP server has timed out.	Establish a connection with the LDAP server again.
PAPER EMPTY LOAD PAPER (xxx)	The indicated paper tray has run out of paper.	Load media into the indicated tray.
PAPER SIZE ERROR RESET PAPER (xxx)	Paper of the selected size is not loaded in a paper tray.	Load paper of the selected size into a paper tray.
REMOVE ORIGINAL IN ADFR	The document is loaded in the ADF while a function is set that requires scanning from the original glass.	Place the document on the original glass.
RESULTS ARE OVER xxx	The LDAP search results exceed the maximum specified with MAX . SEARCH RESULT in the LDAP SETTING menu.	Change the maximum setting, or change the search conditions (for example, increase the length of the keyword), and then try performing the LDAP search again.
SCANNER UNIT OPEN CLOSE SCANNER UNIT	The scanner unit is open.	Close the scanner unit.
SET ORIGINAL TO ADFR	The document is not loaded into the ADF while duplex (double-sided) scanning is set.	Load the document into ADF.
SERVER MEMORY FULL SMTP Server	The memory of the SMTP server has become full.	Free up some space on the disk, for example, by contacting your server administrator.

<b>This message...</b>	<b>means...</b>	<b>Do this...</b>
THE PARTY IS FULL	The maximum number of 236 destinations for the scan data has been reached.	Send the data, and then try scanning again. Otherwise, delete unnecessary destinations before adding the desired ones.
TONER EMPTY CHANGE x TONER	The indicated toner cartridge has become empty. (This message appears if TONER EMPTY STOP on the MACHINE SETTING menu is set to ON.)	Replace the indicated toner cartridge.
Toner Low x	The indicated toner cartridge is low and should be replaced within 200 pages at 5% coverage of Letter/A4 paper.	Prepare the indicated toner cartridge.
Trans. Belt Life	The time to replace the transfer belt unit has been reached.	Replace the transfer belt unit.
Trans. Roll. Life	The time to replace the transfer roller has been reached.	Replace the transfer roller.
TRAYx OPEN CLOSE TRAYx	The indicated paper tray is open.	Close the indicated paper tray.
USB Dev. Not support	A USB device incompatible with this machine is connected.	Disconnect the USB device from this machine.
USB Hub Not support	A USB hub is connected to this machine.	This machine is not compatible with a USB hub. When connecting USB cables to this machine, do not use a USB hub.

<b>This message...</b>	<b>means...</b>	<b>Do this...</b>
USB MEMORY FULL	There is no space available on the USB memory device connected to this machine.	Delete data from the USB memory device to create free space, or use a different USB memory device.
xxx COVER OPEN CLOSE xxx COVER	The indicated cover is open.	Close the indicated cover.
xxx DOOR OPEN CLOSE xxx DOOR	The indicated door is open.	Close the indicated door.
xxx SERVER ERROR	The file cannot be saved on the indicated server.	Check the status of the indicated server.
WASTE TONER FULL REPLACE BOTTLE	The waste toner bottle is full.	Replace the waste toner bottle.
Waste Near Full	The waste toner bottle will soon be full.	Prepare a waste toner bottle.
Wrong I-Unit x	An imaging unit incompatible with the machine is installed.	Replace the indicated imaging unit with a correct one.
WRONG PASSWORD xxx	The password is incorrect, so the indicated server could not be accessed.	Check the password, and then specify the correct one.
Wrong Toner x	A toner cartridge incompatible with the machine is installed.	Replace the indicated toner cartridge with a correct one.

## Service Messages

These messages indicate a more serious fault that can only be corrected by a customer service engineer. If one of these messages appears, turn the machine off, then turn it on again. If the problem persists, contact your local vendor or authorized service provider.

<b>This service message...</b>	<b>means...</b>	<b>Do this...</b>
MACHINE TROUBLE SERVICE CALL (xxxx)	An error has been detected with the item indicated "xxxx" in the service message.	Reboot the machine. This often clears the service message, and machine operation can resume.  If the problem persists, contact Technical Support.

---

***Installing  
Accessories***

---

**10**

# Introduction

---

**Note**

---

**Any damage to the machine caused by the use of accessories not manufactured or supported by KONICA MINOLTA will void your warranty.**

---

This chapter provides information about the following accessories.

<b>Tray 3</b>	Lower feeder unit with 500-sheet tray included
---------------	--

---

**Note**

---

**Installing accessories always requires that the machine and accessories are turned off and unplugged during installation.**

---



*For details on the available options, refer to <http://printer.konicaminolta.com>.*

# Antistatic Protection

## **Note**

---

It's very important to protect the printer controller board from electrostatic damage while performing any task involving the controller board.

Turn off all power switches first. If an antistatic wrist strap is provided in your printer option kit, attach one end of it to your wrist and the other end to the bare metal chassis on the back of your printer. Never attach the wrist strap to any piece of equipment with an electrical current present. Plastic, rubber, wood, painted metal surfaces, and telephones are not acceptable grounding points.

If you don't have an antistatic wrist strap, discharge your body's static electric charge by touching a grounded surface before you handle any printer boards or components. Also avoid walking around after grounding yourself.


---

## Tray 3 (Lower Feeder Unit)

You can install up to one optional lower feeder unit (Tray 3). The lower feeder unit increases your machine's media feed capacity by 500 sheets.

### Kit Contents

- Lower feeder unit with a tray (500-sheet capacity)



## Installing Tray 3


### Note

---

Since consumables are installed in the machine, be sure to keep the machine level when moving it in order to prevent accidental spills.

---

- 1 Turn off the machine and disconnect the power cord and interface cables.




- 2 Prepare the lower feeder unit.




*Be sure to place the lower feeder unit on a level surface.*

- 3 Open the right side cover of the lower feeder unit.



*The right side cover of the lower feeder must be opened before the feeder can be installed onto the machine.*


- 4 With another person's help, place the machine on top of the lower feeder unit, making sure that the positioning pins on the lower feeder unit correctly fit into the holes on the bottom of the machine.



**! WARNING!**


**This machine weighs approximately 55 kg (121 lb) when it is fully loaded with consumables. The machine must be lifted by two people.**

- 5 Close the right side cover of the lower feeder unit.



- 6 Reconnect all interface cables.

- 7** Reconnect the power cord, and turn on the machine.



- 8** From the printer driver, correctly specify the setting for Tray 3.



*For details on specifying printer driver settings, refer to “Selecting Printer Driver Options/Defaults (for Windows)” on page 98.*



---

*Appendix*

**A**

---

# Technical Specifications

Type	Desktop (Tandem Full Color A4 laser beam printer-based all-in-one)
Document holder	Stationary
Developing system	Mono-component SMT
Fusing system	Belt fusing system
Resolution	2400 x 600 dpi, 1200 x 600 dpi, 600 x 600 dpi
First print	Simplex <ul style="list-style-type: none"> <li>■ Monochrome/Full Color 18.0 seconds for A4/Letter (plain paper)</li> </ul>
First copy	Simplex <ul style="list-style-type: none"> <li>■ Monochrome 25.0 seconds for A4/Letter (plain paper) (Normal 600 x 300 dpi)</li> <li>■ Full color 28.0 seconds for A4/Letter (plain paper) (Normal 600 x 300 dpi)</li> </ul>
Print/copy speed	Simplex <ul style="list-style-type: none"> <li>■ Monochrome/Full Color 24/24 pages per minute for A4 (plain paper)</li> </ul> Duplex <ul style="list-style-type: none"> <li>■ Monochrome/Full Color 24/25 pages per minute for A4 (plain paper)</li> </ul>
Warm-up time	Avg. 40 seconds (time to return to Ready mode from Energy Save mode)

Media sizes	<p>Tray 1 (manual feed tray)</p> <ul style="list-style-type: none"> <li>■ Paper width: 92 to 216 mm (3.6" to 8.5")</li> <li>■ Paper length: 148 to 356 mm (5.8" to 14.0")</li> </ul> <p>Tray 2</p> <ul style="list-style-type: none"> <li>■ Paper width: 92 to 216 mm (3.6" to 8.5")</li> <li>■ Paper length: 148 to 297 mm (5.8" to 11.7")</li> </ul> <p>Tray 3 (optional)</p> <p>A4, B5, Executive, Letter, G-Legal, Legal</p>
Paper/Media	<p>Plain paper (60 to 90 g/m<sup>2</sup>, 16 to 24 lb bond)</p> <p>Recycled paper (60 to 90 g/m<sup>2</sup>, 16 to 24 lb bond)</p> <p>Transparency</p> <p>Letterhead</p> <p>Envelopes</p> <p>Labels</p> <p>Thick stock 1 (91 to 150 g/m<sup>2</sup>)</p> <p>Thick stock 2 (151 to 210 g/m<sup>2</sup>)</p> <p>Postcard</p> <p>Glossy 1 (100 to 128 g/m<sup>2</sup>)</p> <p>Glossy 2 (129 to 158 g/m<sup>2</sup>)</p>
Input capacity	<p>Tray 1 (manual feed tray)</p> <ul style="list-style-type: none"> <li>■ Plain/recycled paper: 100 sheets</li> <li>■ Envelopes: 10 envelopes</li> <li>■ Transparency, letterhead, labels, thick stock 1/2, postcard, glossy media 1/2: 20 sheets</li> </ul> <p>Tray 2</p> <p>Plain/recycled paper: 250 sheets</p> <ul style="list-style-type: none"> <li>■ Paper length: 148 to 297 mm (5.8" to 11.7")</li> </ul> <p>Tray 3 (optional)</p> <p>Plain/recycled paper: 500 sheets</p>
Output capacity	Output tray: 250 sheets

Operating temperature	10 to 35 °C (50 to 95 °F)
Operating humidity	15% to 85%
Power supply	120 V, 220 to 240 V (50 to 60 Hz, ±3%)
Power consumption	120 V, 220 to 240 V: 1250 W or less Energy save mode: 25 W or less
Amperage	120V : 11 A or less 220 to 240 V: 6 A or less
Acoustic noise	Standby: 39 dB or less Printing: 54 dB or less Copying: 56 dB or less
External dimensions	Height: 578 mm (22.8") Width: 539 mm (21.2") Depth: 590 mm (23.2")
Weight	50 kg (without consumables) 55 kg (with consumables)
Interface	USB 2.0 (High Speed) compliant, 10/100Base-T Ethernet, Parallel Host USB, RJ-45 connector
Standard memory	256 MB

# Consumable Life Expectancy Chart

## User-Replaceable

Item	Average Life Expectancy
Toner cartridge	<p><b>Standard in-box Cartridge:</b></p> <p>Printed within a constant environment 3,000 pages or more (continuous)</p> <p>Printed outside of a constant environment 2,400 pages or more (continuous)</p> <p><b>Replacement Cartridge (Standard-Capacity):</b></p> <p>Printed within a constant environment 4,000 pages or more (continuous)</p> <p>Printed outside of a constant environment 3,200 pages or more (continuous)</p> <p><b>Replacement Cartridge (High-Capacity):</b></p> <p>Printed within a constant environment 8,000 pages or more (continuous)</p> <p>Printed outside of a constant environment 6,400 pages or more (continuous)</p>
Fuser unit	120,000 pages (continuous)
Waste toner bottle	36,000 pages (monochrome) (continuous) 9,000 pages (full color) (continuous)
Transfer roller	120,000 pages
Ozone filter (bundled with transfer roller)	120,000 pages
Imaging unit	30,000 pages (continuous)
Transfer belt unit	120,000 pages (continuous)
 <p><i>A constant environment is one with a temperature between 15 °C [59 °F] and 25 °C [77 °F] and humidity between 35% and 70%.</i></p>	



The values shown for the toner cartridge and waste toner bottle indicate the number of pages for simplex printing using A4/Letter-size media with 5% coverage.

The actual life may differ (be shorter) depending on the printing conditions (coverage, paper size, etc.), differences in the printing method, such as continuous printing or intermittent printing (when print jobs of one page are often printed), or the type of paper used, for example, thick paper. In addition, the life will be affected by the temperature and humidity of the operating environment.

## Service-Replaceable

Item	Average Life Expectancy
Media feed roller	300,000 pages

# Entering Text

When specifying the user name or programming the recipient name with one-touch dial keys, letters, accented characters, numbers and symbols can be entered.

## Key Operation

Use the keypad to enter numbers, letters, and symbols.

List of characters available with each key of the keypad

## Entering Fax Numbers

Keypad Key	Available characters	Available characters (Registration of USER FAX NO.) *	
	[1]	[1]	[A]
1	1	1	-1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	(space)0
*	*		
#	#		+

\* To display your fax number, select ADMIN. MANAGEMENT/USER SETTING/USER FAX NUMBER in the UTILITY menu. For details, refer to the Facsilite User's Guide on the Documentation CD/DVD.

## Entering Names

Keypad Key	Available characters	
	[1]	[A]
1	1	.,'?¿! "1-()@/;:_
2	2	ABC2abcÆÇàáâãäåæç
3	3	DEF3defÐèéêëð
4	4	GHI4ghiiïñ
5	5	JKL5jkl€£¢
6	6	MNO6mnoØŒñòóôõöøœ°
7	7	PQRS7pqrsß\$
8	8	TUV8tuvùúûü
9	9	WXYZ9wxyzþÿ
0	0	(space)0
*		
#	#	*+×÷=#%&<>[]{} μ^`~

## Entering E-mail Addresses

Keypad Key	Available characters	
	[1]	[A]
1	1	.@_-1
2	2	ABC2abc
3	3	DEF3def
4	4	GHI4ghi
5	5	JKL5jkl
6	6	MNO6mno
7	7	PQRS7pqrs
8	8	TUV8tuv
9	9	WXYZ9wxyz
0	0	(space)0
*		
#	#	+&/*=!?(%)%[]^`'{} ~\$,:.

## Changing Input Mode

Each press of the  $\times$  key switches the input mode between numbers and letters.

[1]: Numbers can be typed in.

[A]: Letters can be typed in.

## Inputting Example

The procedure for entering text is described below, using “NJ Office” as an example.

- 1 Press the  $\times$  key to change the input mode so that letters can be entered.
- 2 Press the **6** key twice.  
“N” is entered.
- 3 Press the **5** key once.  
“J” is entered.
- 4 Press the **0** key once.  
A space is entered.
- 5 Press the **6** key three times.  
“O” is entered.
- 6 Press the **3** key seven times.  
“f” is entered.
- 7 Press the **▶** key.  
The cursor moves to the right.
- 8 Press the **3** key seven times.  
“f” is entered.
- 9 Press the **4** key seven times.  
“i” is entered.
- 10 Press the **2** key seven times.  
“c” is entered.
- 11 Press the **3** key six times.  
“e” is entered.

## Correcting Text and Input Precautions

- To erase all entered text, hold down the **Back** key.
- To delete only part of the entered text, use the ◀ and ▶ keys to move the cursor ( ) to the character that you want to delete, and then press the **Back** key.
- If multiple characters are assigned to a single key, “OK=▶” appears at the bottom of the screen.
- If the same key is to be used to enter two characters in a row, press the ▶ key after selecting the first character. (Refer to the above inputting example.)
- To enter a space, press the **0** key.

# Our Concern for Environmental Protection



As an ENERGY STAR® Partner, we have determined that this machine meets the ENERGY STAR Guidelines for energy efficiency.

## **What is an ENERGY STAR product?**

An ENERGY STAR product has a special feature that allows it to automatically switch to a “low-power mode” after a period of inactivity. An ENERGY STAR product uses energy more efficiently, saves you money on utility bills and helps protect the environment.



---

# Index

---

## Numerics

2in1/4in1 copy 112

## A

### Address book

Searching address 135

Selecting address 135

Admin. Management menu 37

Antistatic protection 253

## B

Basic tab 103

## C

Collated copy 119

Configuration menu 27

Confirm menu 16, 24

## Consumables

Fuser unit 182

Imaging unit 159

Ozone filter 173

Toner cartridge 152

Transfer belt unit 174

Transfer roller 169

Waste toner bottle 165

## Control panel 12

### Copy

2in1/4in1 copy 112

Collated copy 119

Copy density 110

Copy mode 109

Duplex 117

ID card copy 114

Poster copy 116

Repeat copy 115

Select media tray 111

Zoom ratio 110

**Copy Setting menu** 51

## **D**

**Device Options Setting tab** 105

**Dial Register menu** 53

**Duplex**

Copy 117

Scan 147

## **E**

**Electrostatic discharge** 253

**Entering text** 265

Correcting text 268

Input mode 267

Input precautions 268

**Envelope** 69

## **F**

**Favorite list**

Deleting address 140

Registering address 138, 139

Selecting address 133

**FAX RX Operation menu** 56

**FAX TX Operation menu** 54

## **G**

**Glossy media** 73

**Group dial**

Editing/deleting address 145

Registering address 144

Selecting address 134

## **I**

**ID card copy** 114

**Imageable area** 75

**Input mode** 267

## **K**

**Key operation** 265

## **L**

**Label** 70

**Layout tab** 104

**LDAP server**

Registering speed dial 142

Searching address 136

**Letterhead** 71

**Loading document** 95

**Loading media** 76

## **M**

**Machine Setting menu** 29

**Maintenance** 188

**Media**

Clearing misfeeds 203

Loading 76

Path 203

Preventing misfeeds 202

**Media misfeed**

ADF 215

Duplex 217

Fuser unit 218

Horizontal transport area 224

Switchback 222

Transfer roller 206

Tray 1 206

Tray 2 209

Tray 3 213

**Media path** 203

**Message window** 12

**Messages**

Error messages 243

Media misfeed messages 204

Service messages 250

Status messages 242

**Misfeed problems** 226

Clearing 203

Media path 203

Preventing 202

## **O**

**Original media**

Loading 95

**Output tray** 91

**Overlay tab** 104

## **P**

**Page margins** 75

**Paper Setup menu** 34

**Plain paper** 67

**Postcard** 71

**Poster copy** 116

**Print media** 66

Imageable area 75

Storage 92

**Print media type**

Envelope 69

Glossy media 73

Label 70

Letterhead 71

Plain paper 67

Postcard 71

Recycled paper 67

Thick stock 68

Transparency 72

**Print quality** 235

**Print screen** 23

**Printer driver**

Displaying 100

Setting 102

## **Q**

**Quality tab** 104

## **R**

**Recycled paper** 67

**Repeat copy** 115

**Reporting menu** 59

## **S**

**Scan** 122

Data format 146

Delete queued transmission job  
148

Duplex 147

Resolution 146

Scan color 148

Scan density 147

Scan mode 147

Scan size 148

Scan to E-mail 132

Scan to FTP 132

Scan to PC 130

Scan to SMB 132

Scan to USB Memory 130

Specify data location 130

Specify destination address 132

Subject 148

**Scan Setting menu** 61

**Scanned data destination address**

Delete destination address 138

Edit destination address 138

Register destination address 139

Specify destination address 132

Specify multiple destinations 137

**Scanner driver**

TWAIN driver (Macintosh) 125

TWAIN driver (Windows) 123

WIA driver (Windows) 124

**Select media tray** 111

**Service messages** 250

**Speed dial**

Editing/deleting address 143

Registering address (direct input)  
140

Registering address (LDAP search)  
142

Selecting address 133

**Storage**

Print media 92

**System requirements** 10

## **T**

**Thick stock** 68

**Toner remaining** 24

**Transparency** 72

**Troubleshooting** 199

Media misfeed 226

Status, error, and service  
messages 242

**TWAIN driver**

For Macintosh 125

For Windows 123

## U

**USB memory device** 130

**Utility menu** 27

Admin. Management menu 37

Copy Setting menu 51

Dial Register menu 53

FAX RX Operation menu 56

FAX TX Operation menu 54

Machine Setting menu 29

Paper Setup menu 34

Reporting menu 59

Scan Setting menu 61

## V

**Version tab** 105

## W

**Watermark tab** 104

**WIA driver** 124

## Z

**Zoom ratio** 110